

# Zebra Aurora Focus 9.2



**ZEBRA**

## User Guide

2025/04/09

ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corporation, registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners. ©2025 Zebra Technologies Corporation and/or its affiliates. All rights reserved.

Information in this document is subject to change without notice. The software described in this document is furnished under a license agreement or nondisclosure agreement. The software may be used or copied only in accordance with the terms of those agreements.

For further information regarding legal and proprietary statements, please go to:

SOFTWARE: [zebra.com/informationpolicy](http://zebra.com/informationpolicy).

COPYRIGHTS: [zebra.com/copyright](http://zebra.com/copyright).

PATENTS: [ip.zebra.com](http://ip.zebra.com).

WARRANTY: [zebra.com/warranty](http://zebra.com/warranty).

END USER LICENSE AGREEMENT: [zebra.com/eula](http://zebra.com/eula).

## Terms of Use

### Proprietary Statement

This manual contains proprietary information of Zebra Technologies Corporation and its subsidiaries ("Zebra Technologies"). It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the express, written permission of Zebra Technologies.

### Product Improvements

Continuous improvement of products is a policy of Zebra Technologies. All specifications and designs are subject to change without notice.

### Liability Disclaimer

Zebra Technologies takes steps to ensure that its published Engineering specifications and manuals are correct; however, errors do occur. Zebra Technologies reserves the right to correct any such errors and disclaims liability resulting therefrom.

### Limitation of Liability

In no event shall Zebra Technologies or anyone else involved in the creation, production, or delivery of the accompanying product (including hardware and software) be liable for any damages whatsoever (including, without limitation, consequential damages including loss of business profits, business interruption, or loss of business information) arising out of the use of, the results of use of, or inability to use such product, even if Zebra Technologies has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

# Contents

<b>About this Guide.....</b>	<b>10</b>
Icon Conventions.....	10
Notational Conventions.....	10
Service Information.....	11
Minimum PC Requirements.....	11
Installation.....	12
Localization.....	12
<b>Zebra Aurora Focus Software Overview.....</b>	<b>13</b>
Zebra Aurora Focus Features.....	13
UI Overview.....	14
HID Keyboard Localization.....	15
Additional Help and Resources.....	15
Device Discovery.....	16
Setting Up a New Device.....	16
Adding Devices via IP Address.....	16
Updating Firmware on Multiple Devices.....	17
Viewing Devices.....	17
Network Setup.....	21
Configuring Device Settings.....	21
General Settings.....	22
Communication Settings.....	27
GPIO Mapping.....	32
Configuring Jobs.....	33
Capture.....	34

## Contents

Trigger Settings.....	38
Using the Filmstrip.....	38
PLC Trigger Modes.....	38
Triggered Image Buffering.....	44
Using Autofocus Barcodes.....	46
Using ImagePerfect+.....	46
Using Golden Image Compare.....	48
Build.....	50
Barcode Quality Metrics.....	50
BQM Best Practices.....	51
Custom Formatting.....	51
Advanced Filtering and Formatting.....	53
Using Match String.....	56
Using Fixturing Tools.....	65
Using Automation Wedge.....	69
Deploy Mode.....	72
Using Undo/Redo.....	72
Connect.....	74
Output Formatting.....	75
FTP File Saving.....	75
Generating a Configuration Barcode.....	80
 <b>Connectivity Gateway Solutions.....</b>	 <b>83</b>
Asynchronous Passthrough.....	83
Synchronized Leader Follower.....	84
Gateway Licensing.....	85
Compatible PLC Devices.....	86
Setting Up Follower Devices.....	87
Configuring Follower Devices.....	88
GPIO Triggering.....	88
GPIO Mirroring.....	89
GPIO Pass/Fail.....	90
String Filtering.....	91
Serial Triggering.....	92

TCP/IP Triggering.....	94
Failure Timeout.....	96
Run Mode.....	97
Administrator Settings.....	99
Setting Up a Network.....	99
Configuring GPIO.....	101
Attributes.....	102
Configuring the Database.....	103
Enabling Alerts.....	104
Using ZETI with Follower Devices.....	106
Split Codes.....	107
PLC Configuration.....	108
Modbus Configuration.....	112
 <b>Accessing the Web HMI.....</b>	<b>116</b>
Web HMI Top Menu.....	116
Web HMI Dashboard.....	117
Live Monitoring with the Web HMI.....	118
Viewing Result History.....	119
Viewing the Job List.....	121
Viewing the Activity Log.....	122
Updating Device Firmware.....	122
USB-A to USB-C Hardware Setup.....	123
Firmware Update.....	123
Performing a Factory Reset.....	127
 <b>Using Fixed Industrial Scanning Tools.....</b>	<b>128</b>
Editing and Deploying FS Jobs.....	128
Using the Job Toolstrip.....	128
Fixed Industrial Scanner Settings.....	129
Using BQM for Fixed Scanning Jobs.....	130
Advanced.....	132
Image Banks.....	133

Symbologies.....	135
ManyCode.....	138
<b>Using Machine Vision Tools.....</b>	<b>140</b>
Deploying VS Jobs.....	140
Common Machine Vision Tool Settings.....	140
Using Image Types.....	140
Locate Tools.....	141
Locate Object.....	141
Locate Object Plus.....	144
Locate Edge.....	146
Locate Blob.....	147
Locate Circle.....	149
Filter Tools.....	151
Binarize.....	151
Dilate.....	152
Erode.....	153
Open.....	154
Close.....	155
Gradient Full.....	156
Gradient Horizontal.....	157
Gradient Vertical.....	157
Identification Tools.....	158
Using BQM for Identification Tools.....	158
Read Barcode.....	160
Read DPM.....	162
Read DPM and Barcode.....	163
Datacode.....	164
Using Accelerated Tools.....	167
Presence/Absence Tools.....	173
Object Presence Absence.....	174
Object Plus Presence Absence.....	176
Brightness.....	177
Contrast.....	178

## Contents

Edge Detect.....	181
Blob Presence Absence.....	182
Using Anomaly Detection.....	183
Measurement Tools.....	192
Distance.....	192
Circle Diameter.....	193
Measure Object Width.....	194
Counting Tools.....	196
Pixel Count.....	197
Blob Count.....	198
Edge Count.....	199
Locate Object Count.....	200
Flaw Detection.....	201
Edges.....	202
Intensity.....	203
<b>Upgrading a FS/VS Tools License.....</b>	<b>205</b>
FS/VS Licensing.....	205
License Types.....	205
Acquiring a License.....	206
License Acquisition Modes.....	206
Enabling the Activation ID.....	206
Applying a Device Upgrade License (Online).....	207
Applying a Device Upgrade License (Offline).....	210
Downloading the Offline License Upgrade .bin File.....	210
Applying a License in Offline Mode.....	216
Time Tampering.....	217
Returning a License.....	218
Fixed Industrial Scanning Toolset.....	219
Machine Vision Toolsets.....	219
Bridging an internet Connection to FS/VS Devices.....	220
<b>Connectivity Guidelines.....</b>	<b>223</b>

## Contents

Network Communication.....	223
Setting a Static IP Address.....	223
Changing the Hostname.....	223
TCP/IP Communication.....	224
Setting Up TCP/IP Triggering.....	224
Enabling TCP/IP Output in Device Settings.....	224
Configuring Jobs to Accept TCP/IP Triggers.....	224
Setting up RS-232 Hardware.....	224
Setting up RS-232 Triggering.....	226
Enabling RS-232 Output in Device Settings.....	226
Configuring a Job on the Device to Accept Serial Triggers.....	227
Sending a Serial Trigger to the Device.....	227
RS-232 Results.....	229
Listening to RS-232 Output Events.....	231
Listening for USB-CDC Output Events.....	233
Setting Up CDC-Serial Output in Device Settings.....	233
Listening Over USB CDC-Serial Connection.....	233
USB Settings.....	234
Enabling HID Keyboard.....	234
Adding a Keystring Delay.....	234
PLC Protocol.....	235
<b>Troubleshooting.....</b>	<b>236</b>
Firmware Troubleshooting.....	237
License Troubleshooting.....	238
FTP Troubleshooting.....	238
Testing the FTP Connection.....	241
Configuring the Firewall.....	241
<b>RegEx Overview.....</b>	<b>245</b>
RegEx Examples.....	245
<b>Using Zebra Easy Text Interface.....</b>	<b>264</b>

## Contents

Enabling Telnet Connections.....	264
ZETI Commands.....	265
autotune.....	266
backuprestore.....	267
deletejob.....	267
dwload.....	267
dwsideload.....	268
exposure.....	268
factoryreset.....	268
firmwareupdate.....	268
focus.....	269
gain.....	269
getcodes.....	269
getdecodes.....	270
getimage.....	270
getimageresettings.....	270
getgpiostatus.....	271
getgpiosetting.....	271
getjoblist.....	272
getlogfiles.....	272
getquantity.....	273
getresultimage.....	273
help.....	273
internallight.....	274
loadjob.....	274
protocolconfig.....	274
reboot.....	274
setgpiosetting.....	275
setgpiostatus.....	275
trigger.....	276
uploadjob.....	320

# About this Guide

This guide details using Zebra Aurora Focus to configure, deploy, and manage Fixed Industrial Scanning and Vision System jobs.

## Icon Conventions

The documentation set is designed to give the reader more visual clues. The following visual indicators are used throughout the documentation set.



**NOTE:** The text here indicates information that is supplemental for the user to know and that is not required to complete a task.



**IMPORTANT:** The text here indicates information that is important for the user to know.



**CAUTION:** If the precaution is not heeded, the user could receive a minor or moderate injury.



**WARNING:** If danger is not avoided, the user CAN be seriously injured or killed.



**DANGER:** If danger is not avoided, the user WILL be seriously injured or killed.

## Notational Conventions

The following notational conventions make the content of this document easy to navigate.

- **Bold** text is used to highlight the following:
  - Dialog box, window, and screen names
  - Dropdown list and list box names
  - Checkbox and radio button names
  - Icons on a screen
  - Key names on a keypad
  - Button names on a screen

- Bullets (•) indicate:
  - Action items
  - List of alternatives
  - Lists of required steps that are not necessarily sequential
- Sequential lists (for example, those that describe step-by-step procedures) appear as numbered lists.

## Service Information

If you have a problem with your equipment, contact Zebra Global Customer Support for your region. Contact information is available at: [zebra.com/support](http://zebra.com/support).

When contacting support, please have the following information available:

- Serial number of the unit
- Model number or product name
- Software/firmware type and version number

Zebra responds to calls by email, telephone, or fax within the time limits set forth in support agreements.

If your problem cannot be solved by Zebra Customer Support, you may need to return your equipment for servicing and will be given specific directions. Zebra is not responsible for any damages incurred during shipment if the approved shipping container is not used. Shipping the units improperly can possibly void the warranty.

If you purchased your Zebra business product from a Zebra business partner, contact that business partner for support.

## Minimum PC Requirements

Review the table below to ensure that your setup provides the requirements to support the application.

**Table 1** Minimum Requirements

Item	Description
CPU	Intel or AMD 64-bit processor
Random Access Memory Files	4 GB (Recommended: 8GB)
GPU	GTX 1030, Intel UHD 620 or equivalent
Graphics Memory	2 GB (Recommended: 4GB)
Disk Space	4 GB free disk space
Monitor Resolution	1280 x 800 (Recommended: 1920 x 1080)
Operating System	Windows 10 or higher

## Installation

Zebra Aurora Focus is available for download on the Zebra website: [Zebra Aurora Focus Software Downloads](#). After the download is complete, install the application as the administrator and enable Zebra Aurora Focus in Windows Defender.

## Localization

Translate the Zebra Aurora Focus UI to other languages by selecting the desired language from the menu in the upper right corner of the home screen.



# Zebra Aurora Focus Software Overview

The Zebra Aurora Focus application provides a unified platform with an intuitive interface for setting up, deploying, and running Fixed Industrial Scanning or Vision System jobs to control enterprise-wide manufacturing and logistics automation solutions. This tool also can scale in support of new codes and increase scanning speed with the potential to upgrade to machine vision functionality via software license upgrade.

## Zebra Aurora Focus Features


The Zebra Aurora Focus application provides several differentiating features to rapidly process, evaluate and compare multiple images in various lighting conditions without altering any hardware configurations.

Features include:

- QuickDraw – enables the user to draw right on an image to create a tool with minimum steps.
- Object Locate and Pattern Matching – Zebra's algorithms and intuitively crafted default settings enable users to consistently create and deploy efficient tools with less trial and error involved.
- Golden Image Compare – allows users to efficiently identify and resolve issues by comparing any image to an ideal image created at setup. This tool can significantly expedite troubleshooting activities by immediately diagnosing and correcting the source of degradation.
- Image Perfect - captures up to 16 different images, each with unique settings for focus, exposure, gain, and illumination control in one capture event.
- Deep Learning Optical Character Recognition (OCR) - uses Deep Learning tools to quickly read a variety of fonts within a user-defined region of interest (ROI) without training the tool with a large dataset.

## UI Overview

The Home screen features functionality such as viewing and configuring connected or emulated devices and settings for Fixed Industrial or Machine Vision scanning jobs.



**Table 2** Zebra Aurora Focus Home

Setting	Description
<b>Setup New Device</b>	Provides access to the configuration of existing (previously connected) and virtual (emulated) device settings and program jobs.
<b>View Devices</b>	View connected devices on your network.
<b>Settings</b>	Click <b>Settings</b> to manage localization and notification settings or clear the cache. <b>Enable Automatic Fixturing</b> options and <b>Image Capture Disk Management</b> settings on the <b>Job Management</b> tab.

Click the **Recent Activities** drop-down menu to sort by:

- Recent Activities
- Recent Jobs

- Recent Devices

Click the filter icon to filter by:

- Type
- Name
- Model Name
- IP
- Last Accessed

## HID Keyboard Localization

Zebra Aurora Focus supports the following HID keyboard languages:

- English (North America)
- French (France) Windows
- German Windows
- Spanish (Spain Windows)
- Italian Windows
- German Linux
- Czech Linux
- Spanish (Mexico) Linux
- French (France) Linux
- Polish Linux
- Spanish (Spain) Linux
- Italian Linux
- Portuguese (Brazil) Linux

## Additional Help and Resources

Access additional help and resources by clicking **Help** from the top menu.

Additional resources include:


- User Guides
- How-to Videos
- Tutorials
- Support Central
- Licensing Information
- About the Application

## Device Discovery

Emulated devices are accessible under **Virtual Devices** on the **Setup New Device** screen. Devices that are physically connected to the system and are available to connect and set up are viewable under **Existing Devices**.

## Setting Up a New Device

Click **Setup New Device** on the home screen to configure an FS or VS Emulator.



Select Emulator Selection and configure the settings for your emulator from drop-down menu.

**Table 3** Setup New Device

Setting	Description
Type	Select the toolset type for the emulator.
Resolution	Select the desired resolution of the emulator.
Model	Select a device model of the emulator.
License	Select the license type for the emulator.

## Adding Devices via IP Address

Connect to a camera by manually entering its IP address and clicking **Add Via IP Address** in the bottom right corner of the **View Devices** screen. Use this feature for devices with a known IP Address that are not automatically discoverable in Zebra Aurora Focus. You can also connect via IP address by entering the IP address (or hostname) into the **Add New Device via IP Address** form field and clicking **Connect**.

## Updating Firmware on Multiple Devices

Select devices on the **View Devices** list to perform a firmware update.

Update devices using a file stored on an FTP/FTPS server or uploading the file to the device (default).

- Specify the host, username, password, file path, and if the server is running in FTPS mode, to use the FTP / FTPS Server option.
- Select a firmware file from the File Explorer to use the File Based Upload option.

Use **Dual Update** to update the primary device partition, reboot the device, update the secondary partition, and reboot the device again.

Use **Force Update** to apply the same firmware version to all devices.

Firmware updates are performed on Connected devices only.



**NOTE:** It is not possible to open more than one **Update Firmware** window.

## Viewing Devices

Click **View Devices** to access additional device information such as name, part number, IP, serial number, firmware version, and status.

	Name	Model Name	Part Number	IP	SN	Firmware	Status
<input type="checkbox"/>	FS4082b1 Camera	FS40	FS40-WA50F4-2C00W	169.254.130.177	...0022	CAAESS00-003-R24	Managed



**NOTE:** Click the device IP address to access the Zebra Web HMI.

## Zebra Aurora Focus Software Overview

**Table 4** Device Information

UI Element	Description
Backup Device	Create a backup of the selected device. The resulting file is an encrypted archive that can be used only by the restore function.
Restore Device	Select a backup file and restore the device configuration. The process also triggers a complete reboot of the device.  ⚠ <b>WARNING:</b> Applying a backup from one model type to another can create some issues.
Update Firmware	Use this command to update the device firmware. This operation can also be done using the Web HMI.
Download Logs	This command refreshes the list of discoverable devices on the network.
Zebra Connectivity Gateway HMI	Access the Zebra Connectivity Gateway HMI.
Reboot	Reboot the device.
Factory Reset	Perform a factory reset on the device.

Click on the device row to view additional device information.



**NOTE:** Copy the device's Serial Number, Part Number, and Firmware Version before contacting technical support.

	Name	Model Name	Part Number	IP	SN	Firmware	Status						
<input checked="" type="checkbox"/>	FS4082b1 Camera	FS40	FS40-WA50F4-2C00W	172.16.107.22 (USB)	...0022	8.0	<span style="color: green;">● Managed</span>	<a href="#">Manage</a>					
<table border="1"> <tr> <td></td> <td><b>Overview</b> FW Version: 8.0 SN: 21363520180022 Mfg. Date: 29DEC21</td> <td><b>Communications</b> Current Connection Type: USB IP Mode (Static/DHCP): Static</td> <td><b>System</b> DHCP Timeout (s): 30 Uptime: 02:08:08 Sensor Type: 5.1 MP Mono Focus Unit: Diopter</td> <td><b>Status</b> Lens Type: Wide Angle External Illumination GPIO: True Available GPIOs: 9</td> </tr> </table>										<b>Overview</b> FW Version: 8.0 SN: 21363520180022 Mfg. Date: 29DEC21	<b>Communications</b> Current Connection Type: USB IP Mode (Static/DHCP): Static	<b>System</b> DHCP Timeout (s): 30 Uptime: 02:08:08 Sensor Type: 5.1 MP Mono Focus Unit: Diopter	<b>Status</b> Lens Type: Wide Angle External Illumination GPIO: True Available GPIOs: 9
	<b>Overview</b> FW Version: 8.0 SN: 21363520180022 Mfg. Date: 29DEC21	<b>Communications</b> Current Connection Type: USB IP Mode (Static/DHCP): Static	<b>System</b> DHCP Timeout (s): 30 Uptime: 02:08:08 Sensor Type: 5.1 MP Mono Focus Unit: Diopter	<b>Status</b> Lens Type: Wide Angle External Illumination GPIO: True Available GPIOs: 9									

**Table 5** Device Information

UI Element	Description
Overview	View device information including firmware version, serial number, manufacturing date, core services version, and ChiCore library version.
Communications	View communication settings including connection type and IP mode.

**Table 5** Device Information (Continued)

UI Element	Description
System	View system settings including DHCP timeouts, uptime, sensor type, and firmware version, and focus calibration type.
Status	View lens and illumination settings including lens type, illumination type, external illumination, external illumination GPIO, and number of available GPIOs.

## Multi-Device Management

Manage multiple cameras from Aurora Focus using **View Devices** list.

The screenshot shows the Zebra Aurora Focus software interface. The top navigation bar includes File, View, Help, and a language selection for English. The main title bar displays "VS70 - Device Settings" and "Zebra\_Inspect\_2024.04.29\_20.1... (VS) - Build". The left sidebar contains links for Get Started, Setup New Device, View Devices (which is selected and highlighted in blue), and Configuration Barcodes. The central content area is titled "View Devices" and shows a table with device information. The table columns are: Name, Model Name, Part Number, IP, SN, Firmware, and Status. A single device is listed: FS4082b1 Camera, Model FS40, Part Number FS40-WA50F4-2C00W, IP 172.16.107.22 (USB), SN ...0022, Firmware CAAESS00-004-N27, and Status Connected. At the bottom of the central area, there is a button labeled "ADD VIA IP ADDRESS". The bottom status bar shows "v7.0.34" and "Settings".


### Backing Up Multiple Devices

1. Select a device from the **View Devices** list to back up a device configuration, jobs, or both (default).

## Zebra Aurora Focus Software Overview

2. Click **Create Backup** to select a path to save the backup to.

The backup is performed on **Connected** devices. The status of the backup is shown in the **Status** column.



**NOTE:** Performing a backup interrupts the current job execution.

### Restoring Multiple Devices

To perform a restore on connected devices:

1. Select a device on the **View Devices** list to restore a backup.
2. Select the backup file.
3. Click **Restore Device** to initiate a device reboot.

## Network Setup

Zebra Aurora Focus can connect the device via Ethernet or USB-C-to-A(or C; host-side) cable to the Host PC. When connected, navigate to the **View Devices** screen to view all connected devices and their properties, such as **Name**, **Model Name**, **Part Number**, **IP Address**, **Serial Number**, **Firmware Version** and **Status**.

There are three options to connect a device to be discoverable in Zebra Aurora Focus:

1. Connect the device directly to a PC using a USB cable. Using this method does not have access to an internet source by default. In this case, bridge your internet connection using an adaptor. See Bridging an Internet Connection for additional information.
2. Use an M12-ETH cable to connect the device (M12) directly to the Ethernet port on the PC. This option does not provide access to outside internet by default. In this case, bridge your internet connection using an adaptor. See Bridging an Internet Connection for additional information.
3. Use an M12-ETH cable to connect the device (M12) to a switch or router (ETH) on the same subnet as the PC. In this setup, the device typically receives an IP address from the router provided by an Internet Service Provider and can reach outside internet to reach a license server. This is the recommended setup when performing license upgrades and typically does not require bridging a connection.

If access is restricted due to firewall:

- Contact the IT department to allow network traffic.
- Create a proxy server to allow traffic to the license server.
- Move the PC to a home network and attempt to connect again with a less restrictive firewall configuration.

### See Also

[Bridging an Internet Connection](#)

## Configuring Device Settings

Configurable device settings include details on the device, general beeper, power and LED settings, communication settings, and GPIO mapping.

## General Settings

Configure the beeper, power, and LED settings using the **General Settings** tab. Beeper settings can be set to turn on or off, and the beep's volume, tone, and duration can be configured to fit the needs of a specific use case.

The screenshot shows the Zebra Aurora Focus Software interface with the 'General Settings' tab selected. The left sidebar displays device details for the 'FS4082b1 Camera', including disk space usage (1.39/10.61 GB). The main panel is titled 'Beeper' and contains configuration options for beeper volume, tone, and behavior during job success. It also includes a 'Power' section with an option for unrestricted USB-A power. A warning icon is visible in the top right corner.


**Beeper**

- Beeper Enable
- Beeper Volume: High
- Beeper Tone: Medium
- Beep on Job Success
- Beeper Duration: Short
- Suppress Power Up Beeps

**Power**

- Unrestricted USB-A Power

# Zebra Aurora Focus Software Overview



**Table 6** General Settings

Setting	Description
<b>Beeper</b>	
Beeper Enable	Enable the beeper sound on the device.
Beeper Volume	Configure the volume of the beeper. <ul style="list-style-type: none"><li>• High</li><li>• Medium</li><li>• Low</li><li>• Off</li></ul>

**Table 6** General Settings (Continued)

Setting	Description
Beeper Tone	Configure the tone of the beeper. <ul style="list-style-type: none"><li>• High</li><li>• Medium</li><li>• Low</li><li>• Off</li></ul>
Beep on Job Success	When enabled, the device beeps upon successful completion of a job.
Beeper Duration	Configure the tone of the beeper. <ul style="list-style-type: none"><li>• Short</li><li>• Medium</li><li>• Long</li></ul>
Suppress Power-Up Beeps	When enabled, the power-up warble beeps that sound upon device start-up play at a reduced level.
<b>Power</b>	
Unrestricted USB-A Power	When enabled, the device receives unrestricted power from a USB-A power source. This is required to enable full-power internal lighting.
<b>Hardware Buttons</b>	
Tune Button Enable	Turn on or off the Tune button on the device.
Trigger Button Enable	Turn on or off the Trigger button on the device.
<b>Configuration Barcodes</b>	
Enable Parameter Barcodes	When enabled, the device configuration can be changed using a barcode
Timeout	Configure the maximum time (ms) to attempt to generate the barcode before a timeout occurs.
<b>360° LED</b>	
Number of Flashes	Use the slider to configure the number of flashes the LED illuminates upon decode.
Time per Flash	Use the slider to configure the number of times in ms the LED illuminates upon decode.
<b>Configure Logging</b>	
Logging Options	Select <b>Basic</b> or <b>All</b> to enable logging and generate files that provide additional information on job runs. Use the Web HMI to download the log files from the device.
<b>Continuous Acquisition Image Saving</b>	


**Table 6** General Settings (Continued)

Setting	Description
Continuous Acquisition Image Savin Debug Mode	When enabled, debug mode for Continuous Level and Presentation Trigger modes save all images for Continuous Trigger mode until the maximum image saved threshold is reached (the default is 100). The saved images provide insight into the frames acquired during a trigger session that did not result in a Pass. This mode differs from the standard No Read Image save functionality, which does not save No Read images during continuous image acquisition.
Maximum Images Saved	Define the maximum number of images saved during a continuous acquisition session. New sessions are started when switching jobs; jobs start after a device reboot and changes from Edit mode to Deploy mode.
New Sessions Clear Old Debug Images	Delete all previously saved images when a new session starts. This option is helpful to ensure all debug images are examined in the same session.

## Viewing and Downloading Logs

Enable logs that can be viewed using Perfetto Trace Viewer <ui.perfetto.dev/>. Logs are saved every two minutes on the device. Up to 10 log files are stored on the device (older logs are replaced by the newest).

To enable Perfetto Logs using Aurora Focus, set the **Logging Options** in the **Configure Logging** section of **General Settings** to **Basic** or **All**.



- Basic - provides standard device logging.
- All - provides logging for Zebra Support logs.

### Downloading Basic Logs

Download basic log information using Aurora Focus or the Zebra Web HMI when basic logs are enabled.


Using Aurora Focus, navigate to **View Devices** select a device and click **Download Logs** or click the ellipses to download logs from a subset of specific devices.

# Zebra Aurora Focus Software Overview

The screenshot shows the Zebra Web HMI interface. The top navigation bar has tabs for 'Setup Device', 'FS40 - Device Settings', and 'g (FS) - Capture'. On the left, a sidebar menu includes 'Get Started', 'Setup New Device', 'View Devices' (which is selected), and 'Configuration Barcodes'. At the bottom, there are 'Settings' and 'v6.2.6' buttons, and a 'ADD VIA IP ADDRESS' button. The main content area displays a table of devices, with one row selected for 'FS4082b1 Camera'.

	Name	Model Name	Part Number	IP	SN	Firmware	Status
<input type="checkbox"/>	FS4082b1 Camera	FS40	FS40-WA50F4-2C00W	169.254.130.177	...0022	CAAESS00-003-R24	Managed

Using the Zebra Web HMI, navigate to the **Activity Logs** tab and click Share to download Device or Aurora Logs.



**NOTE:** Downloaded Log files must be unzipped.

## Downloading All Logs

Download logs using the Zebra Web HMI when All logs are enabled.

Download the logs in the **Activity Logs** section using the **Device Logs** option.

## Viewing Perfetto Logs

Drag and drop the log file onto the Perfetto UI or use the **Open trace file** option from the left menu to launch File Explorer and locate the log file to import.

## Communication Settings

Configurable communication settings include network, DNS, date/time, PLC protocol, and USB settings. Refer to the FS/VS Industrial Ethernet User Guide for additional information on PLC protocol and Industrial Ethernet.

Click **Enable Edit Mode** to edit the configuration on the device.

### Network Settings

Ethernet Port 1
 Enable DHCP
⚠ Network controls are read-only when DHCP is enabled.

Network		Current Network	
IP Address	0 . 0 . 0 . 0	IP Address	
Subnet Mask	0 . 0 . 0 . 0	Subnet Mask	
Default Gateway	0 . 0 . 0 . 0	Default Gateway	
DNS		Current DNS	
Preferred DNS Server		Preferred DNS Server	
Alternate DNS Server		Alternate DNS Server	
DNS Domain Name		DNS Domain Name	
General			
DHCP Timeout	30	s	
Host Name	FS408b1		

## Network Settings

Configurable Network Settings include Network and DNS and General settings such as DHCP timeout and Host Name. Network settings vary for each Network interface: Ethernet Port 1, Ethernet Port 2, and USB.

**Table 7** Network Settings

Setting	Description
Enable DHCP	Enable DHCP to allow self-configuration of the device in an industrial network.
IP Address	Define the network IP address.
Subnet Mask	Define the network subnet mask.
Default Gateway	Set the default gateway to pass information to the device.
Preferred DNS Server	Set the preferred DNS server to connect the device to.

**Table 7** Network Settings (Continued)

Setting	Description
Alternate DNS Server	Set an alternate DNS server in case the preferred server is not available.
DNS Domain Name	Define a DNS domain name.
DHCP Timeout	Set a timeout for the time the device can use the DHCP server.
Host Name	Define the hostname.

## TCP/IP Settings

Configure TCP/IP settings, such as enabling TCP/IP Control, selecting a port number, selecting a terminator, or setting a trigger string.

**Table 8** TCP/IP Settings

Setting	Description
<b>TCP/IP Settings</b>	
Enable TCP/IP Control	Enabling the TCP/IP control interface allows the device to receive triggers over a TCP/IP connection.   <b>NOTE:</b> Disabling this interface when it is not in use is recommended.
Same Port for Control and Result	TCP/IP input and output communications are on the same port number when enabled.
Connection Type	Server (Default): Host systems attach the device to the Control Port Number, and the data is sent out with the Control Terminator.  Client - The device connects to a host system at the specified IP address, Port Number and use Control Terminator to send the data packet.
IP Address	Enter the host IP address when the Connection Type is set to Client.
Control Port Number	Select a port number that accepts ASCII command strings for the device.
Control Terminator	Select a terminator that follows the incoming ASCII command string.
Trigger String	Set a customizable trigger command. Sending this string to the Control Port with the Control Terminator triggers the deployed job on the camera when the TCP/IP trigger is selected in the Capture chevron.
<b>Results</b>	
Enable TCP/IP Results	Enabling the TCP/IP Results interface allows the device to output result data over a TCP/IP connection.   <b>NOTE:</b> Disabling this interface when it is not in use is recommended.

**Table 8** TCP/IP Settings (Continued)

Setting	Description
Connection Type	The Server Host system attaches to the device using the Result Port Number. The data is sent out with the Results Terminator. The device connects to a host system when the Client is enabled at the specified IP address. Port Number uses Result Terminator to send the data packet.
IP Address	If the Connection Type is set to Client, enter the IP address.
Results Port Number	When in Server mode, the port that the device sends the data out on. When in Client mode, the port on the device's host system connects to.
Results Terminator	For both Client and Server modes, the Results Terminator is the termination text of the string data package. The default setting is CR+LF.
Timeout	When in Client mode, the time the device attempts to connect to the host system.
<b>Deploy Mode Heartbeat</b>	
Enable TCP/IP Heartbeat	When enabled, this setting prompts the device to send out a heartbeat message at the defined interval to the connected TCP result host. The host uses this heartbeat message to verify that the connection with the device is active.   <b>NOTE:</b> This setting only sends out a heartbeat message while a job is deployed. The heartbeat stops when the device is in Edit mode and resets after each TCP/IP output.
Heartbeat Interval	Set the heartbeat time interval.
Heartbeat Sequence	Create an arbitrary sequence of text and special characters for the heartbeat message.

Click **Test Connection** to check port availability before attempting to connect.

## RS-232 Settings

Configure various RS-232 settings such as a terminator, trigger string, baud rate, or parity.



**NOTE:** Enabling RS-232 control enables the device to receive control messages from RS-232. For additional information, refer to the Connectivity Guidelines section.

**Table 9** RS-232 Settings

Setting	Description
Control	Configure the device control settings over RS232
Enable RS-232 Control	Enable or disable control messages issued to the device through the RS-232 serial port.
Control Terminator	Identify a terminator.
Trigger String	Identify a customizable trigger command. Sending this string to the Control Port with the Control Terminator triggered the active job on the device with TCP/IP Trigger is selected in the Capture chevron.

**Table 9** RS-232 Settings (Continued)

Setting	Description
Results	Enable or disable the transmission of the result message to the serial port.
Speed (Baud Rate)	Configure the speed at which information is transferred to the device.
Data Bits	Determine the number of data bits per block of data transmitted.
Parity	Select an error-checking bit that returns a logic bit depending on the number of data bits expected.
Stop Bits	Determine the number of bit periods to wait before sending the next start bit.

## Date/Time Settings

Configure date/time settings by providing an NTP server.



**NOTE:** There is no internal battery in the device, therefore, date and time settings are not preserved.

**Table 10** Date/Time Settings

Setting	Description
NTP Server 1	The IP address of the primary Network Time Protocol server to synchronize to. Default: 0.pool.ntp.org
NTP Server 2	The IP address of the second Network Time Protocol server to synchronize to. Default: 1.pool.ntp.org

## PLC Protocol

Determine the appropriate PLC protocol based on your use case.

Select the PLC protocol from None, EtherNet/IP, Profinet, or Modbus TCP. For additional information, refer to the FS/VS Smart Camera Series Industrial Ethernet User Guide.

**Table 11** PLC Protocol

Settings	Description
Industrial Ethernet/PLC Options	Select the desired industrial protocol for device communication.

## USB Settings


Enable specific USB settings such as a HID keyboard, keystroke delay, or terminator.

**Table 12** USB Settings

Settings	Description
Enable HID Keyboard	<p>Enabling the HID keyboard interface allows the device to output result data in a HID keyboard mode. This restarts USB communication as a Human Interface Device class keyboard to emulate keystrokes.</p> <p> <b>NOTE:</b> It is recommended to disable this interface when not in use. The device can be set to either HID keyboard or USB CDC-Serial mode. Both modes cannot be enabled simultaneously.</p>
Keyboard Country Type	<p>Select your country from the list of available Keyboard Country Types.</p> <ul style="list-style-type: none"> <li>• English (North America)</li> <li>• French (France) Windows</li> <li>• German Windows</li> <li>• Spanish (Spain Windows)</li> <li>• Italian Windows</li> <li>• German Linux</li> <li>• Czech Linux</li> <li>• Spanish (Mexico) Linux</li> <li>• French (France) Linux</li> <li>• Polish Linux</li> <li>• Spanish (Spain) Linux</li> <li>• Italian Linux</li> <li>• Portuguese (Brazil) Linux</li> </ul>
Keystroke Delay	Set the delay (in ms) between emulated keystrokes when HID is enabled.
Special Key Keystroke Delay	Set the delay (in ms) between emulated special keystrokes when HID is enabled.
<b>Control</b>	
Enable USB CDC-Serial Control	Activate the management of special commands received by the CDC-Serial port.
Control Terminator	Set the message terminator that follows the incoming ASCII command string.
Trigger String	Command string used to trigger new image acquisition.
<b>Results</b>	
Enable USB CDC-Serial Results	Enable the transmission of the results over the CDC-Serial port.

## GPIO Mapping

Configure the GPIO on the 12-pin and 5-pin connectors by selecting the GPIO and configuring its direction and signal type. Enable External Illumination mode for the 5-pin connector by specifying its mode.



**Table 13** GPIO Mapping


Setting	Description
Direction	Configure the input signals coming into the device, or the output signals sent out. Select the GPIO port configuration: Input, Output, Static High, and Static Low. Static High sources the current for an external load. Static Low sinks the current for an external load.
Signal Type	Configure the Signal Type: Normal or Hardware Trigger. Normal Trigger - signal is routed through the device software. Normal Trigger is useful for Continuous, Level, periodic, Presentation, and Burst modes. Hardware Trigger - signal is routed through the device hardware directly to the sensor, bypassing the processing of the trigger. Hardware Trigger is more responsive and useful for Single Trigger use cases.
Advanced Settings	Use Input to configure Input Debounce and Input Delay. Use Output to configure Pulse Width and Output Delay.

**Table 13** GPIO Mapping (Continued)

Setting	Description
External Illumination Mode	Toggle this setting to automatically configure the pins in this port to power and control external illumination.

## Configuring Jobs


Configuration and deployment of FIS or MV jobs are facilitated using the Capture, Build, and Connect chevrons.



- **Capture** - configure the Job Mode and Source settings on the Triggers tab and imager settings on the Acquisition Settings tab.
- **Build** - depending on the toolset (FIS or MV), configure the settings and symbologies or tools used to complete a specific job.
- **Connect** - save and configure image settings and network connections such as Industrial Ethernet, Output Formatting, and GPIO Mapping.

## Capture

The Capture chevron configures **Triggers** and **Acquisition Settings** for Fixed Industrial Scanning or Machine Vision jobs.



**Table 14** Trigger Settings


Item	Description
Source	Select the trigger source from GPIO, Device Trigger, Serial, PLC, TCP/IP Auto(Self), Test Trigger
Job Mode	Select the Job Mode between Single Shot, Level Continuous, Series (Burst), Periodic Single Shot, Continuous, Presentation
Show Image	Enable to configure Show Image settings. When enabled, the device sends the images back to Aurora Focus. This takes cycle time. For the faster job times, the frequency of images being sent can be reduced or disabled by configuring these settings.
Show Image Mode	Determine the method to update Shown Images.
Update Every	Determine how frequently shown images are updated per inspection.

## Zebra Aurora Focus Software Overview

**Table 14** Trigger Settings (Continued)

Item	Description
Triggered Image Buffering	Buffer images for triggers received while a job is in progress.
Maximum Image Queue Size	Determine the maximum number of images queued before images are dropped from the queue.
Drop Mode	Determine the approach to drop images when the queue is full.

Acquisition Settings determine the configuration used to capture images with the device.



**Table 15** Acquisition

Setting	Description
Barcode Autotune	Force an automatic tune procedure that configures the camera to read the barcode or Datamatrix and adjust <b>Exposure</b> , <b>Gain Factor</b> and <b>Focus</b> .
Autotune Settings	Open the dialog to adjust the Autotune Settings.
Image Perfect+ Setup	The setup list on the left is the possible configuration for Image Perfect+.
Add Settings	Use this command to add a new setup to Image Perfect+
Name	Assign a name for the Image Acquisition Setup
Exposure	Exposure time in ms.
Long Exposure	Activate this option to adjust the exposure time from 33 to 750 ms.
Gain Factor	Use this slider to adjust the sensor gain factor from 0 to 100.
Focus	Use this slider to adjust the focus length.
Focus Unit	Select Millimeter, Inch, or Diopter to configure the focus measurement units on the device.   <b>NOTE:</b> Depending on the hardware version of your device, <b>Millimeter</b> and <b>Inch</b> measurements are available in addition to <b>Diopter</b> . While the millimeter and inch distance values calculated in the application may slightly differ from the real-world distance value, this does not impact the device's performance.
Aiming Configuration	Enabling this feature projects an aiming pattern onto the surface where the camera is pointing, helping to position the camera by identifying the focal point of the field of view.
Internal Illumination	This setting is only available with Unrestricted USB Power, PoE, and 24V external power.  Select the Light Intensity (0-10V), color (red, white, green, IR), and quadrant (top, bottom, left, right) of the 360° LED light.

**Table 15** Acquisition (Continued)

Setting	Description
Light Intensity	<p>Use the slider to increase light intensity by sliding to the right.</p> <ul style="list-style-type: none"> <li>• Minimum: 1</li> <li>• Default: 4</li> <li>• Maximum: 10</li> </ul>
Torch Mode	<p>When enabled, the internal lights of the device are powered with static DC voltage with no strobing or overdrive.</p> <p>Torch mode offers dimmer illumination, but allows for extended lighting durations.</p> <p>This can be helpful for use cases that do not have movement and necessitate an extended exposure time.</p>
Red Light	<ul style="list-style-type: none"> <li>• Top: enable this setting to use the top illuminator on the device.</li> <li>• Bottom: enable this setting to use the bottom illuminator on the device.</li> <li>• Right: enable this setting to use the suitable illuminator on the device.</li> <li>• Left: enable this setting to use the left illuminator on the device.</li> </ul>
External Illumination	<p>Internal and External illumination can be activated simultaneously on FS42 devices while connected to a 24V DC power supply.</p> <p>Select the Light Intensity (0-10V).</p>
Light Intensity	<p>This controls the analog voltage pin on the Analog Output Pin.</p> <ul style="list-style-type: none"> <li>• Minimum: 1</li> <li>• Default: 8</li> <li>• Maximum: 10</li> </ul>

**See Also**

[Viewing Devices](#)

## Trigger Settings

Different trigger settings are enabled based on the job mode.




**NOTE:** Datacode supports Single Shot, Level Continuous, Periodic Single Shot, Continuous, and Presentation modes.

- Single Shot - initiates a single image capture. Single Shot helps inspect an image.
- Level Continuous - initiates an image capture on a level trigger for objects in motion. This is helpful for use cases involving a conveyor belt.
- Series (Burst Mode) - initiates a series of image captures. Burst mode is helpful for use cases that require capturing a series of images based on a user-defined number of trigger intervals and frequencies.
- Periodic Single Shot - initiates a single image capture after a user-defined period of time. It is helpful for debugging.
- Continuous - initiates a series of captures rapidly. Continuous is helpful for barcode scanning applications.
- Presentation Mode - illuminates the scan window when the sensor detects motion. This mode is helpful for kiosk and retail point-of-sale applications.

## Using the Filmstrip

Drag images onto the Filmstrip from your PC to add to the image bank.




## PLC Trigger Modes

The device supports different use cases with single shot, level continuous, series (burst), periodic single shot, continuous, and presentation trigger modes.

### Single Shot

When the job is in Single Shot trigger mode, the device runs one job on each trigger and decodes the barcode.

## Zebra Aurora Focus Software Overview




Toggle the trigger bit from 0 to 1 to perform a trigger. The job stops when the trigger is complete. Toggle the trigger bit to run the job again. Toggling the trigger bit from 0 to 1 runs the job one time.

## Level Continuous

Level Continuous initiates an image capture on a level trigger for objects in motion. This trigger mode is helpful for use cases that involve a conveyor belt. This mode consistently captures the image for the duration specified in the Active Job Timeout setting. When that duration expires, the job stops capturing the image.

# Zebra Aurora Focus Software Overview



To trigger the job for the first time, the trigger bit state should be toggled from 0 to 1. The job runs for the time specified in Active Job Timeout and stops. Toggle the trigger bit state from 0 to 1 to trigger the job for the first time. Toggle the trigger bit from 0 to 1 before the Active Job Timeout to manually stop the job. Toggle the trigger bit from 0 to 1 again to trigger the job again.




**NOTE:** Toggling the trigger bit from 1 to 0 does not effect the job.

## Series (Burst)

Burst mode initiates a series of image captures, which is helpful for use cases that require capturing a series of images based on a specified amount of trigger intervals and frequency.

# Zebra Aurora Focus Software Overview




In this mode, the first trigger event (toggling the trigger bit from 0 to 1) starts the burst sequence. Consecutive trigger events do not have any effect until the previous burst sequence is complete. The following trigger event (toggling the trigger bit from 0 to 1) starts the burst sequence again.

## Periodic Single Shot

Periodic Single Shot mode initiates a single image capture after a specified time. This is helpful for debugging use cases.

# Zebra Aurora Focus Software Overview




Periodic Single shot maintains the triggering job periodically after a specified period. Send the trigger again to stop the job in progress. While using PLC, the first trigger (toggling the trigger bit from 0 to 1) starts the job, and a second trigger event (toggling the trigger bit from 0 to 1) stops the job.

## Continuous

Continuous mode initiates a series of image captures rapidly. This mode is helpful for barcode scanning applications.

## Zebra Aurora Focus Software Overview




While in Continuous Mode, the PLC behavior is the same as in Periodic Single Shot mode.

## Presentation

Presentation mode illuminates the scan window when the sensor detects motion. This mode is helpful for kiosk and retail point-of-sale applications.

# Zebra Aurora Focus Software Overview



The first trigger event (toggling the trigger bit from 0 to 1) starts Presentation mode. Send the second trigger event (toggling the trigger bit from 0 to 1) before scanning the barcode to cancel Presentation mode.




**NOTE:** Presentation mode stops after the barcode successfully decodes and restarts when the next trigger event occurs.

## Triggered Image Buffering

When Triggered Image Buffering is enabled, there is an image processing event and one buffer event between each trigger occurrence.

Increase the **Maximum Image Queue Size** to configure the size of the image queue.

Select the **Drop Mode** from the menu to determine when images should no longer be included in the queue.




### Using Autofocus Barcodes

Use calibration barcodes to set the device's focus settings automatically.




**NOTE:** This process only adjusts the focus setting on the device and does not adjust exposure or gain.


Bring one of the following calibration barcodes into the device field of view:



5s delay



8s delay



13s delay

1. Read one of the autofocus barcodes to start the focus-tuning process based on the selected delay (8s, 13s, or 18s).



**NOTE:** Observe the status LED flash every 500ms during the delay, providing time to bring the test barcode into the field of view to tune the focus on it.

2. During this delay, bring the desired test barcode into the field of view for the autofocus process to use as a reference. It is recommended to tune the focus of the device with a barcode type that is commonly decoded in your use case.



**NOTE:** Do not use the calibration barcode as the test barcode to calibrate focus against.



3. After the delay, the autofocus process starts and continues for 5-15 seconds.
4. Listen for the confirmation beeper sequence indicating the focus calibration process is complete.

### Using ImagePerfect+


ImagePerfect+ is an intuitive functionality used to grab additional images from the same trigger using a set of Acquisition Settings. It is helpful in acquiring images with different shutters, gain, focus, or different illumination configurations.

Single Shot and Periodic Single Shot are supported for use with ImagePerfect+.

Click **Default Setup** to clone the current configuration or click **Add Settings** at the bottom of the page to create a new configuration.



Delete a configuration by clicking the ellipses:



**NOTE:** FS10/xS20 devices support a maximum of three Acquisition Settings.




**NOTE:** xS40 and xS70 devices support a maximum of 16 Acquisition Settings.

### Saving ImagePerfect+ Images

The smart camera saves only images processed by the decoder.


For the FTP to save bank\_0 and bank\_1, it is important to add both banks while configuring in **Build > Image Banks**.




## Using Golden Image Compare

Use Golden Image Compare to inspect two images from the Filmstrip simultaneously.

1. Acquire a frame using the capture button  in the bottom right corner of the canvas.
2. Select the frames to set as Golden Image candidates by clicking the transparent yellow rectangle icon in the top right corner of each frame in the filmstrip.




3. Next, capture a new image or select frames in the filmstrip to compare to the golden image.




4. Hover over the three dots  on the right of the canvas to view the dialog box menu and select the yellow Golden Image compare icon  at the bottom of the menu.

## Zebra Aurora Focus Software Overview

5. Select the Golden Image candidate to compare to the current image in the canvas and click **Next**.



6. Observe the Golden Image Compare window to simultaneously inspect the Golden Image and the current image in the canvas side by side.




7. Hold the CTRL button on the keyboard while scrolling and zoom in or out using the scroll wheel on the cursor.



**NOTE:** Scroll to zoom in or out and inspect the same area of each image side-by-side. At the bottom of each image, use the window where the cursor is positioned to view a given pixel's XY position values and RGB color values.

## Build

The **Build** chevron facilitates job configuration and deployment for FIS and MV tools.



**Table 16** Build Settings

Settings	Description
View Results	View the results of recent jobs.
Image Viewer	Observe the tool's analysis of the image.
Filmstrip	View the series of images captured by the device or upload a previously captured set of images.
Deploy	Run the job as configured in FlowBuilder.

## Barcode Quality Metrics

Barcode Quality Metrics (BQM) are used to verify the quality of your printed barcode so you know you can count on it to perform in its necessary setting. Enabling BQM reports an overall grade for the decoded barcode and grading based on various sub-components.



**NOTE:** The BQM mechanism in Zebra Aurora Focus implements the ISO15415/ISO15416 standard. Per ISO specifications, the optical reference arrangement requires high resolution, such as an

effective resolution of not less than ten pixels per module in width and height. Refer to ISO 15415 for additional information.

Zebra BQM measures the barcode quality in the captured image, not the barcode itself. BQM score stability is dependent upon image quality stability. To calculate the quality of the barcode, measure it in a strictly controlled manner using an image acquisition procedure.

BQM in Zebra Aurora Focus uses coarse grading. For example, the score step size is 1, per the ISO specs. A specific score of 2.9 is graded as 2 (C), although it is close to 3 a (B).

## BQM Best Practices



**NOTE:** While ISO specs recommend a minimum of 1OPPM, achieving a PPM of 15 or greater is recommended to ensure consistent BQM results.

Follow the best practices outlined in this section to ensure optimal BQM performance.


- Consistent lighting with high contrast, little to no gradient, and clear focus is critical to achieving optimal BQM results. Maximum pixel intensity should be between around 160 and 200 with reasonably good contrast. Ensure there are no defects or glare on the image; no specular spots should be present.
- Consider using a polarized light filter accessory to eliminate glare. A clean and consistent barcode is essential for BQM grading; a polarizer can be helpful to eliminate glare that could compromise the barcode image.
- Position the barcode close to the center of the Field of View (FOV) to minimize any optical distortion and ensure that the barcode is parallel to the camera plane on the device so the edges are parallel to the image border.

## Custom Formatting

Use Custom Formatting to retrieve specific data by adding rules and delimiters.


To configure **Custom Formatting**, access the **Data Formatting** tab from the **Build** chevron.

1. Select the **Custom Formatting** radio button.




## Zebra Aurora Focus Software Overview

### 2. Select a symbology from the **All Symbologies** list.




3. Depending on the symbology, click **Add Rule** to add a find and replace rule.
4. Click next to **Find** to add a data type to identify.
5. Next, click next to **Replace With** to designate a data type to replace the data type identified in the Find form field.
6. Click next to the **Prefix** form field to add a data type. Follow the same steps for **Data** and **Suffix**.




## Zebra Aurora Focus Software Overview

7. Select a **Data Type Delimiter** from the drop-down.



8. Select a **End Delimiter** from the drop-down.



9. Click **Get Last** to retrieve the **String** or **Result**.

String	S20065010573543
GET LAST	
Result	
RESET TO DEFAULT	

## Advanced Filtering and Formatting


The following functionalities are not supported in Aurora Focus:

- Non-standard, customer-specific check digit calculations
- Location based Pattern Match requirements based on barcode positional dependencies such as Code 128 is on the left of a UPC
- Interjection of time delays between transmitted barcode data
- Non-ASCII values

To configure Advanced Filtering and Formatting settings in Aurora Focus:

## Zebra Aurora Focus Software Overview


1. Select the **Data Formatting** tab to access **Advanced Filtering and Formatting**.
2. Select the **Advanced Filtering and Formatting** radio button.
3. Click **Edit Rules** to create a new rule or edit an existing rule. Rename the rule if necessary.




4. To add a **Filter**, click **Edit** and select an **And** or **Or** operation from the drop-down menu, or select the **Not** checkbox to invert the result.



- a. Click **Add Criteria** to add a condition to the rule from the drop-down menu.




- b. Click **Add Group** to add a parenthesis block that contains rules separated by the same combinator.




## Zebra Aurora Focus Software Overview

### 5. To add an **Action**, click **Add**.


- Select a type of **Action** (send, move, remove, or individual).
- Click **+** to specify an **Action** to add to the list of selected actions by clicking the plus sign.




- Use **Send Function Key** to configure which function key to send as the keystroke for the HID output interface. The range of keys is from F1 to F24. Add modifiers when applicable, including Left Ctrl, Right Ctrl, Left Alt, Right Alt, Left Shift, Right Shift, and Windows.



- Edit the action by clicking **Edit** on the selected action.



6. After a **Filter** and **Action** are identified for the rule, and rules are managed by clicking the ellipses.




## Using Match String

Use Match String to determine if the code has a specific string present.

Match String supports the following tools:


- Datacode
- Deep Learning OCR
- Read Barcode

For cases where match string functionality is not necessary, ensure **Barcode String Match** is disabled.




In cases where the data code contains the given string, the job passes.

## Zebra Aurora Focus Software Overview



In cases where the data code does not contain the given string, the job fails.


# Zebra Aurora Focus Software Overview




## Using Set and Get Match Strings

Match Strings are configurable in Aurora Focus for Datacode, Deep Learning OCR, and Read Barcode tools.

1. Add the tool in **FlowBuilder** using the **Build** tab to view match string options.



2. Select the **Barcode String Match** mode from the drop-down menu.



- Disabled (Default) - no match string is used, and every string is accepted.
- Exact string - the result must match the exact string provided.
- String Contains - the result must contain the given string.
- Regex - result acceptance follows the given regex rule.



**NOTE:** **Barcode String Match** mode is disabled by default and the match string value is empty. In this case, the tool accepts all read codes.

3. Click **Last Decode** to use the last successful read string as the current match string value.


## Command Channels

Match strings are set by channels that support controlling devices that use commands such as TCP/IP or Serial Port.



**NOTE:** Ensure that **Enable TCP/IP Control** and **Enable TCP/IP Results** are enabled in **Communication** settings.

## Zebra Aurora Focus Software Overview



Enabling **TCP/IP Results** is necessary if command results are required to be read from the channel. It is recommended to enable this setting even in cases where the return value is unnecessary for the set command because it can return useful information about possible errors.



**NOTE:** You cannot get a match string value if this option is disabled.

### Available Commands

Parameters are preceded with two strings that inform what action should be performed and which job parameter it applies to.

The first string informs whether the command should get (**GetJobParameter**) or set (**UpdateJobParameter**) as the value. The second string informs which job parameter should be updated (in this case, use **matchstring**).

Provide the parameters in the following command line format:

```
--parameter_name parameter_value
```

For string parameters, use double quotes:

```
GetJobParameter matchstring --toolname "Datacode 1"
```

For boolean values, use true or false:

```
UpdateJobParameter matchstring --value "XYZ" -- persistent true
```

For the enum parameter, enter the parameter value without quotes:

```
GetJobParameter matchstring --format plain
```

In cases where arguments do not take any value, provide the argument name:

```
GetJobParameter matchstring --help
```

## Get Match String Commands

If an optional argument is not provided, use the default value.



**NOTE:** Skipping a required parameter results in command failure

Get Match String command:

```
GetJobParameter matchstring [optional parameters]
```

Parameters:

**Table 17** Get/Set Command Parameters

Parameter	Argument	Optional	Description
help	no argument	Yes	Produce a help message with a description of all commands. If provided, other arguments are ignored, and only the help output is returned.
toolname	string ( <b>empty string</b> by default)	Yes	Friendly name of a tool. If provided, the result will contain only data for the given tool (and only if the given tool is found and supports a match string). Otherwise, the result contains data for all tools.
format	enum ( <b>plain</b> / base64)	Yes	The format used to present the match string in the result.

Example input:

```
GetJobParameter matchstring --format plain
```

Example result:

```
[GetJobParameter result] Get match string result: ["GetMatchStringEntries", [{"MatchMode": "STRING_EXACT", "MatchString": "ABC", "Toolname": "Datacode 1"}]]
```

## Set Match String Commands

If an optional argument is not provided, use the default value.



**NOTE:** Skipping a required parameter results in command failure.

Set Match String Command:

```
UpdateJobParameter matchstring --value "match string value" [optional parameters]
```

**Table 18** Set Match String Command Parameters

Parameter	Argument	Optional	Description
help	N/A	Yes	Produce a help message with a description of all commands. If provided, other arguments are ignored, and only the help output is returned.
toolname	string ( <b>empty string</b> by default)	Yes	Friendly name of a tool. If provided, the match string is applied only to the tool with the given tool name; otherwise, it is applied to all tools supporting the match string.   <b>NOTE:</b> If this parameter is omitted or an empty string, other parameters are applied to all tools supporting the match string.

**Table 18** Set Match String Command Parameters (Continued)

Parameter	Argument	Optional	Description
format	enum ( <b>plain</b> / base64)	Yes	<p>Format of provided match string. Setting the format to base64 makes the value parameter to be interpreted as base64.</p> <p> <b>NOTE:</b> This applies only to the value you insert in the command and doesn't influence the way of storing match strings internally by Aurora Focus.</p>
persistent	bool ( <b>true</b> / false)	Yes	If true, setting the match string will be persistent (saved in the database). Otherwise, it will only be applied to a currently deployed job.
match_mode	enum string ( <b>unknown</b> / disabled / string_contains / string_exact / regex)	Yes	<p>Match mode:</p> <ul style="list-style-type: none"> <li>• unknown - either previous mode from job is used or string_contains, if it was not set;</li> <li>• disabled - every match string is accepted, regardless of set value;</li> <li>• string_contains - result must contain given match string in any place;</li> <li>• string_exact - result must exactly match the given match string;</li> <li>• regex - result acceptance follows the given regex rule.</li> </ul>
value	string	No	Match string value. If the format parameter is set to base64, then the value is interpreted as base64; otherwise, it is plain text.

Example Input:

```
UpdateJobParameter matchstring --value "XYZ"
```

Example Result:

[UpdateJobParameter result] Set match string, success

## Using Fixturing Tools

Use fixturing tools to focus on a specific symbology in environments where codes are processed rapidly and may be presented in different orientations.



**NOTE:** All 1D and 2D symbologies are compatible with fixturing tools.

1. Create a new job.
2. Add the Read Barcode tool to the FlowBuilder.

The screenshot shows the Zebra Aurora Focus software interface. The top navigation bar includes File, Edit, View, Image, Device, Help, and a language selection for English. Below the navigation bar, there are tabs for Get Started, NS42 - Device Settings, and Zebra\_Inspect\_2025.03.26\_00.5... (VS) - Build. The main workspace is divided into two main sections: FlowBuilder on the left and Image Viewer on the right.

**FlowBuilder Panel:**


- Toolbox:** Shows various inspection tools like Read Barcode, Read Barcode 1, etc.
- FlowBuilder Area:** Displays a flowchart with a "Read Barcode" node selected. It includes settings for Fixture (None), Image Type (Default Setup (Bank 0)), and Decode options (Timeout: 2000 ms, Inverse 1D: Regular, Min % Barcode/ROI Overlap: 20).
- Results Area:** Shows a green checkmark indicating success.

**Image Viewer Panel:**

- Image Status:** Status: Pass, Tool Time: 0 ms, Job Run Time: 0 ms, PPM: 7.2, Symbology: DATAMATRIX, BQM Grade: -.
- Image Preview:** Shows a barcode and the text "Zebra Technologies". A green box highlights the barcode area, labeled "Read Barcode 1 | Default Setup (Bank 0)".
- Filmstrip:** Shows a sequence of images, with the second image highlighted by a green border. It displays the same barcode and text from the viewer.
- Bottom Buttons:** Includes "Editing", "Edit", and "Deploy" buttons.

## Zebra Aurora Focus Software Overview


3. Add an additional tool, such as Deep Learning OCR.



4. Ensure that Manycode is disabled before using fixuring.



5. Select the first tool (Read Barcode) from the Fixture drop-down list.




6. Deploy the job and move the test image. Observe the Deep Learning OCR tool's ROI following the Barcode tool results.



## Using Automation Wedge

Automation Wedge transmits data captured by the smart camera to an application running on a Zebra mobile computer. Use Automation Wedge to enhance productivity by streamlining the process of collecting and utilizing data from physical sources.

1. Navigate to the **Communication** section in **Device Settings**.
2. Click **Enable SSI communication over USB** in the USB settings section.



The screenshot shows the 'FS42 - Device Settings' window for an 'FS423b49 Camera'. The left sidebar has sections for 'View Devices', 'Power Source: PoE+', and 'Device Settings' (which is expanded, showing '1 Device Details', '2 General', '3 Communication' (selected), and '4 GPIO Mapping'). The main area shows 'IE / PLC Options' set to 'None'. Under 'USB Settings', 'USB Speed' is set to 'USB 3.0'. The 'Results' section includes 'Enable HID Keyboard' (unchecked). Under 'SSI Communication', 'Enable SSI communication over USB' is checked with a warning icon. Under 'USB CDC-Serial Control', 'Enable USB CDC-Serial Control' is unchecked. Buttons for 'CREATE CONFIGURATION SNAPSHOT', 'LOAD CURRENT JOB', 'OPEN JOB', and 'NEW JOB' are at the top right.




**NOTE:** SSI mode can only be enabled if HID results, CDC results and CDC Control options are disabled.

3. Navigate to job settings and configure. **Source** and **Job Mode** settings from the drop-down menu on the **Triggers** tab.




**NOTE:** Only auto modes are supported in job settings when SSI mode is enabled. The job starts when the device receives the enable command.


- Supported Trigger Sources: Auto/Self



- Supported Trigger Modes: Presentation, Continuous and Periodic Single Shot



4. Ensure that **Aim Code Identifier** is enabled when creating a new job in SSI mode.



**NOTE:** An Aim Code Identifier is required for decoded data to be transmitted correctly. If it is not enabled, the first three characters may get removed from the barcode data sent to the device.

## Deploy Mode

Use Deploy mode to view the job results and decode summary.

Click **Deploy** while in **Edit** mode to enter **Deploy** mode and view job results and decode summary for read count, total pass/fail, tool time, and quality information.




**NOTE:** The Filmstrip is not available while in Deploy mode.

## Using Undo/Redo

Use Undo or Redo to go back to the previous step in a job deployment or configuration.


Click **Edit** from the top menu and select **Undo** or **Redo** to revert back or forward while building a job.

# Zebra Aurora Focus Software Overview



## Connect

The Connect chevron provides access to Industrial Ethernet, Output Formatting, Script Formatting, GPIO mapping and Interface configuration.



**Table 19** Connect Settings

Setting	Description
Save Image	Enable save settings for Failures or Passes.
Industrial Ethernet	Configure User Control Data and Results data, add tools or jobs for configuration, and review the message sample.
Output Formatting	Enable Output Formatting to customize the formatting for all or specific results, including Serial, TCPIP, and HID, by enabling filters or delimiters.
Script Formatting	Enable Script Formatting to open the JavaScript editor and create scripts for specific use cases.
GPIO Mapping	Configure GPIO Mapping by clicking <b>Edit Device Settings</b> .

**Table 19** Connect Settings (Continued)

Setting	Description
Interfaces	Configure HID or RS-232 interfaces by clicking <b>Edit Device Settings</b> .



**NOTE:** Click  to configure advanced settings.

## Output Formatting

Use Output Formatting to customize data output from identification and Machine Vision Tools. Access Output Formatting using the **Connect** chevron to adjust delimiter settings for each tool or job.

1. Navigate to the **Connect** chevron and click **Output Formatting**.



**NOTE:** Standard identification tools (Read Barcode, Read DPM, Read DPM & Barcode, and Datacode) will have their Decodes.formattedOutputValue output. If there is more than one standard identification tool, the additional tool's Decodes.formattedOutputValue will be appended to the existing result data. The output result will be in the order of the tools on the flowbuilder. For example, barcodeTool1barcodeTool2barcodeTool3



**NOTE:** Machine Vision Tools will add the overall job Success field (Pass/Fail) to the result output. If a standard identification tool is in the job, the job Success field is added to the front of the output result with a comma separator between the job success and barcode data.

For MV tools only: Pass

For MV tools and standard identification tools: Pass,barcodeTool1barcodeTool2barcodeTool3

2. Slide the toggle to the right to enable **Output Formatting** and customize the output result format.
3. Click the specified tool under **Tools** to add a **Results Field** or **Delimiter** to a **Prefix**, **Data**, or **Suffix** category.
4. Click the specified **Job** to add a **Results Field** or **Delimiter** to a **Prefix**, **Data**, or **Suffix** category.
5. Select a **Data Type Delimiter** from the dropdown menu.
6. Click **Copy** to copy the **Message Sample** to clipboard.

## FTP File Saving

1. Download babyftp (free FTP solution): [pablossoftwaresolutions.com/html/baby\\_ftp\\_server.html](http://pablossoftwaresolutions.com/html/baby_ftp_server.html).
2. Navigate to Settings and define the home directory for files to be saved to.



**NOTE:** Babyftp does not have an option for credentialed access (SFTP).

3. Use the following credentials:
  - Username = anonymous
  - Password = <blank>

Determine the IP address of the host computer where the FTP resides.

1. In Aurora Focus, navigate to the **Connect** chevron, then **Save Image**.

2. Select **FTP** under **Save Location**.
3. Click the **Gear** Icon
4. Enter the IP address of the host PC.
5. Use the following credentials:
  - Username = anonymous
  - Password = <blank>
6. To save to a specific subdirectory on the FTP server, enter the following format:

```
/xyz/ (this will write to the folder identified below)
```

```
<FTP home directory>/xyz/
```

```
C:\Users\RMQ783\Desktop\babftp\xyz\
```

Save.



**NOTE:** Include a tilde (~) when providing the file path, for example, ~/myFilePath/

Deploy a job to observe the Pass/Fail images in the expected folder.



**NOTE:** For example, failed images are saved in the following directory after a Failed job run: Desktop\babyftp\VS407a8e\result\asf\fail. Each job run generates a .jpg and a JSON file.

## FTP Naming

The FTP file name is generated from different fields.

For example:

result\_FtpJob\_bank\_0\_2023-06-26T03-04-13.004479+00-00

- Parameter File Name Prefix as configured in the Connect chevron.
- JobName
- bank\_0 that identifies the first image acquired by ImagePerfect+
- The image timestamp with time representation up to microseconds.

It is recommended to align the image name with the setting name in **Acquisition Settings**.

## FTP Folder Structure


The default FTP settings can generate a complex folder structure.

The file path is formed by:

- Host Name (as configured in **Communication > General > Host Name**)
- result
- JobName

## Zebra Aurora Focus Software Overview


- Pass or Fail (based on Good Read and No Read events)




## Applying a Simplified FTP Folder Structure

If the default folder structure is not necessary, disable the default folder structure and apply a simplified structure.


1. Enable **Do not add pathname suffix** in the **Settings** dialog for the FTP connection.



2. To save pass or fail images only and avoid the JSON file, use the **Connect** chevron and deselect the **Enable JSON** checkbox.



The following figure displays the resulting folder content. Use File Name Prefix to separate Good Reads from No Reads without using the folder structure.



## Saving a Series of Images in Burst Mode


Images collected using Series or Burst mode are saved to the FTP server.

SOURCE	JOB MODE
Test Trigger	Series (Burst)

Get the **Burst Count** and disable Stop after successful inspection to retrieve the same number of images each time.

BURST COUNT	<input type="text" value="1"/> <input max="100" min="1" type="range" value="1"/>	<input type="text" value="100"/>
<input type="checkbox"/> Stop after successful inspection		

In the FTP configuration dialog, configure **Burst Mode Settings**.



## Generating a Configuration Barcode


The **Configuration Barcodes** tab generates barcodes using a device configuration snapshot. Use an existing configuration snapshot or select the currently managed device setup to deploy to multiple cameras.



**NOTE:** Configuration barcodes are generated and applied to fixed scanners (FS) only. Vision scanners (VS) cannot generate or apply configuration barcodes.

1. Navigate to the **Configuration Barcodes** tab.

2. Select a **Device Setup** to create a snapshot from the current managed device or load one from the PC.



**NOTE:** If the device is not managed, you cannot select a setup from the device. Status is indicated next to the **Currently Managed Device** option.



**NOTE:** To create a saved configuration snapshot of a connected device, click **Create Configuration Snapshot** in **Devices Details**.

3. Configure the size of the barcode being exported. The options are Small, Medium, or Large. The default size is Medium.
4. Enable **Replace Network Settings** to replace the network settings from the configuration file with the network settings of the new device that the configuration is being deployed onto.
5. Enable **Replace Hostname** to replace the hostname in the configuration file with the hostname of the new device that the configuration is being deployed onto.
6. Click **Generate**.

Print barcodes



## Configuration Snapshot for FS4082b1 (FS40-WA50F4-2C00W)

Date Created: Sep 27, 2023 10:36 PM

File name: zsnapshot\_FS40-WA50F4-2C00W\_2023-09-28T02-36-13Z.zsnapcfg



CANCEL

PRINT

SAVE AS PDF

# Connectivity Gateway Solutions

The Zebra Connectivity Gateway provides asynchronous passthrough and synchronized leader-follower solutions for use cases requiring high-speed scan tunnels, sorting facilities, and multi-point or multi-side barcode scanning for parcels and boxes.

When assembling the Connectivity Gateway with the Gateway License, consider the following device characteristics before determining which devices acts as a leader or follower.

- Fixed Scanning and Gateway devices enable USB HID mode as output. However, GS20 devices do not natively support a USB port.
- Fixed Scanning and Gateway devices support up to 9 total GPIO. GS20 devices have 4 total GPIO.
- It is recommended to implement no more than four followers in a given Connectivity Gateway solution. This implies that the Fixed Scanning and Gateway devices may act as a follower and a leader device simultaneously. If this is implemented in your system, expect a slight degradation in read rate performance in the device acting in both modes.

## Asynchronous Passthrough

In asynchronous leader-follower use cases, multiple devices send result data to a single leader device. The leader passes the data through as a single point of contact to the host.

Examples:

- High-speed scan tunnels.
- Humans present barcodes for scanning in a sorting facility.

Fixed Scanner Input:

- Generic
- TCPIP (Followers)

Fixed Scanner Output to Host:


- TCPIP
- Industrial Communication
- Serial
- USB HID

Functionalities:

- Enable simple passthrough to send result data without changes.

- Enable advanced passthrough to change or add input text before the output.

**Figure 1** Asynchronous Passthrough



## Synchronized Leader Follower

In synchronized leader-follower use cases, the leader receives a trigger, activates the follower devices, receives the data from the followers, and sends the results to the host.

Examples:

- Multi-sided reading of parcels.
- Multi-point reading of barcodes on a tire rim (overhead view only).

Leader Input:

- Generic:
  - GPIO Trigger
- From Follower:
  - Results:

Leader Output:


- To Host:
  - TCPIP
  - Industrial Communication
  - Serial
  - USB HID

- To Follower:
  - Trigger
- To Machine/PLC:
  - Total Result String
  - Total Pass/Fail GPIO

Functionalities:

- Enable synchronous triggers from leader to follower devices.
- Receive results from follower devices and apply pass/fail criteria.
- Send result data to the host, GPIO, or PLC.

**Figure 2** Synchronized Leader-Follower



## Gateway Licensing

Licenses for the Connectivity Gateway solution are available for xS40/70 devices using the Zebra Web HMI.

Click the **Licensing** tab to activate a new license and view active licenses,

The screenshot shows the 'LICENSING' tab selected in the top navigation bar. It includes fields for managing license methods (Online or Offline), a licensing server URL (https://zebra-licensing.flexnetoperations.com), an activation ID (44dd-58ae-11a3-4465-907f-2a64-87f0-1), and a green 'ACTIVATE LICENSE' button. Below this, a table lists active licenses with columns for License Index, License Name, License Version, Expiry Date, License Count, Host ID, and Release.



**NOTE:** GS20 devices include a license by default.

## Compatible PLC Devices

The Connectivity Gateway supports communication to and from the following PLC models.

PLC	Protocols
<b>Siemens</b>	S7 TCP/IP
	Logo!
	S7-200
	S7-300
	S7-400
	S7-1200
	S7-300 (ERPC)
	ET 200 Pro
	S7-1500
	SINUMERIK 840D
<b>Rockwell</b>	PCS 7
	ControlLogix CPU
	CompactLogix CPU
<b>Mitsubishi</b>	Micro800 CPU
	QCPU (Built-in Ethernet)

PLC	Protocols
	LCPU (Built-in Ethernet)
	RCPU (Built-in Ethernet)
	FX3CPU
	FX5CPU
	GOT
	ACPU
<b>Omron</b>	CS1 CPU
	CJ1 CPU
	CV1 CPU
	NJ CPU
	CP1 CPU
	NX CPU
	CJ2 CPU
	NE1S CPU
<b>Modbus</b>	TCP/IP

## Setting Up Follower Devices

Set up follower devices for the Connectivity Gateway using the Web HMI.

1. Navigate to the **Setup** screen using the left menu on the **Home** screen.
  - If you are in triggered mode and intend to update the port that the device is monitoring for an incoming trigger string, enter the desired port into the Trigger Input field (0 to 65535) and click **Update**.
  - To configure the IP and Port address of the host, enter the desired IP address and port into the Output IP and Output Result fields. Click **Update** for the changes to update the field values.
  - To set up the TCP port to act as a Server, select this option from the Mode menu and click the icon above the menu to edit the server settings.
2. Click **Update** to enable the changes and update the field values. Select **Server** to use the TCP port as a server.



**NOTE:** When the Leader to Host port acts as a Server, a timeout occurs after five seconds of inactivity. In some cases, you may need to set up a heartbeat to keep the connection alive by sending a string (for example, HB) from the host machine to the device IP address and the specified server port with a frequency higher than every five seconds.

3. Once the form fields are populated, click **Commit Changes**.
4. Observe the message and wait for at least two minutes before sending the next trigger to the Connectivity Gateway.




**NOTE:** Inactivity Timeout is the time the device waits for the next TCP message before the connection is lost. This setting is only applicable when the leader device operates in Server mode. The default setting of one day is helpful for stable network connections. However, lower

timeout options should be used along with a heartbeat from the host to recognize dropped connections quicker on unstable networks. If your network is unstable, set up a heartbeat to maintain the connection by sending a string (for example, HB) from the host machine to the leader's device IP address and specify the server port with a frequency higher than the inactivity timeout.

## Configuring Follower Devices

Click **Config** on the **Home** screen to configure GPIO, Filtering, Triggering, Timeout, and Run Mode settings.




## GPIO Triggering

Define a pulse width for the signal to trigger a device over the input of your choice.

1. Navigate to the **Configuration** screen using the left menu on the **Home** screen.

2. In the top left GPIO section, select the desired trigger pin (either In 0 or In 1) and click **Update**.



3. Click **Config** to edit the Trigger Pulse and Pass/Fail Pulse fields.

4. Enter the desired values and click **Update**.

- Trigger Pulse: specifies the pulse width for the signal that triggers the follower devices.
- Pass/Fail Pulse: specifies the pulse width for the pass/fail result signal.




**NOTE:** If you configure the same output for GPIO Pass/Fail and as an input for the follower device (for example, trigger input), the trigger input for the follower device takes precedence.

## GPIO Mirroring

Use the HMI to turn GPIO Mirroring on or off and inverse the mirroring to allow Input 0 and Input 1 to mirror to Out1 and Out0.

- Enabled GPIO Mirroring: the output signal goes high whenever the input pin that it is mirroring goes high.
- Disabled GPIO Mirroring: the output signal goes high for its predefined pulse width and then goes low immediately after.

- Enabling Opposite pins: input 0 mirrors Out0, and Input1 is mirrored to Out1 by default. Enabling opposite inverses the mirroring to allow Input0 and Input1 to mirror Out1 and Out0, respectively.
1. Navigate to the **Configuration** screen using the left menu on the **Home** screen.
  2. Locate the **GPIO Mirroring** section and toggle **GPIO Mirroring** to enable.



3. Click **Config** and select an **Input Pin** and an **Output Pin** from drop-down.


4. Click **Update** to apply the changes.

## GPIO Pass/Fail

Use the HMI to configure GPIO Pass/Fail on an output pin of your choice.

1. Determine which output to use for Pass/Fail. The output triggers followers and cannot be used to output scanning results.
2. Navigate to the **Configuration** screen using the left menu on the **Home** screen.

3. Use the top-right **GPIO Pass/Fail** section to select Pass and Fail pins from the drop-down menu.



4. Set the toggle to **Enabled** and click **Update**.

## String Filtering

The device supports string filtering modes such as exclude and include and string filters such as exact match, start with, ends with, contains, and RegEx.

- **Exclude:** the device excludes barcode results that match the specified string filter.
- **Include:** the device only includes barcode results that match the specified string filter.

Supported string filters include:

- **Disabled:** disables string filtering.
- **Exact Match:** filters strings that exactly match the input string.
- **Start With:** filters string matches at the beginning of the string.
- **Ends With:** filters string matches at the end of the string.
- **Contains:** filters string matches anywhere in the string.

- **RegEx:** uses a regular expression to define string filtering.

To set up string filtering:

1. Navigate to the **Configuration** screen using the left menu on the **Home** screen.
2. Use the **String Filtering** section to select the desired **Mode**, **Input**, **String Filter**, and **Filter Type**.

The screenshot shows the 'CONFIGURATION' screen with various settings panels. The 'String Filtering' panel is highlighted with a blue border. It contains fields for 'String Filter' (input field), 'Mode' (dropdown: 'Exclude'), and an 'UPDATE' button. Other panels include 'GPIO In', 'Pulse', 'GPIO Mirroring', 'GPIO Pass/Fail', 'Serial', 'Trigger Strings', 'Failure Timeout', 'Results Delay', 'Leader to Host', and 'Run Mode'. Each panel has a 'CONFIG' button at the bottom right.

3. Click **Update** to apply the changes.

## Serial Triggering

Set up a Serial Trigger from the host to the Connectivity Gateway.



**NOTE:** There is no serial connection between the leader and the follower devices; triggering between the devices occurs over TCP/IP.

1. Navigate to the **Configuration** screen using the left menu on the Home screen.

The screenshot shows the 'CONFIGURATION' screen with the following sections:

- GPIO In:** Trigger Pin N/A, Trigger Pin N/A(), Trigger Type Disabled, Mode Exclude, UPDATE, CONFIG.
- Pulse:** Trigger: 100 ms, Pass/Fail: 100 ms, Rising (1) selected, Falling (0) selected, UPDATE, CONFIG.
- String Filtering:** String Filter, Filter Type Disabled, Mode Exclude, UPDATE, CONFIG.
- GPIO Mirroring:** Enabled (switched off), UPDATE, CONFIG.
- GPIO Pass/Fail:** Pass Pin N/A, Fail Pin N/A, Pass N/A(), Fail N/A(), CONFIG, UPDATE.
- Serial:** Start: TRIGGER, Stop: TRIGGER, CONFIG.
- Trigger Strings:** String NORREAD, Enabled (switched off), CONFIG.
- Failure Timeout:** Timeout 500 ms, Timeout (ms) 500, UPDATE.
- Results Delay:** Absolute selected, Relative selected, Delay 0 ms, Delay (ms) 0, UPDATE.
- Leader to Host:** Terminators CRLF, Output via TCP (switched off), Terminators CRLF, CONFIG, UPDATE.
- Run Mode:** Mode Level, Current Mode Level, CONFIG, UPDATE.

2. Locate the **Serial** section and click **Config** to set the serial settings for the device.

The screenshot shows a configuration interface for serial settings. It includes the following fields:

- State:** Enabled (dropdown: Disabled)
- Baud Rate:** 9600 (dropdown: 9600)
- Data Bits:** 8 (dropdown: 8)
- FC (DTR/RTS):** Disabled (dropdown: Disabled)
- Output via Serial:** A toggle switch that is turned on (green).
- Parity:** None (dropdown: None)
- Stop Bits:** 1 (dropdown: 1)

At the bottom are two large buttons: **APPLY** on the left and **CANCEL** on the right.

3. Configure the form fields and click **Confirm** to enable the settings on the device.

## TCP/IP Triggering

Before setting up TCP/IP triggering on the device, configure the Host to Leader port and follower devices.

1. Navigate to the **Configuration** screen using the left menu on the **Home** screen.

2. Locate the **Trigger Strings** section and click **Config**.

The screenshot shows the 'CONFIGURATION' screen of the Connectivity Gateway Solutions software. The 'Trigger Strings' section is highlighted with a blue border. The 'Trigger Strings' section contains the following configuration:

- Start: TRIGGER
- Stop: TRIGGER


Below the 'Trigger Strings' section is a 'CONFIG' button.

The other sections visible include:

- GPIO In**: Trigger Pin N/A, Trigger Type Rising (1) selected.
- Pulse**: Trigger: 100 ms, Pass/Fail: 100 ms.
- GPIO Mirroring**: Enabled (switch is off).
- GPIO Pass/Fail**: Pass Pin N/A, Fail Pin N/A.
- String Filtering**: String Filter, Filter Type Disabled, Mode Exclude.
- Serial**: No configuration shown.
- No Read String**: String NORREAD, Enabled (switch is off).
- Failure Timeout**: Timeout 500 ms.
- Results Delay**: Absolute selected, Delay 0 ms.
- Leader to Host**: Terminators CRLF, Output via TCP (switch is off).
- Run Mode**: Mode Level, Current Mode Level.

Each section has a 'CONFIG' button and an 'UPDATE' button at the bottom.

3. Select the terminator for each trigger from the drop-down menu and click **Update** to apply the changes.



**NOTE:** Serial Interface does not support a null terminator.

## Failure Timeout

Set a failure timeout to account for trigger input delays.

1. Navigate to the **Configuration** screen using the left menu on the **Home** screen.

2. Use the bottom left **Failure Timeout** section to specify a timeout.

The screenshot shows the Configuration screen of the Connectivity Gateway. It includes sections for GPIO In, Pulse, String Filtering, Serial, Trigger Strings, Failure Timeout, Results Delay, Leader to Host, and Run Mode. The Failure Timeout section is highlighted with a blue border. The Failure Timeout value is set to 500 ms. Other sections include Pulse (Trigger: 100 ms, Pass/Fail: 100 ms), String Filtering (String Filter, Filter Type: Disabled, Mode: Exclude), Serial (Start: TRIGGER, Stop: TRIGGER), Trigger Strings (No Read String, String: NORREAD, Enabled: Off), Results Delay (Absolute, Delay: 0 ms), Leader to Host (Terminators: CRLF, Output via TCP: On), and Run Mode (Mode: Level, Current Mode: Level).

3. Click **Update** for the changes to take effect.



**NOTE:** Ensure your failure timeout accounts for any trigger input delays specified on the follower side.

## Run Mode

The Connectivity Gateway operates in Single Shot, Continuous, or Level mode.

1. Ensure that you set up continuous mode between leader and followers before selecting an operating mode.
2. Navigate to the **Configuration** screen from the **Home** screen using the left navigation menu.

3. Use the bottom right **Run Mode** section on the **Configuration** screen to change between **Single Shot**, **Continuous** and **Level** modes.


The screenshot shows the 'CONFIGURATION' screen of the Connectivity Gateway Solutions software. It consists of several cards arranged in a grid:

- GPIO In:** Trigger Pin N/A, Trigger Pin dropdown (N/A()), Update button.
- Pulse:** Rising (1) selected, Trigger: 100 ms, Pass/Fail: 100 ms, CONFIG button.
- CONFIGURATION:** A central card containing:
  - GPIO Mirroring:** Enabled toggle switch, CONFIG button.
- GPIO Pass/Fail:** Pass Pin N/A, Fail Pin N/A, Pass dropdown (N/A()), Fail dropdown (N/A()), CONFIG button, UPDATE button.
- String Filtering:** String Filter dropdown (String Filter), Filter Type dropdown (Disabled), Mode dropdown (Exclude), Update button, CONFIG button.
- Serial:** Start: TRIGGER, Stop: TRIGGER, CONFIG button.
- Trigger Strings:** CONFIG button.
- No Read String:** String NOREAD, Enabled toggle switch, No Read St... dropdown, UPDATE button.
- Failure Timeout:** Timeout 500 ms, Timeout (ms) input field (500), Update button.
- Results Delay:** Absolute selected, Relative radio button, Delay 0 ms, Delay (ms) input field (0), Update button.
- Leader to Host:** Terminators CRLF, Terminators dropdown (CRLF), Output via TCP toggle switch, Update button.
- Run Mode:** Mode Level selected, Current Mode Level, CONFIG button, UPDATE button.

4. Click **Config** to edit **Run Mode** settings.

**5.** Configure the required trigger settings:

- Level Mode - determines how a level starts and stops.
- Grace Period - the amount of time to wait after a level stop signal is received to accept incoming barcodes before rejecting them.
- Output Mode - determines how barcodes are output over all configurable host interfaces while running in level mode.
- Output Delimiter - determine the delimiting characters separating the barcode output after a level session when running in **Level End** output mode.



**6.** Click **Update** for the changes to take effect.

**7.** Observe the warning screen indicating that scan data is erased after the changes are implemented. Acknowledge the warning to proceed with your changes.

## Administrator Settings

Accessible administrator settings include network, GPIO, PLC, ZETI, database, and alerts.

### Setting Up a Network

Configure network settings, including the hostname, IP address, subnet, gateway, and DNS server.

Access **Network Config** from the **Admin Settings** menu to edit the hostname and server settings and click **Update** to save each setting.

◀ RETURN HOME

**HOSTNAME**  
**FS4082b1**

Hostname

UPDATE

**GATEWAY**

Gateway

UPDATE

**NTP SERVER 1**  
**0.pool.ntp.org**

NTP Server

UPDATE

**IP**

IP

UPDATE

**DNS SERVER**

DNS Server

UPDATE

**SUBNET**

Subnet

UPDATE

**DHCP**  
**true**

Status  
DISABLED

UPDATE

**NTP SERVER 2**  
**1.pool.ntp.org**


NTP Server

UPDATE


## Configuring GPIO

Configure GPIO settings such as Mode, Edge Sense, and Debounce.

1. Access **GPIO Config** from the **Admin Settings** menu.



2. Select the GPIO pin from dropdown and configure the **Mode**, **Edge Sense**, and **Debounce** settings.




3. Click **Confirm** to apply the changes.


## Attributes

Provide the Attribute ID or value to set or retrieve the response.

1. Access **Attributes** from the **Admin Settings** screen.




2. Enter the **Attribute ID** and **Attribute Value** and click **Get** or **Set** to retrieve the response.



## Configuring the Database

Configure the database to set a data capacity or clear interval.

1. Click **Database Config** on the **Admin Settings** menu.
2. Enable a **Database Cap** by sliding the toggle to the right and selecting an entry capacity from the drop-down menu.
3. Enter a **Clear Interval** in ms.




4. Click **Update** to apply the changes.


## Enabling Alerts

Enable alerts to understand the timeout intervals of the follower and leader devices or if the read rate drops.

1. Click **Alert Config** on the **Admin Settings** menu to enable alerts.



2. Enable an alarm for **Follower Heartbeat**, **Host Heartbeat**, **Read Rate**, or **Trigger Overrun** by sliding the corresponding toggle to the right.




- Follower Heartbeat: enables a heartbeat (timeout interval) for follower devices.
- Host Heartbeat: enables a heartbeat (timeout interval) for the host device.
- Read Rate: enables a notification on the Home screen if the read rate drops below 95% over 1000 scans.
- Trigger Overrun: enables a notification on the Home screen when triggering occurs faster than the result is received from the follower or when a failure timeout occurs.


## Using ZETI with Follower Devices

Use Zebra Easy Text Interface (ZETI) to execute specific commands and retrieve a response.

1. Access **ZETI** from the **Admin Settings** menu.



2. Select a follower from the drop-down menu and enter a command.
3. Click **Exec** to execute the command and observe the **Status** and **Response**.



## Split Codes


Configure follower devices for Split Code functionality using Zebra Aurora Focus.

1. Create a new job for the follower device and navigate to the Build tab in Zebra Aurora.
2. Navigate to the **Symbologies** section. Ensure that only the symbologies necessary for the application are enabled.
3. Navigate to the **ManyCode** tab. Configure the total number of Barcodes to Decode (3 max). Sort by symbology and enable partial results.
4. Navigate to the **Data Formatting** tab and select **Advanced Formatting**.
5. Select **ManyCode** and input the following:
  - Prefix: None
  - Data
    - Many Code String
    - Custom String "~~\$~"
  - Suffix: None
  - Delimiter
    - Data Type: None
    - End: None
    - ManyCode String: None
6. Select All Symbologies
  - Prefix: None
  - Data
    - Symbology
    - Custom String ","
    - Full String: Base 64
    - Custom String: "~~#~"
  - Suffix: None
  - Delimiter
    - Data Type: None
    - End: None


## PLC Configuration

Create a PLC device to connect to the Connectivity Gateway.


1. Select **PLC Config** from the **Admin Settings** menu.



2. Select **Create PLC** from the **PLC Configuration** menu.



3. On the Create PLC screen, select the **Manufacturer** and **Model** of the PLC, specify a **Friendly Name** for the PLC, and enter the **IP Address**.




4. Click **Confirm** and observe the confirmation message.

### Sending Results to a PLC Device


Use the Connectivity Gateway to send results to the connected PLC device.

1. Navigate to the **Admin Settings** screen from the left menu on the **Home** screen and click **PLC Config**.


2. Click **Results Tag** on the **PLC Configuration** screen.



3. Select the PLC device from the menu and enter a value for the trigger.



4. On the **PLC Configuration** screen, toggle **Output via PLC** to **On** (green).




**NOTE:** The results tag supports a string of up to 4096 characters, including the CR+LF terminator.

5. After the configuration is complete, navigate to the **Control PLC** screen, select the PLC device from the menu, and click **Start** to begin sending results.

## Modbus Configuration


Configure a Modbus device and define a specific coil to monitor.

1. Navigate to the **Admin Settings** menu from the **Home** screen and click **Modbus Config**.




2. Slide the toggle to the right to enable **Modbus Triggering** or **Output to Modbus**.
3. Click **Control Device** to access controls to the Modbus device.


4. Select the Modbus device from the menu and click **Start** to begin controlling the device. Click **Stop** to end the session or **Delete** to remove the device. When you are finished controlling the device, click **Back** to return to the **Admin Settings** menu.



5. Click **Results** to access Modbus results and configure where results are sent to.



- Select the Modbus device from the menu and define a **Holding Register**.




- Click **Confirm** to save changes and return to the **Admin Settings** menu.
- Click **Create Device** to configure the device information.
- Provide the required device information and click **Create** to return to the **Admin Settings** menu.

Name	IP	Port	
Device Name	IP Address	Port 502	
Coils	Discrete Inputs	Input Registers	Holding Registers
1	0	0	Holding Registers 4096

**CREATE** **CANCEL**

- Click **Monitoring** to monitor a specific coil on the Modbus device

11. Select a Modbus device from the menu and determine a coil number to monitor.



# Accessing the Web HMI

Access the Web HMI by entering the device IP address into a web browser. To obtain the device IP address, select **View Devices** from the menu on the left of the Zebra Aurora Focus application.

When logged in to the Zebra Web HMI, the application presents a dashboard with key hardware metrics such as average inspection per minute, total uptime, temperature, CPU load, communication status, average pass/fail, and resource utilization.



**NOTE:** Use Google Chrome for optimal performance while using the Web HMI.

## Web HMI Top Menu


The Web HMI provides access to the following options using the menu in the top right of the application:



- Device Status Icon - describes the state of the device:
  - Blue - indicates the device is managed and available in Zebra Aurora Focus.
  - Red - indicates a job is actively being edited or deployed in Zebra Aurora Focus.
  - Green - indicates the device is online and running.
- Hostname (FS4072E7) – displays the hostname of the camera.
- Timestamp - displays the current date and time.
- Profile Icon (Operator) - displays the current user role. Click the icon and provide the appropriate credentials to access other roles, such as Administrator.
- Gear Icon (Settings Menu) – provides access to updating the device firmware, selecting a language, restoring factory defaults, setting date and time settings, and backing up the device.
- Notification Icon - displays the current number of unread notifications.
- Localization - displays the current language of the UI.

## Web HMI Dashboard




The Web HMI dashboard provides insight into the device's details, such as resource utilization, uptime, temperature, and GPIO communication. Scanning metrics such as total pass/fail count and average inspection per minute are available on the dashboard.



**Table 20** Web HMI Dashboard Overview

Section	Description
Average Inspection Per Minute	Displays the number of scans per minute.
Up Time	Displays the total time the device has been running in a given session.
Temperature	Displays the operating temperature of the device.
CPU Load	Displays the current number of processes executed by the CPU.
Communication	Displays the pinout configuration of the GPIO.
Total Pass/Fail	Displays the total number of successful and unsuccessful reads.

**Table 20** Web HMI Dashboard Overview (Continued)

Section	Description
Result Overflow	Provides insight into the performance of the setup by displaying the number of results that were not sent out. This could be due to the amount of results data (size/frequency of data) greater than the output interface's throughput. If the system setup is correct, the graph shows 0. If the graph shows an interface greater than 0, an adjustment must be made to preserve the result data. For example, utilize an interface with greater throughput, decrease the amount of output data, or decrease inspection frequency).
Resource Utilization	Provides resource utilization by memory and disk.
Device Information	Provides device information such as Host Name, Part Number, Version, Ethernet IP, and Build number.
Indicators	Power, PoE Network, Device Status, Focus, Warning, Auto Flash, and Firmware Update.
Status	 Ready - the camera is waiting for a trigger, or there are no active jobs.  Busy - the camera is processing one or more triggers.  Editing - Zebra Aurora Focus is editing a job.

## Live Monitoring with the Web HMI

The Live Monitoring feature allows users to view decode results as they occur in real time by clicking the Live Monitoring tab at the bottom of the interface.

The Web HMI also provides the capability to update the device firmware by selecting the settings icon in the top right corner of the application.

**Table 21** Live Monitoring with the Web HMI

Section	Description
Live Monitoring View	Provides real-time monitoring of the camera's view while processing jobs.
Recent Inspections	Lists all recent jobs and their status, the toolset used for the job, and total job time.

## Viewing Result History

The Results History tab provides job result information, such as status, execution time, and date. Trigger information, including total triggers, total pass/fail, and missed triggers, are available on the Job panel on the right.

## Accessing the Web HMI

The screenshot shows the Zebra Web HMI interface. At the top, it displays the Zebra logo, session information (FS4072E7, 02/17/2023 21:58), operator status, and language settings (English). Below this is a table titled "Result History" with columns for ID, Inspection, Result, Execution Time, Date, and Job. The table contains 10 rows, all of which show a "Pass" result for the "BARCODE\_SCANNING\_TOOL". To the right of the table is a "Job" statistics panel. This panel includes a dropdown menu set to "Serial Number" and a large green button labeled "VIEW RESULT DETAILS". Below these are four summary statistics: Total Triggers (2252), Total Pass (2248), Total Fail (4), and Missed Triggers (0). At the bottom of the page, there are navigation links for DASHBOARD, LIVE MONITORING, RESULTS HISTORY (which is currently selected), JOB LIST, and ACTIVITY LOG. A footer note indicates "1 row selected".

ID	Inspection	Result	Execution Time	Date	Job
1	BARCODE_SCANNING_TOOL	Pass	197	2023-02-17T21:50:36.28957...	
2	BARCODE_SCANNING_TOOL	Pass	37	2023-02-17T21:50:36.52826...	
3	BARCODE_SCANNING_TOOL	Pass	34	2023-02-17T21:50:36.76341...	
4	BARCODE_SCANNING_TOOL	Pass	33	2023-02-17T21:50:36.99819...	
5	BARCODE_SCANNING_TOOL	Pass	33	2023-02-17T21:50:37.23347...	
6	BARCODE_SCANNING_TOOL	Pass	33	2023-02-17T21:50:37.46884...	
7	BARCODE_SCANNING_TOOL	Pass	33	2023-02-17T21:50:37.70341...	
8	BARCODE_SCANNING_TOOL	Pass	33	2023-02-17T21:50:37.93842...	
9	BARCODE_SCANNING_TOOL	Pass	33	2023-02-17T21:50:38.17330...	
10	BARCODE_SCANNING_TOOL	Pass	33	2023-02-17T21:50:38.40839...	

1 row selected

Rows per page: 10 ▾ 1-10 of 500 < >

Total Triggers 2252  
Total Pass 2248  
Total Fail 4  
Missed Triggers 0

**VIEW RESULT DETAILS**

DASHBOARD LIVE MONITORING RESULTS HISTORY JOB LIST ACTIVITY LOG

**Table 22** Viewing Result History

Section	Description
Result History Table	Displays decode result information such as ID, status, execution time, and date.
Job Statistics	Select a job from the menu to view total triggers, pass/fail, and missed trigger details.

## Viewing the Job List

The job list provides information on the currently active jobs that can be run on the device. Additional details on the right of the list include filtering by active and inactive jobs, the trigger mode of the specified job, its slot number, and its description.

Name	Type	Size	Slot	Status	Uptime
Default Barcode Job	-	-	1	-	-
Box Reader	-	-	2	-	-
Serial Number	-	-	3	Active	-

**JOB**  
 Serial Number  
  
ACTIVE INACTIVE

**Trigger Mode**  
 PERIODIC\_SINGLE\_SHOT  
  
**Slot No.**  
 3

**DESCRIPTION**

Rows per page: 10 ▾ 1-3 of 3 < >

[DASHBOARD](#)
[LIVE MONITORING](#)
[RESULTS HISTORY](#)
JOB LIST
[ACTIVITY LOG](#)

**Table 23** Job List

Section	Description
Job List	Displays each job's statistics, such as type, size, slot status, and uptime.
Current Job	Provides additional details on a specific job, including its Trigger Mode and description.

## Viewing the Activity Log

The Activity Log provides information on specific actions taken by the device, a live view of the device state, and a list of all currently active jobs and jobs deployed upon startup.

The screenshot shows the Zebra Web HMI interface. At the top, there's a header with the Zebra logo, device ID (FS4072E7), date and time (02/17/2023 22:00), user (Operator), settings, notifications, and language (English). Below the header, the main content area is divided into several sections:

- DEVICE:** FS4072E7. This section shows a thumbnail image of a Zebra label with barcode and text.
- JOB LIST:** A table showing the status of various jobs. It includes columns for Job Name, Status, and Action (e.g., Startup, Active).
- RESULTS HISTORY:** A green button labeled "SHARE" with a share icon.
- NAVIGATION:** Buttons for DASHBOARD, LIVE MONITORING, RESULTS HISTORY, JOB LIST, and ACTIVITY LOG.

The left side of the interface lists a long series of "Result" entries, each with a timestamp and duration (Time: 30 or 31 seconds). These represent the device's recent activities.

**Table 24** Viewing the Activity Log

Setting	Description
Activity Log	Lists all of the device's recent activities.
Live View	Real-time view from the camera of the device.
Job List	Displays all jobs sorted by jobs deployed upon startup and currently active jobs.

## Updating Device Firmware

The device must be connected to a PC using a USB or Ethernet cable or from Ethernet to a router (common network with a host PC) to update the firmware. The USB connection provides power and communications to the device.



**NOTE:** Conduct a Factory Reset after applying a firmware update to a Connectivity Gateway license-enabled device.

For additional details on setting up the device, refer to the FS/VS Smart Camera Product Reference Guide.

Requirements:

- Web browser (Google Chrome, Mozilla Firefox, or equivalent)
- Firmware file on the local PC

## USB-A to USB-C Hardware Setup

Required hardware:

- Windows 10 or higher PC with USB-A or USB-C port
- USB-A to USB-C cable, Zebra P/N: CBL-USB0200-USA00 or
- USB-C to USB-C cable, Zebra P/N: CBL-USB0200-USC00


## Firmware Update

This section outlines performing a Firmware Update on the device.

1. Open **File Explorer** on your host Windows desktop PC.
2. On the left window pane, scroll down and select **Network** to view devices on your network and identify a device.

## Accessing the Web HMI

3. Right-click on the device and select **Properties** to obtain the device's IP address information.



4. Enter the IP address (or hostname) into your browser.




**NOTE:** This example refers to the hostname as localhost in the top left corner of the Properties window.



- View the Zebra Web HMI and observe the build number RELEASE-xx (where xx is the build number) in the **Device Information** section of the dashboard.

Device Information	
Host Name	FS4082B1
Part Number	FS40-WA50F4-2C00W
Version	CAAESS00-003-R14
ETH0 IP	169.254.130.177
USB IP	172.16.107.22
Build	RELEASE-433

- Click **Operator** to launch the login window.




- Enter the following login credentials:
  - User ID: admin
  - Password: admin
- Click **Login**.
- Observe that **Operator** now displays as **Admin**.




- Click the gear icon.
- Click the **Firmware Update** tab.


12. Click **Choose File**, navigate to the location of the file stored on the Local PC, and select the latest firmware file.



13. Click **Open**.



14. Select either **Forced Update** or **Dual Update**.



**NOTE:** Forced Update loads the device in cases where it is identical to the current firmware on the device. Dual Update loads the device firmware and updates the backup partition. This option typically takes longer (twice as long) than a forced update.

15. Click **Update**.

The device LED blinks red and the upload progress displays on the screen. The device reboots after the upload is complete.

16. Refresh the browser window and view the build number in the device information field to confirm that it has been updated from the previous version.

## Performing a Factory Reset

A factory reset deletes all created jobs on the camera.



**NOTE:** A factory reset deletes all created jobs on the camera. It is critical to save all jobs and user-specific information before performing the factory reset.

1. Click **Operator** to launch the login window.




2. Enter the following credentials:

- a) User ID: admin
- b) Password: admin

3. Click **Login**.

4. Click

5. On the **General** tab, click **Reset All** in the **Factory Reset** field, and wait for the device to reboot (approximately 45-60 seconds).



# Using Fixed Industrial Scanning Tools

Use Fixed Industrial Scanning symbologies and tools and set image banks and format data.

## Editing and Deploying FS Jobs

To set up a Fixed Scanning (FS) job, set decoder parameters, symbologies, OCR settings, code quality metrics, and data formatting rules.

Begin by configuring the decode parameters and selecting the appropriate set of symbologies. A symbology is chosen by clicking Symbologies Tab. Next, select specific symbologies to be deployed by clicking the corresponding checkboxes.

Once the job is in progress, monitor the **Image Viewer** and the **Filmstrip** controls to view job progress. The **Image Viewer** contains a status bar that displays the result and runtime. In the FS editor, the status bar displays the decode time, decoded value, PPM, and the type of symbology decoded.

**View Results** provides additional data on the decode and displays the results for each job instance.

## Using the Job Toolstrip


The Jobs Toolstrip provides access to available devices or emulators to apply the job to, the barcode type, and the detected power source. Save the configuration by clicking the disk icon.

**Table 25** Jobs Toolstrip

Setting	Description
Device/Emulator Selector	Select the device or emulator for the job to be deployed to.
Barcode Type	Select the applicable barcode type for the job.
Power Source	Displays the power source type that the device is connected to.
Save Options	Saves the job configuration.

## Fixed Industrial Scanner Settings

Configure Fixed Industrial Scanning settings such as timeout, adaptive ROI search, barcode string match, or a no-read string, depending on your use case.



**Table 26** Fixed Industrial Scanning Tool Settings

Setting	Description
Timeout	<p>The amount of time (ms) the tool should stop its process of searching for barcodes.</p> <p> <b>NOTE:</b> For high-speed barcode-reading applications (for example, a fast conveyor belt or high-speed turntable), set this value as low as possible, just above the average time to read a barcode. Deploy the application and obtain real-world data on the decode speed in your specific use case (for example, a range of 5-15ms). Set this to a value just above that speed (for example, 20ms). This allows the application to capture frames from high-speed subject images, increasing the odds of a good read.</p>
Inverse 1D	<ul style="list-style-type: none"> <li>Regular - reads dark foreground/light background barcodes.</li> <li>Inverse Only - reads light foreground/dark background codes only.</li> <li>Inverse Autodetect - reads both barcode types defined above.</li> </ul>

**Table 26** Fixed Industrial Scanning Tool Settings (Continued)

Setting	Description
Minimum Percentage Barcode/ROI Overlap	Define the minimum percentage a barcode needs to be contained within the ROI to be read. <ul style="list-style-type: none"> <li>For 1D barcodes, this applies only to the horizontal (X) dimension.</li> <li>For 2D barcodes, this applies to horizontal and vertical (X &amp; Y) dimensions.</li> </ul>
No Read String	Define the data that should be output if no barcode is read (in place of barcode data in a successful read, as opposed to no output at all).
Enable Adaptive ROI Search	Enabling this parameter allows the underlying barcode scanning algorithm to alter (shrink and reposition) the area of the ROI for subsequent reads based on the presence of past-read barcodes. This provides quicker and better-performing barcode reads. The small/medium/large drop-down settings alter how the adapted ROI component is generated.
Barcode String Match	Enable this setting to define the pass/fail criteria based on the contents of the decoded barcode. If the Match String matches and the substring within the barcode is, the barcode tool passes.
Minimum BQM Grade	Defines a minimum BQM threshold (produces a barcode-based pass/fail if it does not meet this minimum BQM score).
Send Decode on Failure	If a barcode is read but does not meet the <b>String Match</b> criteria, enabling this setting allows the barcode data to be output while the tool fails.

## Using BQM for Fixed Scanning Jobs

Barcode Quality Metrics are enabled on the Settings tab for FIS jobs.

## Using Fixed Industrial Scanning Tools

The screenshot shows the F540 Device Settings software interface. The main window title is "BOM\_Job (F5) - Build". The left sidebar has tabs for "Setup Device", "F540 - Device Settings", "Power Source: PoE+", and "Image Viewer". The "Image Viewer" tab is active, displaying a barcode image with a green ROI (Read Barcode) box around it. The ROI box contains the barcode data: (01) 00850007728243, (40) RD3MP225501054ZP, 01008500077282431800TN25501054ZP, 17.0 PPM, BOM Grade: 3 (B), and (17) 24-1203. The "Code Quality" section on the right shows an overall grade of 3 and a minimum BQM Grade of 4.0 (A). The "View Results" section lists various metrics: Overall Grade (3), Decode (4), Modulation (4%), Symbol Contrast (64%), Axial Nonuniformity (1%), Fixed Pattern Damage (4), and Color Nonuniformity (3%).

After the **Minimum BQM Grade** is set, observe the additional metrics displayed on the **Code Quality** tab in the **Results** section.

## Advanced

The Advanced tab provides access to additional Fixed Industrial Scanning tool settings



**NOTE:** All Advanced detection methods apply to both 1D and 2D barcodes.

**Table 27** Advanced Fixed Industrial Scanning Tool Settings

Setting	Description
Decode Strategy	<p>Changes the variables to alter the balance of speed and performance.</p> <ul style="list-style-type: none"> <li>Fast – This strategy is designed to be fast but may not find a barcode if it is hard to find.</li> <li>Moderate - This strategy is helpful for most use cases with a moderate increase in analysis times.</li> <li>Exhaustive – This strategy does an exhaustive search to find hard to find barcodes. This method can sometimes lengthen analysis time significantly.</li> </ul>

**Table 27** Advanced Fixed Industrial Scanning Tool Settings (Continued)

Setting	Description
Detection Method	<p>Determine the preferred method for detecting the data:</p> <ul style="list-style-type: none"> <li>Uniform - uses a splatter pattern to uniformly analyze the whole image. This is helpful for 1D and 2D barcodes that have a lot of noise. If you are looking for a random pattern, slightly favor the center of the image.</li> <li>Quiet Zone - specialized to find 2D barcodes fast and helpful when over 8 pixels of buffer zone around the barcode is expected. This setting may not be helpful for use cases when the buffer area is less than 4 pixels or 1D barcodes.</li> <li>Finder Pattern - uses a contrast map that finds patterns with little or no noise. This method is applicable to 1D and 2D barcodes.</li> </ul>
Allow Rectangular Codes	Allows the reading of 2D rectangular barcodes in addition to square 2D barcodes.
Expected Module Size (Pixels)	<p>Define the range (pixels) you expect a module to be in given barcodes to help increase read performance.</p> <p>A module is the smallest divisible unit of a barcode; for 1D, typically the width of a single thin line; for 2D, the pixel size. This setting serves as a general guidance to increase performance, but is not a strict threshold.</p>

## Image Banks

All available Image banks display on the left side of the table. The right side of the table provides a top-down sequence of image capture acquisition banks that are used for an **ImagePerfect** job.



**NOTE:** Image banks are taken in sequential order, starting from the top. After a barcode is successfully decoded, the sequence stops. For example, if there are four banks and the first two decode attempts fail, but the third one decodes successfully, the fourth acquisition attempt does not occur.

ImagePerfect provides multiple banks for a single job run and is commonly used for applications that require different focus levels in the same Field of Vision (FoV).

For example, two barcodes in the same FoV, one 12" away from the camera and the other 36" away from the camera. These barcodes require two different focus levels to be clear enough to read. ImagePerfect multiple-acquisition-bank functionality makes this possible.

The screenshot shows a software interface with a top navigation bar containing tabs: Settings, Advanced, Image Banks, Symbologies, Data Formatting, and ManyCode. The 'Image Banks' tab is currently selected, indicated by a dark grey background and bold text. Below the tabs, there is a message: "All image setups have been added to the tool's configuration." To the right, a large rectangular area displays a list titled "Default Setup (Bank 0)" with a delete icon (X) and a camera icon. A warning message below states: "Note that the order of the banks is important, images will be captured in succession and terminate once the tool passes." This message includes a yellow exclamation mark icon.


All image setups have been added to the tool's configuration.

Default Setup (Bank 0)

Note that the order of the banks is important, images will be captured in succession and terminate once the tool passes.

## Symbologies

Configure the settings of each symbology based on your use case.



**Table 28** Symbologies

Setting	Description
Code 39	<p>Configurable settings include:</p> <ul style="list-style-type: none"> <li>Enable Trioptic</li> <li>Enable Full ASCII Conversion</li> <li>Select Code 39 Length</li> <li>Enable Check Digit Verification</li> <li>Enable Convert to Code 32</li> </ul>

**Table 28** Symbologies (Continued)

Setting	Description
Code 128	Configurable settings include: <ul style="list-style-type: none"> <li>• Enable GS1 128</li> <li>• Enable ISBT 128</li> <li>• Select Code 128 Length</li> <li>• ISBT Concatenation Redundancy</li> <li>• Emulate UCC128</li> <li>• Select ISBT Concatenation</li> <li>• Enable Ignore Code128 FNC4</li> </ul>
Interleaved 2 of 5	Configurable settings include: <ul style="list-style-type: none"> <li>• Select Interleaved 2 of 5 Length</li> <li>• Select Check Digit Verification</li> <li>• Transmit Check Digit</li> <li>• Enable Convert Interleaved 2 of 5 Length to EAN13</li> <li>• Enable Fabraban (Interleaved 2 of 5 Length)</li> </ul>
Data Matrix	Configurable settings include: <ul style="list-style-type: none"> <li>• Decode Data Matrix Mirror Images</li> <li>• Select Inverse Data Matrix</li> <li>• Enable GS1 Datamatrix</li> </ul>
PDF417	Configurable settings include: <ul style="list-style-type: none"> <li>• Enable MicroPDF</li> </ul>
QR Code	Configurable settings include: <ul style="list-style-type: none"> <li>• MicroQR Enable (Enabled by Default)</li> <li>• Enable GS1 QR</li> <li>• Select Linked QR Mode</li> </ul>

**Table 28** Symbologies (Continued)


Setting	Description
UPC/EAN	<p>Configurable UPC-A settings include:</p> <ul style="list-style-type: none"> <li>• Select Interleaved 2 of 5 Length</li> <li>• Select Check Digit Verification</li> <li>• Transmit Check Digit</li> </ul> <p>Configurable UPC-E settings include:</p> <ul style="list-style-type: none"> <li>• Enable UPC-E</li> <li>• Select UPC-E Preamble</li> <li>• Transmit UPC-E Check Digit</li> <li>• Convert UPC-E to UPC-A</li> </ul> <p>Configurable UPC-E1 settings include:</p> <ul style="list-style-type: none"> <li>• Enable UPC-E1</li> <li>• Select UPC-E1 Preamble</li> <li>• Transmit UPC-E1 Check Digit</li> <li>• Convert UPC-E1 Check Digit to UPC-A</li> </ul> <p>Configurable EAN-13/JAN-13 settings include:</p> <ul style="list-style-type: none"> <li>• Enable EAN-13/JAN13</li> </ul> <p>Configurable EAN-8/JAN8 settings include:</p> <ul style="list-style-type: none"> <li>• Enable EAN-8/JAN8</li> <li>• Enable EAN-8/JAN8 Extend</li> </ul>
Code 93	<p>Configurable settings include:</p> <ul style="list-style-type: none"> <li>• Select Code 93 Length</li> </ul>
DotCode	<p>Configurable settings include:</p> <ul style="list-style-type: none"> <li>• Select DotCode Inverse</li> <li>• Select DotCode Mirror</li> <li>• Determine DotCode ECC Erasure</li> </ul>
MaxiCode	There are no configurable settings for Maxicode.
Aztec	<p>Configurable settings include:</p> <ul style="list-style-type: none"> <li>• Select Inverse Aztec</li> </ul>

**Table 28** Symbologies (Continued)

Setting	Description
MSI	Configurable settings include: <ul style="list-style-type: none"> <li>Select MSI Length</li> <li>Select MSI Check Digits</li> <li>Enable Transmit Check Digit</li> <li>Select MSI Check Algorithm</li> <li>Enable MSI Reduced Quiet Zone</li> </ul>
CODABAR	Configurable settings include: <ul style="list-style-type: none"> <li>Select Codabar Length</li> <li>Enable CLSI Editing</li> <li>Enable NOTIS Editing</li> <li>Select Upper or Lower Case Start/Stop Characters</li> <li>Select Security Level</li> <li>Enable Mod 16 Check Digit Verification</li> <li>Enable Transmit Codabar Check Digit</li> </ul>

## ManyCode

Use ManyCode to decode multiple barcodes simultaneously and determine their sorting arrangement.



**Table 29** ManyCode Tools

Setting	Description
ManyCode (Disable/Enable)	Enabling this setting allows the barcode to read multiple barcodes in a single iteration.
Total Number of Barcodes to Decode	Limits the number of barcodes to attempt during a single ManyCode scan iteration. For example, if you have eight barcodes in your field of view but set this to five, only the first five barcodes read are decoded, and the scan iteration ends.
Decode All	Explicitly defines no limit for the number of barcodes to attempt to read in a single scan iteration.
Sorting Type	Define how barcode results are sorted: <ul style="list-style-type: none"> <li>• Alphabetical</li> <li>• First Decoded</li> <li>• Top to Bottom</li> <li>• Left to Right</li> </ul>
Expand String Match to Entire Payload	The tool searches for a string match in the entire payload when enabled.
Enable Partial Results	If the number of decodes is less than the <b>Total Number of Barcodes to Decode</b> setting, enabling this setting still outputs these barcodes.
Enable Decode of Identical Symbols	By default, identical (duplicate) barcodes are only read once. When enabled, all duplicate barcodes are read.
Exhaustive Search Attempt	Sets the underlying ManyCode barcode algorithm to prioritize read performance over speed.
Apply Across Level Selection	This option is only active in Level Continuous mode while Read Multiple Barcodes is enabled.

# Using Machine Vision Tools

## Deploying VS Jobs

To build and deploy a VS Job, start by selecting a machine vision tool and dragging it onto the FlowBuilder. Using Flowbuilder, stack additional tools onto the workflow or configure the intended results to deploy the Job. To streamline the creation of a specific toolset, use the QuickDraw tool.

## Common Machine Vision Tool Settings

Some Machine Vision tools share common settings, refer to the table below to understand how to configure them based on your use case.

**Table 30** Common Machine Vision Tool Settings


Setting	Description
ROI Type	Select a rectangular or circular Region of Interest (ROI).
Histogram	Displays the number of pixels between two values in a user-defined value range.
Timeout	Set a time limit to stop the execution of the inspection tool ending, producing a failed result.
Inverse Pass/Fail	Inverts the output result when enabled.

## Using Image Types

When using the **Image Type** drop-down menu to use a filter or tool output as the source image, the ROI of the tool must be fully contained within the ROI of the source images. If the tool's ROI exceeds the source's ROI, the tool automatically issues a failing result.

In the following image, the **Brightness** tool uses the **Binarize** tools output as the source image. As a result, the ROI of the **Brightness** tool must be fully contained within the **Binarize** tools source ROI. If there is an overlap between the two ROIs, the **Brightness** tool issues a fail.

# Using Machine Vision Tools



## Locate Tools

Locate tools find a single occurrence of a predefined template on an image by comparing object edges.

### Locate Object

Locate Object finds a specific pattern in a filmstrip based on an edge inside a user-defined region of interest.




**NOTE:** Aurora Focus imposes a 1GB size limit on all models.

If the total size of all models within a specific region exceeds this limit, use one of the following strategies to reduce the size:

- reduce the ROI size to keep only unique parts of the object
- increase edge contrast to keep only the most important edges (reduce noisy edges)
- reduce scale (if possible)
- reduce rotation (if possible)

# Using Machine Vision Tools



**Table 31** Locate Object Settings

Setting	Description
Acceptance Threshold	Determines the minimum score of the valid object occurrence.
Candidate Threshold	Filters out objects below the acceptable threshold in the intermediate phases of the algorithm execution. Note that increasing value can improve performance. However, low-quality objects may not be found.

## General Locate Object Settings

Configure General Locate Object settings such as acceptance threshold, candidate threshold, and rotation threshold.

**Table 32** General Locate Object Settings

Setting	Description
Acceptance Threshold	The minimum match score required to be considered a passing match. If multiple object match scores exceed this minimum, the highest matching object score is used as the final match.
Candidate Threshold	The threshold for a match of the trained pattern to a pattern in the acquired image.

**Table 32** General Locate Object Settings (Continued)

Setting	Description
Rotation Threshold	The minimum match score required to be considered a passing match. If multiple object match scores exceed this minimum, the highest matching object score is used as the final match.

## Advanced Locate Object Settings


Configure Advanced Locate Object settings such as performance control, noise, rotation threshold, and scale deviation.

**Table 33** Advanced Locate Object Settings

Setting	Description
Performance Control	Select the best coarseness and search type combinations for a more performant search.
Noise	This filter removes pixel-level noise while preserving edge data. <ul style="list-style-type: none"> <li>• Off - the object edges have no noise.</li> <li>• Low - the object edges have a low level of noise. The object shape and the model shape are nearly identical.</li> <li>• High - the object edges have a considerable noise level, or the object shape slightly differs from the model shape.</li> </ul>
Rotation Threshold	The minimum match score required to be considered a passing match. If multiple object match scores exceed this minimum, the highest matching object score is used as the final match.
Allow Scale Deviation	Allows locating objects slightly smaller or bigger than those used during model creation.

## Locate Object Plus

Locate Object Plus finds specific patterns in a specified region of interest and evaluates them based on advanced characteristics such as minimum edge contrast and scale factor.



### Advanced Locate Object Plus Settings


Configure Advanced Locate Object Plus settings such as performance control, noise, rotation threshold, minimum edge contrast and scale factor.

**Table 34** Advanced Locate Object Plus Settings


Setting	UI Element
Performance Control	Use the selector to choose the best coarseness and search type combinations for a more performant search.
Noise	Use this filter to remove pixel-level noise while preserving edge data.
Rotation Threshold	A minimum match score is required to be considered a passing match. If multiple object match scores are above this minimum, the highest matching object scores are used as the final match.
Minimum Edge Contrast	Manually sets the minimum contrast in the acquired image to match the trained patterns.

**Table 34** Advanced Locate Object Plus Settings (Continued)

Setting	UI Element
Scale Factor	The Minimum Scale Factor and Maximum Scale Factor parameters determine the range of template scales that will be considered in the matching process. It enables locating objects that are slightly smaller or bigger than the object used during model creation. A wide range of possible scales introduces significant overhead (both in memory usage and computing time). As a result, it is recommended to limit the range whenever possible.




Smaller object used to model creation



Max Scale Factor = 1.1


## Using Machine Vision Tools



Max Scale Factor = 1

### Locate Edge

Locate Edge identifies transitions based on the highest contrast in a user-defined region of interest.



## General Locate Edge Settings

Configure General Locate Edge settings such as fixture, image type, scan direction, edge sorting, transition type, fixture type, minimum edge length, maximum gap, skew tolerance, edge contrast and edge profile.

**Table 35** General Locate Edge Settings

Setting	Description
Fixture	Select a previous tools' result to be used to position this tool's ROI.
Image Type	Select the type of image that the inspection type will use.
Scan Direction	Sets the direction that the tool uses when searching for edges.
Edge Sorting	Narrow down a collection of found edges to a single found edge.
Transition Type	Select the type of edge transition used to find the edge.
Fixture Type	Include all information, position only, or Y position only.
Minimum Edge Length	The minimum length in pixels for an edge to use.
Maximum Gap	The maximum size in pixels to consider in gaps for an edge.
Skew Tolerance	Degrees to attempt to measure a line if it is not straight.
Edge Contrast	Threshold acceptance to consider a line.
Edge Profile	Displays the contrast score of the features across a region of interest.

## Locate Blob


A blob is a set of connected light-or dark-colored pixels. The Locate Blob tool detects blobs that pass specific filter parameters within a region of interest.

This filter is helpful for quickly segmenting an image. The Locate Blob tool performs a series of operations on the image, including; thresholding using the **Threshold** parameter and removing holes by setting **Fill Holes**.

Filter Boundary blobs by setting **Allow Boundary** blobs.


## Using Machine Vision Tools

Image Viewer




Allow Boundary Blobs = False

Image Viewer




Allow Boundary Blobs = True

Image Viewer



Fill Holes = False

Image Viewer



Fill Holes = True

## General Locate Blob Settings

Configure General Locate Blob settings such as fixture, image type, threshold, histogram result, filters and sorting.

**Table 36** General Locate Blob Settings

Setting	Description
Fixture	Select a previous locate tool result that is used to position the tool's ROI.
Image Type	Select the image that the inspection tool will use.
Threshold	Select a threshold for black or white blobs. This value is automatically set to 117.
Histogram Result	Visual representation of the number of pixels found at each grayscale level.
Filters	Apply filters to set the criteria used to consider a blob as valid.
Sorting	Defines the priority for selecting the blob to return.

## Locate Circle

Locate Circle finds a circle model inside a user-defined region of interest that fits the specified parameters.



## General Locate Circle Settings


Configure General Locate Circle settings such as find by, transition type, maximum edge magnitude, edge profile, and scale calibration.

**Table 37** General Locate Circle Settings

Setting	Description
Find By	<p>Describes which result is reported as filter output:</p> <ul style="list-style-type: none"> <li>Best Score - searches for the best match to the detected edges within a given ROI.</li> <li>Largest Circle - returns the largest circle that matches the edges found in a given ROI.</li> <li>Smallest Circle - returns the smallest circle that matches the edges found in a given ROI.</li> </ul>
Transition Type	<p>Determines what is considered an edge in a given image.</p> <ul style="list-style-type: none"> <li>Blended - any change in pixel intensity determines an edge.</li> <li>Both - changes from dark to bright pixels or changes from dark to bright pixels determine an edge.</li> <li>Dark to Light - changes from dark to bright pixels determine an edge.</li> <li>Light to Dark - changes from bright to dark pixels determine an edge.</li> </ul>
Maximum Edge Magnitude	The minimum acceptable edge strength.
Edge Profile	Displays the contrast score of the features across the region of interest.
Scale Calibration	Calibrates pixel values to engineering units.

## Advanced Locate Circle Settings

When **Enable Outlier Suppression** is enabled, the resulting output resembles the output example below:



**Table 38** Advanced Locate Circle Settings

Setting	Description
Scan Width	Defines the width of the area neighboring each scanning line that should be considered when calculating the results in pixels.
Scan Count	Sets the number of scanning segments used around the circumference when defining the circle edge.
Maximum Incompleteness	Sets the percentage of points in the circle edge that are allowed to be missing while still providing a passing result.
Enable Outlier Suppression	Allows the suppression of influence of values far from most others on the result using Tukey's M-estimator.

## Filter Tools

Filter Tools are facilitated by the use of a kernel. A kernel is repeatedly centered at each pixel within the dimensions of the region that is being transformed. Every pixel is either added to the resulting region or not, depending on the operation-specific condition set on the minimum number of kernel pixels that have to overlap with actual input region pixels in the given position of the kernel.

### Binarize

The Binarize Tool converts the image to monochrome.

The operation transforms each pixel value to the maximum or minimum level, creating a binary image. The result of the transformation depends on the pixel intensity:

- Pixel values in the range (MinValue, MaxValue) are transformed to the maximum level.

- Other pixel values are transformed to the minimum level.



**Table 39** Binary Settings


Setting	Description
Fixture	Select a previous tool's result to position this tool's ROI.
Image Type	Select which image to use with this tool.
Threshold	The algorithm detects the best threshold to use for the filter.
Histogram Result	Visual Representation of the number of pixels found at each greyscale level.

## Dilate

The Dilate tool replaces each pixel with a maximum of pixels within the kernel. This tool also thickens bright features in an image and reduces dark features.

The operation replaces each pixel with the brightest pixel in its neighborhood, thus shrinking dark areas and expanding the bright ones.

The following images display a Dilate tool result with three Kernel Rows and three Kernel Columns.


**Table 40** Dilate Tool Settings

Settings	Description
Fixture	Select a previous locate tool's result that is used to position this tool's ROI.
Image Type	Select which image this inspection tool uses.
Kernel	Select the kernel values used to calculate the filter output.

## Erode

The operation replaces each pixel with the darkest pixel in its neighborhood, thus shrinking bright areas and expanding the dark ones.

The following images display an Erode tool result with three Kernel Rows and three Kernel Columns.

**Table 41**


Settings	Description
Fixture	Select a previous locate tool's result to position this tool's ROI.
Image Type	Select which image this inspection tool will use.
Kernel	Select the kernel values used to calculate the filter output.

## Open


The Open tool decreases the image's overall brightness and enhances the remaining bright features by contrast.

Removes small bright structures from an image (or fills in dark ones) by applying consecutive erosion and dilation.

The following images display an Open tool result with three Kernel Rows and three Kernel Columns:



Original image



Result

**Table 42** Open Settings


Settings	Description
Fixture	Select a previous locate tool's result to position this tool's ROI.
Image Type	Select which image this inspection tool will use.
Kernel	Select the kernel values used to calculate the filter output.

## Close


The Close tool increases the image's overall brightness and enhances the remaining dark features by contrast.

Removes small bright structures from an image (or fills in dark ones) by applying consecutive erosion and dilation.

The following image displays an Open tool result with three Kernel Rows and three Kernel Columns:



Original Image



Result

**Table 43** Close Settings

Settings	Description
Fixture	Select a previous locate tool's result that is used to position this tool's ROI.
Image Type	Select which image this inspection tool will use.
Kernel	Select the kernel values used to calculate the filter output.

## Gradient Full


The Gradient Full tool brightens horizontal and vertical edges within the defined area of interest.

Method of estimation of the vectors' magnitude:


$$\text{Hypot} - \frac{\sqrt{x^2+y^2}}{4}$$

**x- horizontal gradient component**

**y- vertical gradient component**



Original Image



Result

**Table 44** Gradient Vertical Settings

Settings	Description
Fixture	Select a previous locate tool's result to position this tool's ROI.
Image Type	Select which image this inspection tool will use.
Scale	Increases the brightness of the edges in the output result. This input is used to scale the output edge brightness values.


## Gradient Horizontal

The Gradient Horizontal tool brightens horizontal edges within the defined region of interest.

Method of estimation of the vectors' magnitude:

$$\text{Vertical} - \frac{\sqrt{y^2}}{4}$$

### y- vertical gradient component



Original Image



Result

**Table 45** Gradient Vertical Settings

Settings	Description
Fixture	Select a previous locate tool's result to position this tool's ROI.
Image Type	Select which image this inspection tool will use.
Scale	Increases the brightness of the edges in the output result. This input is used to scale the output edge brightness values.


## Gradient Vertical

The Gradient Vertical tool brightens vertical edges within the defined region of interest.

Method of estimation of the vectors' magnitude:

$$\text{Horizontal} - \frac{\sqrt{x^2}}{4}$$

### x- horizontal gradient component



**Table 46** Gradient Vertical Settings

Settings	Description
Fixture	Select a previous locate tool's result to position this tool's ROI.
Image Type	Select which image this inspection tool will use.
Scale	Increases the brightness of the edges in the output result. This input is used to scale the output edge brightness values.

## Identification Tools

Use the Identification Tools to read barcodes, DPM, Datacode, and Deep Learning OCR.

### Using BQM for Identification Tools


Statistics similar to Code Quality metrics are accessible for Identification tools such as Read Barcode by using Advanced Data Formatting (ADF).

To access and output various BQM statistics using the Advanced Data Formatting configuration:

1. Navigate to the **Data Formatting** tab


## Using Machine Vision Tools

2. Click the **Select Advanced Formatting** radio button




3. Click **Add Data Types** in the **Data** section.

4. Scroll to observe various BQM-related statistics that you can send to your output.



## Read Barcode

Configure barcode decode settings such as Inverse 1D, ROI overlap, or ROI search.



**Table 47** Read DPM and Barcode Settings


Settings	Description
Inverse 1D	Choose the type of barcode to read.
Minimum Percentage Barcode/ROI Overlap	Define the minimum percentage a barcode needs to be contained within ROI to decode. For 1D barcodes, this applies only to the horizontal (X) dimension. For 2D barcodes, this applies to horizontal and vertical (X & Y) dimensions.
No Read String	Define the data that should be output if no barcode is read (in place of barcode data in a successful read, as opposed to no output at all).

**Table 47** Read DPM and Barcode Settings (Continued)

Settings	Description
Enable Adaptive ROI Search	Enabling Adaptive ROI allows the underlying barcode scanning algorithm to alter (shrink and reposition) the area of the ROI for subsequent reads based on the presence of past-read barcodes, providing better-performing barcode reads. The small/medium/large drop-down settings alter the generation of the adapted ROI component.
Barcode String Match	Enable this setting to define the pass/fail criteria based on the contents of the decoded barcode.
Enable Barcode Quality Metrics	Enable this checkbox to enable BQM outputs (Overall Grade)
2D DataMatrix BQM Parameters	Enable or disable parameter options to include in BQM calculations.   <b>NOTE:</b> These settings are applicable to 2D DataMatrix barcodes only,
Minimum BQM Grade	Enable this option to use a threshold for issuing a pass or fail based on the BQM overall grade for each barcode scan.  For example, by setting the threshold between C and D, if a barcode achieves a BQM grade of A, B, or C, the job/tool issues a pass. If the overall grade is a D or an F, the BQM grade is a fail.
Send Decode on Failure	By default, if a barcode is read but has a failing BQM grade (as defined by the <b>Minimum BQM Grade</b> threshold above), its data is not output (to either the <b>Deploy</b> screen or various outputs such as TCP/IP/Serial/USB).  When enabled, the decoded data is output even if the BQM Overall Grade is a failing grade based on the <b>Minimum BQM Grade</b> threshold.

## Read DPM

Configure DPM decode settings such as Inverse 1D, barcode string match, or ROI search.




**Table 48** Read DPM Settings

Settings	Description
Inverse 1D	Choose the type of barcodes to read.
No Read String	Define the data to be output if no barcode is read.
Enable Adaptive ROI Search	Enabling Adaptive ROI allows the underlying barcode scanning algorithm to alter (shrink and reposition) the area of the ROI for subsequent reads based on the presence of past-read barcodes. This provides better-performing barcode reads. The small/medium/large drop-down settings alter how the adapted ROI component is generated.
Barcode String Match	Enable this setting to define pass/fail criteria based on the contents of the decoded barcode.

## Read DPM and Barcode

Configure DPM and barcode decode settings such as Inverse 1D, a no-read string, or barcode string match.



**Table 49** Read DPM and Barcode Settings


Settings	Description
Inverse 1D	Choose what type of barcodes you want to be able to read.
No Read String	Define the data that should be output if no barcode is read (in place of barcode data in a successful read instead of no output at all).
Enable Adaptive ROI Search	Enabling Adaptive ROI allows the underlying barcode scanning algorithm to alter (shrink and reposition) the area of the ROI for subsequent reads based on the presence of past-read barcodes. This provides better-performing barcode reads. Drop-down settings alter how the adapted ROI component is generated.
Barcode String Match	Enable this setting to define pass/fail criteria based on the contents of the decoded barcode.

## Datacode

Configure Datacode settings such as a No Read String, Module Size, or Search Strategy. This tool is helpful for reading 2D barcodes that are difficult to decode.

### General Datacode Decode Settings

General Datacode decode settings include defining a timeout string, no read string, polarity, and string match.




**Table 50** General Datacode Decode Settings

Setting	Description
Timeout	Set a time limit to stop the execution of the inspection tool, resulting in a failure.
No Read String	Specify a no read string.
Polarity	Select a polarity for the decode. <ul style="list-style-type: none"> <li>• Any</li> <li>• Bright</li> <li>• Dark</li> <li>• Mixed</li> </ul>
String Match	Enable String Match to decode successfully when the value matches the string provided.

## Advanced Datacode Decode Settings

Advanced Datacode decode settings include defining a detection strategy, decoding strategy, module size, detection method, finder tradeoff, contrast threshold, line count, distortion, gap size, code slant, super resolution, perspective level, edge tracker, mirrored codes, broken patterns, rectangular codes and codes with broken corners.



**Table 51** Advanced Datacode Decode Settings

Setting	Description
Detection Strategy	<p>Specify the step of image downsampling used for finding codes at different scales.</p> <ul style="list-style-type: none"> <li>• Super Fast</li> <li>• Fast</li> <li>• Precise</li> <li>• Strict</li> <li>• Extended</li> </ul>

**Table 51** Advanced Datacode Decode Settings (Continued)

Setting	Description
Decoding Strategy	<p>Specify the precision of outline detection:</p> <ul style="list-style-type: none"> <li>• Super Fast</li> <li>• Fast</li> <li>• Precise</li> <li>• Strict</li> <li>• Extended</li> </ul>
Module Size	Determine the minimum and maximum range for modules.
Detection Method	Specify how code candidates are located.
Finder Tradeoff	Optimize parameters for weak or jagged edges.
Contrast Threshold	Set a contrast threshold for Datacode to use.
Line Count	Limit the number of Datamatrix modules in a row and column.
Allow Distortion	<p>Specify a distortion level:</p> <ul style="list-style-type: none"> <li>• None</li> <li>• Low</li> <li>• Medium</li> <li>• High</li> </ul>
Expected Gap Size	<p>Specify the distance between neighboring modules.</p> <ul style="list-style-type: none"> <li>• Zero</li> <li>• Small</li> <li>• Medium</li> <li>• Large</li> </ul>
Maximum Code Slant	Specify the maximum deviation from the right angle in the corner of the Finder Pattern.
Use Super Resolution	<p>Specify the image up-scaling method for low-resolution codes depending on minimum module size:</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• Yes</li> <li>• No</li> </ul>

**Table 51** Advanced Datacode Decode Settings (Continued)

Setting	Description
Perspective Level	Specify a perspective distortion of the code grid: <ul style="list-style-type: none"> <li>• None</li> <li>• Low</li> <li>• High</li> </ul>
Edge Tracker	Specify how strongly to preserve the continuity of an edge <ul style="list-style-type: none"> <li>• Very Weak</li> <li>• Weak</li> <li>• Medium</li> <li>• Strong</li> <li>• Very Strong</li> </ul>
Allow Mirrored	Allow mirrored codes.
Allow Broken Finder Pattern	Attempt to create a candidate if there are gaps in the Finder Pattern.
Allow Rectangular	Allow rectangular codes.
Allow Broken Corner	Attempt to create a candidate if the bottom-left corner of the code is occluded.


## Using Accelerated Tools

Deep Learning Object Character Recognition (OCR) and Anomaly Detection tools can be accelerated to speed up a specified tool during job execution and reduce overall tool time.



**NOTE:** Acceleration is available on FS42 and NS42 devices only.

1. Enable acceleration by sliding the **Accelerate** toggle to the right.



**NOTE:** In this mode, the Region of Interest (ROI) can be moved or rotated but not resized. Tool settings **Average Character Height** and **Character Width Scale %** are not editable while in Accelerate mode. Move the slider to the left to disable Accelerated mode and edit tool settings.


2. After **Accelerate** is enabled, the **Optimization** overlay displays, and all settings are blocked and transferred to the device.

Optimization



**NOTE:** For optimal performance, jobs should contain only one accelerated tool. Jobs containing more than one accelerated tool can negatively impact performance and increase execution time.

3. All accelerated tools are marked on the **FlowBuilder** by the green **Accelerated** indication.



**NOTE:** If a job is saved with the **Accelerate** setting enabled and later opened on a device that does not support this setting, it is automatically switched back to its standard state without acceleration.


## Deep Learning OCR

The Deep Learning Optical Character Recognition (OCR) tool reads text from images using Deep Learning.

This tool locates and recognizes characters without additional training:

- Horizontally-oriented
- Height between 85% and 115% of Char Height (in pixels)
- Contain Latin letters (upper case or lower case), digits, or one of: !#\$%&()^,-/:<=>?@[]^\_{}~"\€£¥

Use the Deep Learning OCR region of interest to limit the analyzed area, which can lead to improved performance. Moreover, it may be used to adjust to text that is not displayed horizontally.



**Table 52** Deep Learning OCR Settings

Setting	Description
Minimum Confidence	<p>The Minimum Confidence parameter may be used to change a character's minimum score. By default, this threshold is set to 80%.</p> <p><b>NOTE:</b> Adjusting this value downward can help include decodes of slightly lesser confidence to get the desired output. For example, the above example is too strict and does not decode various characters. Lowering this value from 99 to 98 yields a favorable result.</p>


**Table 52** Deep Learning OCR Settings (Continued)

Setting	Description
Average Character Height	<p>The Average Character Height should be set to the average height of characters (specifically, capital letters) in the analyzed area. For example, if an image contains two kinds of characters: one is 24 pixels high and the second is 40 pixels high, the Average Character Height should be set to 32, irrespective of the number of characters of each kind.</p> <p>Use the slider to select a value that is close to the average pixel height of text that is trying to be decoded. Performance improves when this value is closer to the average character height (in pixels).</p> <ul style="list-style-type: none"> <li>• Minimum Value: 8</li> <li>• Default Value: 25</li> <li>• Maximum Value: 200</li> </ul>
Character Spacing	Distance between characters denoted as a fraction of CharHeight.
Text Color	<p>Set a required polarity for a character to be returned.</p> <ul style="list-style-type: none"> <li>• Bright: Only characters with contrast greater than Contrast Threshold are returned.</li> <li>• Dark: Only characters with contrast lower than Contrast Threshold are returned.</li> <li>• Any: Only characters with contrast lower than Contrast Threshold or greater than Contrast Threshold is returned.</li> </ul> <p>Default Value: Any</p>
Contrast Threshold	<p>Sets a threshold for a contrast of found characters.</p> <p>Default value: 0</p>
Character Width Scale Percentage	<p>Scales image width by the given factor (%).</p> <ul style="list-style-type: none"> <li>• Minimum Value: 10%</li> <li>• Default Value: 100%</li> <li>• Maximum Value: 1000%</li> </ul>
Character Range	<p>Enable Character Range to limit the set of recognized characters. This string must be formatted according to the following rules:</p> <ul style="list-style-type: none"> <li>• Allowed characters must be separated with commas.</li> <li>• For ease of use, a continuous range of letters or digits may be written as starting_character-ending_character, for example: A-Z or 1-6.</li> <li>• Comma and backslash have to be prepended with a backslash.</li> </ul> <p>For example, Character Range equal to A-F,g-o,0-9,X,Y,Z,-,\,, results in recognizing only ABCDEFXYZghijklmnno0123456789-\,, characters.</p>

**Table 52** Deep Learning OCR Settings (Continued)


Setting	Description
Character Range	Provides the option to limit the set of desired characters when returning the result.
String Match	Defines a string that must be contained within the decoded OCR output for the tool to pass (for example, substring). By default, the tool passes if the match string is contained in the resulting OCR output. This allows additional characters to be added before and after the string. Enable the RegEx checkbox and use the syntax ^<stringToExactMatch\$ to implement the exact match behavior. RegEx can also be used for complex string match logic. Refer to the <a href="#">RegEx</a> section for more details.
Timeout	Sets a time after which the tool fails.
Invert Pass/Fail Result	Flips the results of this tool.

To use Deep Learning Based OCR with RegEx, enable the RegEx checkbox and provide an expression for the OCR tool to locate. The following example searches for the expression `^22\d{3}`.



## Advanced Deep Learning OCR Settings

Configure Advanced Deep Learning OCR settings such as character gap percentage, vertical misalignment percentage, minimum characters to create a line, and flatten.



**Table 53** Advanced Deep Learning OCR Settings

Setting	Description
Minimum Character Gap Percentage	<p>The maximum horizontal gap between joint characters' boxes is denoted as a percentage of A char height.</p> <ul style="list-style-type: none"> <li>• Minimum Value: 0%</li> <li>• Default Value: 25%</li> <li>• Maximum Value: 100%</li> </ul>
Maximum Vertical Misalignment Percentage	<p>The Maximum vertical misalignment between joint character boxes is denoted as a percentage of A char height.</p> <p>Default value: 0.25f</p> <ul style="list-style-type: none"> <li>• Minimum Value: 0%</li> <li>• Default Value: 25%</li> <li>• Maximum Value: 100%</li> </ul>

**Table 53** Advanced Deep Learning OCR Settings (Continued)


Setting	Description
Minimum Characters to Create a Line	Determine the minimum number of characters to create a line. Default value: 1  <b>NOTE:</b> can also be described as a Block or Word for the utilization of this tool.
Flatten	If True, it concatenates the words on the line into a single result string. Otherwise, each word is a separate result string. Default value: False.  <b>NOTE:</b> It is generally recommended to enable this setting.

## Presence/Absence Tools

Use Presence/Absence tools to detect specific objects or patterns within a user-defined region of interest.

## Object Presence Absence

The Object Presence Absence tool verifies the presence or absence of a specific pattern or object within a user-defined region of interest.



**Table 54** General Object Presence Absence Settings

Settings	Description
Acceptance Threshold	Select a minimum match score required to be considered a passing match. If multiple object match scores exceed this minimum, the highest matching object score is used as the final match.
Candidate Threshold	The threshold for a match of the trained pattern to a pattern in the acquired image.

## Advanced Object Presence Absence Settings


Configure Advanced Object Presence Absence settings such as performance control, noise, rotation threshold, and scale deviation.

**Table 55** Advanced Object Presence Absence Settings

Settings	Description
Performance Control	A selector to choose the best coarseness and search type combinations for a more performant search.
Noise	This filter removes pixel-level noise but preserves edge data.
Rotation Threshold	A minimum match score is required to be considered a passing match. If multiple object match scores are above the minimum, the highest matching object score is not used as the final match.
Allow Scale Deviation	When enabled, this setting allows the location of objects slightly smaller or larger than the object used during the creation of the model.

## Object Plus Presence Absence

The Object Plus Presence Absence tool finds specific patterns in a specified region of interest and evaluates them based on advanced characteristics such as minimum edge contrast and scale factor.



Settings	Description
Acceptance Threshold	The minimum match score required to be considered a passing match. If multiple object match scores exceed this minimum, the highest matching object score is used as the final match.
Candidate Threshold	The threshold for a match of the trained pattern to a pattern in the acquired image.

## Brightness

The Brightness tool calculates the average pixel brightness value in a user-defined region of interest.




**Table 56** General Brightness Settings

Settings	Description
Fixture	Determine the fixture for the ROI shape.
Image Type	Select which image this inspection tool should use.
Value Range	Set the minimum and maximum values.
Histogram	Shows the number of pixels at each value.

## Contrast

The Contrast tool calculates the maximum and minimum pixel intensity difference in a user-defined region of interest.



**Table 57** Contrast Settings


Settings	Description
ROI Shape	Select a Rectangle or Circle shape for the Region of Interest
Fixture	Select the output from a locate or scanning tool's previous result to position the current tool's ROI.
Image Type	Select which image this inspection tool should use.
Value Range	Set the minimum and maximum values.
Outlier Suppression	Specify the amount of extreme pixel values to exclude when calculating the final contrast. Its meaning is the percentage of outlier (noise) we suppress while calculating contrast value.
Histogram	Shows the number of pixels at each value.

## Using Outlier Suppression


Outlier Suppression is the percentage of the noise suppressed when calculating the contrast value.

The following histograms provide visual examples of different levels of suppression:


**Figure 3** High Suppression (5%) / Contrast: 20




**Figure 4** Medium Suppression (2%) / Contrast: 83



**Figure 5** Low Suppression (1%) / Contrast: 180




**Figure 6** No Suppression (0%) / Contrast: 226



## Edge Detect

The Edge Detect tool identifies transitions based on the highest contrast in a user-defined region of interest.



**Table 58** Edge Detect Settings


Settings	Description
Fixture	Select a previous locate tool result to position this tool's ROI.
Image Type	Select which image type this tool uses.
Scan Direction	Set the direction that the tool uses when searching for edges.
Edge Sorting	Refine a collection of found edges to a single best edge.
Transition Type	Select the type of edge transition used to find the edges.
Minimum Edge Length	The minimum length in pixels of an edge to use.
Maximum Gap	The maximum size in pixels to consider in gaps of the edge.
Skew Tolerance	Degrees to attempt to match the skew of the line if it is not straight.
Edge Contrast	Threshold acceptance to consider a line.

**Table 58** Edge Detect Settings (Continued)

Settings	Description
Edge Profile	Displays the contrast score of the features across the region of interest.

## Blob Presence Absence

The Blob Presence/Absence tool verifies the presence or absence of a blob within a user-defined region of interest.

**Table 59** Blob Presence Absence

Setting	Description
Image Type	Select which image this tool should use.
Threshold	The algorithm detects the best threshold for the tool to use
Histogram Result	Sets the number of pixels at each value.
Filters	Apply filters to set the criteria used to consider a blob valid for this tool.
Sorting	Define the priority for selecting a blob to return.

## Using Anomaly Detection

Aurora Deep Learning Editor is required to run Anomaly Detection in Aurora Focus.



**NOTE:** Anomaly Detection is available on FS42 and NS42 devices only.

### Acquiring Images


Images can be acquired and saved via FTP or directly onto the device.

1. If you acquire the images live in an industrial environment, use Image Saving via FTP or directly onto the device. For more information on setting up image saving, refer to the FTP File Saving section in the Aurora Focus User Guide.
2. If you save the images via FTP, they are saved directly to the host PC using Aurora Deep Learning Editor.
3. If you save the images directly onto the device, access them using the Aurora Focus Web HMI. For more information, refer to the Accessing the Web HMI section in the Aurora Focus User Guide.

### Preparing Images

It is important to properly organize and label the images when training the model.

1. Collect a series of images using periodic single-shot mode in Aurora Focus.
2. Save the images to the local host/PC
3. Create separate folders for Bad and Good images for testing purposes.



4. Click  to import the images into Aurora Deep Learning Editor and label them.


### Using Aurora Deep Learning Editor

Aurora Focus and Deep Learning Editor are directly connected and require compatible versions.

1. The upper left corner of the home screen provides tools for training images. Click **Add** to add new images to the editor.
2. Images added using **Toggle Class** and **Select type** can be marked as ready to be trained on.

## Using Machine Vision Tools

3. Images with a model are marked as training with a green checkmark.




**NOTE:** In some cases, it may be helpful to include irregular images marked as test images to train the model.

4. The **Training Parameters** to decrease or increase the complexity and downscaling of the model. Both contribute to the training time and the working time of the model. The effect of enabling these settings is observable by clicking **Pre-processing** above the previewed image.
5. After the settings are configured, click **Run** to start generating the model.




**NOTE:** If the Deep Learning Editor is being run for the first time, the first click launches the Deep Learning Service, and the second starts generating the model.




## Creating a Model

The Anomaly Detection tool in Aurora Focus uses the Aurora Deep Learning Editor.


1. Add the **Anomaly Detection** tool from **Presence/Absence** tools list.




2. Click **Create Model** to use an existing model or create a new one.




**NOTE:** Anomaly Detection requires the latest version of Aurora Deep Learning Editor. To download the latest version, open Zebra Aurora Focus while connected to an FS42 or NS42 device or emulator and add the Anomaly Detection tool. The dialog box provides a direct link to download the latest version of Deep Learning Editor.




- 3.** If you are using an existing model, click  and navigate to the location of the model on your PC and click the folder icon.



- 4.** If you are creating a new model, select the model type from the dropdown and click OK.



- a)** Click  to select a location for the model on your PC.





**NOTE:** Model editing is done in Deep Learning Editor.

## Understanding Thresholds

Threshold values inform the classification of the images in the dataset by providing scores and confidence levels.

After the training phase, scores are calculated for every training sample and presented as a histogram; good samples are marked with green bars and bad samples with red bars. All images with scores between  $T_1$  are marked Good, and images above  $T_2$  are classified as Bad. If the score is below  $T_1$  and  $T_2$ , the result has a low confidence level.


Training with many samples from both groups is recommended to achieve a more robust threshold.

The histogram tool displays green bars representing correct samples and red bars representing anomalous samples.  $T$  marks the main threshold, and  $T_1$  and  $T_2$  define the area of uncertainty.


- Images that have scores within  $0-T_1$  are marked as Good, Confident: Yes
- Images that have scores within  $T_1-T$  are marked as Good, Confident: No
- Images that have scores within  $T-T_2$  are marked as Bad, Confident: No
- Images that have scores within  $T-T_2$  are marked as Bad, Confident: Yes
- If both thresholds are equal ( $T_1=T_2=T$ ), there is no area of uncertainty. Results are marked as Confident: Yes
- Confident: No indicates the score is close to the threshold. In this case, perform another inspection.

The following histogram displays well-separated groups, indicating that the model has good accuracy:


**Figure 7** Uncertainty Threshold



The following histogram displays groups in close proximity, indicating that the model has poor accuracy:

**Figure 8** Good and Bad Model Accuracy Examples

The following histogram provides a real-world example in Aurora Deep Learning Editor:

**Figure 9** Aurora Deep Learning Editor Example

This example shows 36 images in the model with clear grouping between Good and Bad images, indicating that the model has good accuracy.


## Using Pro Mode

Enable Pro Mode to access advanced parameters such as Network Depth, Complexity, and Device.

1. Toggle the button to the right to enable Pro Mode

## Using Machine Vision Tools

### 2. Observe the following additional parameters:




- Network Depth - the size of the network's internal memory. Use higher depth for images containing complex patterns or a wide variety of objects.
- Complexity - higher density provides more precise heatmaps but can increase execution time.
- Device - provides information on the device the training is being performed on.
- Pre-Processing
  - Downsample - each level reduces the width and height of the images by a factor of two.
- Augmentations
  - Rotate Angle - rotate samples by a random angle between 0 and the parameter value.
  - Flip Up-Down - reflect samples along the x-axis.
  - Flip Left-Right - reflect samples along the y-axis.
  - Minimum Scale Percentage - minimum value of random scale factor applied to samples.
  - Maximum Scale Percentage - maximum value of random scale factor applied to samples.
  - Luminance Percentage - change brightness of samples by a random percentage (between -ParameterValue and +ParameterValue) of pixel values (0-255)

## Editing and Deploying Models in Aurora Focus

Load an existing model in Aurora Focus to edit and deploy on a set of images.

- Select the model from the drop-down menu.



- a) Click **Load** to deploy the model on a set of images in Aurora Focus.  
 b) Click **Edit** to edit the model in Deep Learning Editor.
- Configure the model settings as necessary:
  - Thresholds - use thresholds to classify an image as good or bad. Images that score below Threshold 1 (T1) are marked as good, and images above Threshold 2 (T2) are marked as bad. Classification results have low confidence if the threshold is between T1 and T2.



**NOTE:** For additional information on thresholds, go to [Understanding Thresholds](#)


- Heatmap - change the visualization settings of the heatmap that appears when reviewing results.

## Measurement Tools

Use measurement tools to measure the distance between two objects, the width of an object, or the diameter of a circle in the region of interest.

### Distance

The Distance tool determines the space between two specifically defined objects or patterns in an image.



**Table 60** Distance Tool Settings


Settings	Description
Measured Tools	<p>There are four different options for where to measure edges:</p> <ul style="list-style-type: none"> <li>• Left - measures from left or top of an edge.</li> <li>• Middle - measures from the middle of an edge</li> <li>• Right - measures from right/bottom of an edge</li> <li>• Perpendicular/Bottom - creates a measuring line perpendicular to this edge, extending until it intersects with another edge. Select an edge on one side.</li> </ul>

**Table 60** Distance Tool Settings (Continued)

Settings	Description
Distance Limit	Determine the minimum and maximum values.
Scale Calibration	Calibrate pixel values to engineering units measured in centimeters, millimeters, microns, or inches.

## Circle Diameter

The Circle Diameter tool measures the diameter of a circle located in the user-defined region of interest.




**Table 61** Circle Diameter Settings

Settings	Description
Find By	Define the approach used to search for the circle: <ul style="list-style-type: none"> <li>• Best Score</li> <li>• Largest Circle</li> <li>• Smallest Circle</li> </ul>
Transition Type	Select the type of edge transition used to find the circle: <ul style="list-style-type: none"> <li>• Both</li> <li>• Blended</li> <li>• Dark to Light</li> <li>• Light to Dark</li> </ul>
Minimum Edge Magnitude	Sets the minimum contrast value used to define the edge of the circle.
Edge Profile	Displays the contrast score of the features across ROI.
Diameter Range	The Diameter range parameter defines the diameter value for which the tool returns a pass or fail status.
Scale Calibration	Calibrates pixel values to engineering units.

## Measure Object Width

The Measure Object Width tool measures the width of an object present in an image.

The tool performs a series of scans along Scan Count parallel scan segments constructed from Measure Object Width ROI. The obtained points are then used for computing two parallel segments using a slightly modified segment-fitting routine. The Outlier Suppression parameter supports the process. Finally, the stripe widths and fitted segments' direction compute the object width.



**Table 62** Measure Object Width Settings

Setting	Description
Scan Direction	Set the direction that the tool uses when searching for edges.
Object Polarity	Determine the contrast type for the target object.
Stripe Sorting	Determine the mode of selection for the edges of the object.
Minimum Edge Magnitude	Set the minimum contrast value used to define object edges.
Edge Profile	Displays the contrast score of the features across the region of interest.
Distance Limit	Configure the minimum and maximum distance values.
Scale Calibration	Calibrate scale values to engineering units.

## Advanced Measure Object Width Settings

Configure Advanced Measure Object Width settings such as scan width, scan count, and object outlier suppression.

**Table 63** Advanced Measure Object Width Settings


Setting	Description
Scan Width	Defines the minimum number of pixels to consider when searching for an edge.
Scan Count	Sets the number of scanning segments used across the region of interest to find object edges.
Object Outlier Suppression	When enabled, this setting reduces the impact of outlier points found on edges by suppressing the influence of values in a significant variance of most others on the result using Tukey's M-estimator.

## Counting Tools

Counting tools determine the instances of particular objects within a user-defined region of interest.

## Pixel Count

The Pixel Count tool provides the number of pixels of a user-specified value (0-255) within a user-defined region of interest.




**Table 64** General Pixel Count Settings

Setting	Description
Threshold	The minimum and maximum threshold values for Pixel count.
Pixel Count	The minimum and maximum pixel count values are considered for passing.
Histogram	Shows the number of pixels at each value.

## Blob Count

The Blob Count tool counts the number of blobs that pass certain filter parameters within a region of interest.




**Table 65** Blob Count Settings

Settings	Description
Threshold	Determine the black or white threshold from the drop-down and use the slider to change the threshold value.
Histogram Result	Visual representation of the number of pixels found at each greyscale level.
Blob Count	The minimum and maximum blob count values are considered for passing.
Filters	Apply filters to set the criteria to consider a blob valid for this tool.

## Edge Count

The Edge Count tool identifies transitions based on the highest contrast level in a user-defined region of interest.



**Table 66** Edge Count Settings


Settings	Description
Scan Direction	Set the direction that the tool uses when searching for edges. <ul style="list-style-type: none"> <li>• Left to Right</li> <li>• Right to Left</li> <li>• Top to Bottom</li> <li>• Bottom to Top</li> </ul>
Edge Count Range	The minimum and maximum count value that is considered a pass.
Transition Type	Select the type of edge transition used to find the circle starting from the center outwards.
Minimum Edge Length	The minimum length in pixels of an edge to use.

**Table 66** Edge Count Settings (Continued)

Settings	Description
Maximum Gap	The maximum size in pixels to consider in gaps of the edge.
Skew Tolerance	of degrees to attempt to match the skew of the line if it is not straight.
Edge Contrast	Threshold acceptance to consider a line.
Edge Profile	Displays the contrast score of the features across the region of interest.

## Locate Object Count

Use the Locate Object Count tool to find a pattern in the image and set a match threshold for a candidate to be considered a match.



**Table 67** General Locate Object Count Settings

Settings	Description
Acceptance Threshold	The minimum match score required to be considered a passing match. If multiple object match scores are above this minimum, the highest matching object score is the final match.
Candidate Threshold	The threshold matches the trained pattern to a pattern in the acquired image.
Object Count	The minimum match score required to be a passing match. If multiple object match scores are above this minimum, the highest matching object score becomes the final match.
Minimum Distance	Set the minimum distance required between found objects.

### Advanced Locate Object Count Settings

Configure Advanced Locate Object Count settings such as performance control, noise, inverting the pass/fail result, and setting a minimum distance.

**Table 68** Advanced Locate Object Count Settings

Settings	Description
Performance Control	Use the selector to choose the best coarseness and search type combinations for a more performant search.
Noise	Removes pixel-level noise but preserves edge data.
Invert Pass/Fail Result	Inverts the result from the tool.
Minimum Distance	Sets the Minimum distance required between identified objects.

## Flaw Detection

Flaw Detection tools perform a pixel-to-pixel comparison of two images. This is helpful for cases where the object's surface or shape is complex.

- Edges - comparison based on objects' edges. This method is helpful when defects occur on the object's edge, pixel comparisons fail due to different light reflections, or when checking the object's surface is unnecessary.
- Intensity - comparison based on pixel intensity. Using this method, two images are compared pixel-by-pixel, and the defect is classified based on pixel intensity differences. This technique helps find defects like smudges or scratches.

The model uses a previously prepared image to compare images from the device. This technique provides a quick comparison inspection when specific conditions are met, such as stable lighting conditions, camera position, and precise object positioning.

## Edges

The Edge tool compares edges given input image with an image stored in a model created in the Training tab. As a result, the tool creates a region containing only pixels with different edges.

This method helps find defects in the object's shape. Due to its resilience against pixel gray level changes, it is helpful in applications with changing light conditions.

Parameter Maximum Distance defines the maximum distances of two edges that should be treated as the same edge.


The **Edge Threshold** and **Edge Hysteresis** parameters in the **Inspection** tab should have the same value as in the **Training** tab.



**NOTE:** Increasing the Edge Hysteresis connects more pixels by detecting edges.

If the input image's brightness significantly differs from the brightness of the golden image used in the **Training** tab.

Decrease the **Edge Threshold** slightly to concentrate on missing edges or increase the value to focus on excessive edges.



**Table 69** Edges Settings

Setting	Description
Edge Threshold	Determine a sufficient edge strength. Edges of at least 30 are detected on the input image.

**Table 69** Edges Settings (Continued)


Setting	Description
Edge Hysteresis	Determine the value by which the edge threshold decreases for edge points neighboring sufficiently strong edges.  NOTE: Use this parameter to control how weak adjacent pixels can be connected to a strong pixel. A higher value connects more pixels
Smoothing	Determine the tool's amount of horizontal and vertical smoothing to improve edge detection.

## Intensity

The intensity Tool detects edges given input image with an image stored in a model created in the Training tab and then, as a result, creates a region containing only pixels where edges are different.

This method is especially useful for finding defects in the object's shape. Due to its invulnerability to color changes, it may be used in appliances with changing light conditions. Parameter Maximum Distance defines the maximal distances of two edges that should be treated as the same edge.

The **Edge Threshold** and **Edge Hysteresis** parameters in the **Inspection** tab should have the same value as in the **Training** tab. The values should be changed, however, if the input image's brightness is significantly different from the brightness of the golden image used in the **Training** tab. The **Edge Threshold** can also be decreased slightly if one wants to concentrate on missing edges or increased to concentrate on excessive edges.



**Table 70** Intensity Settings

Setting	Description
Edge Threshold	Determine the minimum strength of the edges on the model where comparison is not performed.
Edge Dilation	Define how far from the detected edges comparison should not be performed.

# Upgrading a FS/VS Tools License

## FS/VS Licensing

There are two license types, Device Emulator Licenses and Device Upgrade Licenses. Device Emulator Licenses must be activated online. Device Upgrade licenses can be acquired online or offline using a .bin file. The activation of both licenses requires an Activation ID provided in the Entitlement Notification email.



**NOTE:** Ensure that your Date/Time is up to date before applying licenses. If the Date/Time is out of sync, unexpected behavior may occur, such as Device Upgrade Licenses appearing to be successfully applied, yet the tool that should be unlocked does not display in ToolBox when creating a job (for example, the OCR tool). If your clock is out of sync, update it using the Zebra Web HMI and reboot the device afterward. Verify that the time is updated by viewing the top-right bar in the Web HMI (green box) and restart Aurora Focus.

## License Types

The Zebra Web HMI refers to the License Name when describing license types that apply to FS/VS devices.

The following table outlines the available licenses and the corresponding License Name referenced in the Zebra Web HMI.

**Table 71** License Types

License Type	Part Number	License Name
VS Sensor Package	LIC-SEN001-0100	xs-feature-vspkg:1.0
VS Standard Package	LIC-SEST01-0100	xs-feature-vspkg:2.0
FS DPM Full Package	LIC-DPM001-0200	xs-feature-fspkg:3.0
FS Fast 1D/2D	LIC-2DF001-0200	xs-feature-fast1D2D:1.0
VS OCR	LIC-OCR002-0100	xs-feature-OCR02
FS OCR	LIC-OCR003-0100	xs-feature-OCR03
NS Anomaly Detection	LIC-AD002-0100	NSx2-feature-AD02
FS Anomaly Detection	LIC-AD003-0100	FSx2-feature-AD03

**Table 71** License Types (Continued)

License Type	Part Number	License Name
Gateway Connectivity License for FS10 devices	LIC-10LF-0000	xs-feature-deviceWISE03
Gateway Connectivity License for FS20 and VS20 devices	LIC-20LF-0000	xs-feature-deviceWISE04
Gateway Connectivity License for FS40, FS42, FS70, VS40, and VS70 devices	LIC-47LF-0000	xs-feature-deviceWISE05
Gateway Connectivity Full License for all devices in the FS and VS family	LIC-EXLF-0000	xs-feature-deviceWISE06



**NOTE:** Upgrades are available from a Sensor Toolset to a Standard Toolset and from an Fixed Scanning License to a Machine Vision License.

## Acquiring a License

For the customers, partners, and distributors that require a FS/VS Industrial Scanner product license for FS Decode and VS Machine Vision Tools through your Account Manager.

A perpetual license is a permanent license that is available for the lifespan of the device.

## License Acquisition Modes

Licenses can be acquired online or offline.

- Licensing Server (Online mode)
- Capability Response .bin File (Offline Mode)



**NOTE:** The upgrade and deactivation process for a license requires the device to be connected to an Ethernet network with an active internet connection. The device cannot utilize a computer's Internet connection (over USB-C or direct Ethernet connection to the computer) to perform the upgrade. When using an FS10 device, manually connect using a bridge.

### See Also

[Bridging an Internet Connection to FS/VS Devices](#)

## Enabling the Activation ID

The Activation ID is the unique 32-bit alpha-numeric number provided when the license is procured.

This number acts as the key to enable the device to activate a license. An example of the Activation ID is **xssn-ixa3-tdgb-elsi-mxd8-q6kq-cw50-20bp**.

## Upgrading a FS/VS Tools License

**Figure 10** Entitlement Email

Thank you for your Zebra Technologies software order. This email confirms receipt of your order and provides you with the associated Activation ID(s) for your licenses and link to access software downloads. Your use of the software is subject to your agreement of the terms and conditions of any end user license agreement associated with the software and may not be copied or further distributed unless authorized by Zebra Technologies Corporation.

We appreciate your feedback to help improve services related to Zebra Software Licensing, and kindly request you to fill out a quick anonymous satisfaction survey available [here](#).

1. Please validate the information below is correct. If incorrect, please contact [Zebra Technical Support](#) before proceeding.
  - Account Name: Information Not Available  
Account Type: End Customer  
Contact Name:  
Contact Email:
  - Account Name: Automation Distribution Inc  
Account Type: Zebra Distributor  
Contact Name:  
Contact Email:
2. Use the Activation ID(s) to activate the licenses you recently purchased with  
Sales Order ID: 92940778
  - Activation ID: xssm-ixa3-tdgb-elsi-mxd8-q6kg-cw50-20bp  
Product Name: Upgrade License for Deep Learning OCR for FS models  
Product Description: Upgrade License for Deep Learning OCR for FS models  
Sales Order ID: 92940778  
Purchase Order ID: 85523089  
Quantity: 4  
Start Date: May 8, 2023  
Expiration Date: Permanent
3. Zebra Software Licenses Portal Access:
  - End Customer, First Time User:
    - Click [here](#) to register with your entitlement ID  
Entitlement ID: 0rge-tkty-nbgo-n8ke-9hqr-Symr-27i8-bizw
  - Already have access, click [here](#)
  - Distributor/Partner, First Time User:
    - Please register for "Software License Management" access within [Partner Gateway](#) > Connecting Tools > Sales Enablement section
    - If the "Software License Management" access option is not available within the Partner Gateway, please contact the Partner Interaction Center for access



**NOTE:** Refer to the link shared in the confirmation e-mail when the license is procured for credentials.

## Applying a Device Upgrade License (Online)



**NOTE:** If you are using a USB or Ethernet cable directly connected from the device to your laptop, the device cannot leverage the host-laptop internet connection without manual bridging/sharing of internet connection across adaptors. For more information, go to the Bridging an internet Connection to FS/VS Devices section.

## Upgrading a FS/VS Tools License

1. Open the Zebra Web HMI by entering the device's IP address into a web browser or clicking the IP address link under **View Devices** in Zebra Aurora Focus.

The screenshot shows the Zebra Web HMI interface. The left sidebar has a 'View Devices' tab selected. The main content area shows a table of devices with columns: Name, Model Name, Part Number, IP, SN, Firmware, and Status. One device is listed: FS40 Camera (FS40), part number FS40-WA50F4-2C00W, IP 172.16.107.22 (USB), SN ...0022, Firmware 8.0, Status Connected. There are buttons for BACKUP DEVICE, RESTORE DEVICE, UPDATE FIRMWARE, DOWNLOAD LOGS, PRINT, REFRESH, and a search bar.

Name	Model Name	Part Number	IP	SN	Firmware	Status
FS40 Camera	FS40	FS40-WA50F4-2C00W	172.16.107.22 (USB)	...0022	8.0	Connected

2. Log in to the HMI using the default credentials for an administrator account:

- a. Username: admin
- b. Password: admin

## Upgrading a FS/VS Tools License

3. Select the gear icon to access the settings menu.



4. Select the **Licensing** tab.
5. Select the **Online** option from the ACQUIRE LICENSE METHOD.
6. Enter the following Licensing Server URL in the LICENSING SERVER URL form field:[zebra-licensing.flexnetoperations.com/flexnet/deviceservices](https://zebra-licensing.flexnetoperations.com/flexnet/deviceservices)
7. Enter the **Activation ID** that is provided via email when the license is procured.



**NOTE:** To circumvent a firewall while contacting the cloud-based license server. For detailed instructions, visit: [supportcommunity.zebra.com/s/article/ZSL-Licensing-Server-Connectivity](https://supportcommunity.zebra.com/s/article/ZSL-Licensing-Server-Connectivity)

8. Click **Activate License** to acquire the license. Available Licenses contain the following information:
  - a) License Index: Lists the license number
  - b) License Name: This is the license's feature name, for example, xS-feature-vsPKG.
  - c) License Version: Lists the license version number.
  - d) Expiration Date: Expiration date for the trial license. For a Perpetual license, this field shows permanently.
  - e) License Count: Lists the number of licenses allocated to the device.
  - f) Host ID: A unique number for the license server to identify the device. This number has both the devices' Part Number and Serial number. The example shown below is VS40-WA50P4-2100W\_12345678901234.
  - g) Release: Click **Discard** to release the license back to the device's license server.

## Applying a Device Upgrade License (Offline)

Ensure you have the Device ID and the Activation ID information before downloading the capability response.

### Downloading the Offline License Upgrade .bin File

To download the Capability Response (Offline License Upgrade .bin File) from the licensing server:

1. Visit the following link and log in to enter the Zebra Licensing Server at: [zebra-licensing.flexnetoperations.com/](http://zebra-licensing.flexnetoperations.com/).
2. Enter the Username and Password.

The screenshot shows the Zebra Licensing Server login interface. At the top is the Zebra logo. Below it is a form with two fields: 'Username\*' containing 'zslsystemtest@mailinator.com' and 'Password\*' containing several dots. A note below the fields says '\*Mandatory fields'. A large blue 'Sign in' button is centered below the fields. Below the button, there are links for 'Don't have an account? [Register now](#)', 'Forgot your password? [Reset Password](#)', and 'Need to change your password? [Change Password](#)'.

## Upgrading a FS/VS Tools License

3. The **Software Licenses Portal** displays:

The screenshot shows the Software Licenses Portal interface. At the top, there is a navigation bar with links for Home, Activation & Entitlements, License Support, Devices, Downloads, and Accounts & Users. Below the navigation bar, the title "Software Licenses Portal" is displayed. On the left, there are two main sections: "Recent Entitlements" and "Recent Releases". The "Recent Entitlements" section lists two items:

Activation ID	Product	Product description	Last modified
fdc4-ba5f-d451-4ba7-b4...	WFC Voice Device License Avaya Aura PREM	WFC Voice Device License - Avaya Aura Premium	Jul 7, 2021
c9e2-3c87-c213-4ff1-d-a...	WFC Voice Client SW Avaya Aura PREM 8.2	WFC Voice Client Software - Avaya Aura Premium 8.2. Note: This software product requires the WFC Voice Device IP Phone - Avaya Aura	Jul 7, 2021

The "Recent Releases" section shows a message: "The accounts you are currently assigned to do not have any entitlements. Please contact your system administrator." To the right of these sections are two boxes: "Your Downloads" (which is empty) and "Announcements" (which is also empty).

4. Click the **Devices** drop-down arrow and select **Create Device**.

5. On the **New Device** screen:

- Enter the **ID** in the format <Part\_Number>\_<Serial\_Number>
- Enter the **Name** (same as the ID)



**NOTE:** Some serial numbers are prefixed with the letter S, do not include the letter S in the Serial Number you include in your Device ID because this causes the process to fail.



**NOTE:** Do not select the **Runs license server** checkbox and leave **Site Name** empty.

- Select your **Account** from the drop-down list.



**NOTE:** Zebra (Zebra Technologies) is used as an example.

The screenshot shows the 'Device New Device' configuration screen. The 'Name' field contains 'VS40-WA50P4-2100W\_123456789'. The 'Runs license server?' checkbox is unchecked. The 'ID Type' dropdown is set to 'STRING'. The 'ID' field contains 'VS40-WA50P4-2100W\_123456789'. The 'Account' dropdown is set to 'Zebra (Zebra Technologies)'. The 'Site name' field is empty.

6. Click **Save**. Observe the **Device created successfully** screen to confirm the device is configured correctly.

The screenshot shows a success message "Device created successfully." followed by the device details for a newly created device. The device ID is VS40-WA50P4-2100W\_12345678901234. The device name is also VS40-WA50P4-2100W\_12345678901234. Other details include Site Name, Status (ACTIVE), Series (Series.Zebra), Model (Model-Zebra), Account (Zebra (Zebra Technologies)), and Vendor Dictionary (None).

ID :	VS40-WA50P4-2100W_12345678901234
Name :	VS40-WA50P4-2100W_12345678901234
Site Name :	
Status :	ACTIVE
Series :	Series.Zebra
Model :	Model-Zebra
Account :	Zebra (Zebra Technologies)
Vendor Dictionary :	(None)

7. Select **Action** to expand drop-down.

8. Next, select **Map By Activation ID**.

The screenshot shows a web-based device management interface. At the top, it displays "Device VS40-WA50P4-2100W\_12345678901234". Below this, there are two buttons: "View" and "Action". A dropdown menu is open under the "Action" button, listing the following options: "Map Entitlements", "Map By Activation ID", "Remove Licenses", "Download Capability", and "Response". The "Map By Activation ID" option is highlighted with a blue selection bar. To the right of the dropdown, the text "0180564" is visible. Below the dropdown, device details are listed: Status: ACTIVE, Series: Series.Zebra, Model: Model-Zebra, Account: Zebra\_Internal (ZEBRA INTERNAL), and Vendor Dictionary: (None).

Device VS40-WA50P4-2100W\_12345678901234

Back to list

Action

Map Entitlements

Map By Activation ID

Remove Licenses

Download Capability

Response

0180564

Status : ACTIVE

Series : Series.Zebra

Model : Model-Zebra

Account : Zebra\_Internal (ZEBRA INTERNAL)

Vendor Dictionary : (None)

9. On the **Map by Activations IDs** screen, enter the **Activation ID**. If you have multiple IDs, ensure each ID is entered on a separate line.

The screenshot shows the Zebra Licensing portal interface. At the top, there is a navigation bar with links for Home, Activation & Entitlements, License Support, Devices, Downloads, and Accounts & Users. Below the navigation bar, the title 'Map by Activation IDs' is displayed. Underneath the title, there is a field labeled 'Device ID:' containing the value 'VS40-WA50P4-2100W\_12345678901234'. Below this, there is a text area labeled 'Activation IDs (one per line):' containing the value 'b138-f432-4eca-470c-8d74-6838-0c41-4dd1'. At the bottom of the form are two buttons: a blue 'Validate' button with a white cursor icon over it, and a light blue 'Cancel' button.

10. Click **Validate**. Observe the **Validation successful** message to confirm that the **Activation ID** is valid.
11. Edit the **Quantity to Add** for all the licenses mapped to a single device.



**NOTE:** For a standalone license, the value should be 1 to map one license to one device.

12. Click **Save**.
13. Observe the **Entitlement successfully mapped** message.

14. Click **Action** to expand the menu and select **Download Capability Response**. The bin file is available in the **Download** folder.

The screenshot shows a device management interface. At the top, it displays "Device VS40-WA50P4-2100W\_12345678901234". Below this, there are two buttons: "View" and "Action". A mouse cursor is hovering over the "Action" button, which has a dropdown menu open. The dropdown menu contains five options: "Map Entitlements", "Map By Activation ID", "Remove Licenses", "Download Capability Response", and "Synchronize". To the right of the dropdown menu, the text "0180564" is visible. Below the dropdown, there is a summary of device details:

- Status : ACTIVE
- Series : Series Zebra
- Model : Model-Zebra
- Account : Zebra\_Internal (ZEBRA INTERNAL)
- Vendor Dictionary : (None)

After the download, verify that the device is accessible in the directory.



**NOTE:** The attached files follow a specific naming convention and must not be renamed. The files do not apply correctly if they are renamed. Also, ensure that Windows does not append any text to the filename, such as (1).

## Applying a License in Offline Mode

Use the offline license acquisition method when an internet connection is unavailable.




**NOTE:** The Capability Response (Offline License Upgrade .bin File) must be downloaded from the server to acquire a license with this method.

To acquire the license in the offline mode:

1. Download the Capability Response (Offline License Upgrade .bin File).

2. On the **Licensing** screen, select the offline option from the **Acquire License Method** option.



3. Click **Choose File** and locate the bin file acquired as part of downloading the capability response.
4. Click **Activate License** to activate the license and observe the **Available License(s)** list.
5. Start a new job in Aurora Focus to utilize the upgraded toolset.
  - Close any current jobs if they are still open in the application.
  - Starting a new job displays the newly enabled tools available with the upgraded license.



**NOTE:** The device name, model name, and part number remain unchanged after a license upgrade. New tools based on the new license are available upon creating a new job.


## Time Tampering

License operations such as acquiring and returning licenses are time-dependent. The device must be configured with the current date and time. Failing to do so can result in errors when acquiring and releasing licenses. The device time can be set automatically via the NTP server or configured manually in the **Date and Time Sync** window.



**NOTE:** Clock Wind Back detection is enabled by default in the device firmware. Backtracking of date or time results in a license error.

## Upgrading a FS/VS Tools License




## Returning a License

Users can return the license to the cloud server regardless of the method used to acquire the license (offline or online) initially.



**NOTE:** The device must be connected to the internet to return a license.

1. On the **LICENSING** screen, select **Online** option in the **ACQUIRE LICENSE METHOD** section.



2. In the **LICENSING SERVER URL** field, enter the licensing server URL.

3. Click  to release the license back to the license server.
4. After removing the licenses, the empty **ACTIVE LICENSES** list window displays.

## Fixed Industrial Scanning Toolset

The following tools are available with a specific license type.

**Table 72** Fixed Industrial Scanning Tools

Tool	Standard 2D	Fast 2D	DPM with Fast 2D	OCR
Barcode Reading	X	X	X	
Fast 2D (60 fps)		X	X	
DPM			X	
Locate Object				X
Deep Learning OCR				X

## Machine Vision Toolsets

The following tools are available with a specific license type.

**Table 73** Machine Vision Tools

Type	Tool	Sensor	Essential (NS42 Only)	Standard
Locate Tools	Locate Object	X	X	X
	Locate Object Plus		X	X
	Locate Edge	X	X	X
	Locate Blob		X	X
	Locate Circle	X	X	X
Filter Tools	Binarize		X	X
	Dilate		X	X
	Erode		X	X
	Open		X	X
	Close		X	X
	Gradient Full		X	X
	Gradient Horizontal		X	X
	Gradient Vertical		X	X
Identification Tools	Read Barcode		X	X
	Read DPM			X
	Read DPM and Barcode			X

**Table 73** Machine Vision Tools (Continued)

Type	Tool	Sensor	Essential (NS42 Only)	Standard
	Datacode			X
Presence/Absence Tools	Object P/A	X	X	X
	Object Plus P/A		X	X
	Brightness	X	X	X
	Contrast	X	X	X
	Edge Detect	X	X	X
	Blob P/A		X	X
Measurement Tools	Distance	X	X	X
	Circle Diameter	X	X	X
	Measure Object Width		X	X
Counting Tools	Pixel Count	X	X	X
	Blob Count		X	X
	Edge Count	X	X	X
	Locate Object Count	X	X	X
Flaw Detection	Edges		X	X
	Intensity		X	X

## Bridging an internet Connection to FS/VS Devices

To add a license to an FS/VS device using an online licensing server, the device must have access to the internet. The device can be connected through an Internet-connected router. But in cases where that is not possible or convenient, the internet connection of a laptop or desktop computer running Windows can be shared with the devices. To share internet to a device connected to the computer over USB, these steps must be performed on the device first (does not need to be done for devices connected over Ethernet):

1. Open Aurora Focus.
2. Manage the device to which you want to share internet.
3. Navigate to the **Communication** tab.
4. Click **Enable Edit Mode** and **OK** if prompted with a warning about stopping jobs.
5. Navigate to the **USB** tab under **Network Settings**.
6. Select **Enable DHCP**, and click **Apply**.

To share the internet connection to a device when connected over USB or when plugged into a PoE switch that is plugged into the computer or dock's ethernet port:

1. Navigate to **Windows Control Panel > Network and Sharing Center > Change adapter settings**.
2. Right-click on the connection that provides internet. This is typically Wi-Fi but can also be Ethernet.
3. Click **Properties**.

4. Click the **Sharing** tab.
5. Select **Allow other network users to connect through this computer's internet connection..**
6. In the **Home networking connection** drop-down, select the connection you want to share internet over if the option appears. This may be something such as "Ethernet" or "Ethernet 5". If there is only one option for the connection, drop-down does not display.
7. If there are multiple Ethernet options, to find out which adapter is using the USB RNDIS, open a cmd prompt and type ipconfig /all, and locate the USB IP of your device (typically matches a DHCP Server as shown in the screenshot below). Locate the Ethernet adapter name for that section. Select that option in the menu.
8. Click **OK**.
9. Reconnect and reboot the device.

To share the internet connection to multiple devices connected over USB and Ethernet simultaneously:

1. Navigate to the **Windows Control Panel > Network and Sharing Center > Change adapter** settings.
2. Ctrl-click the USB or ethernet connections that the devices are connected to so they are highlighted simultaneously.
3. Right-click any of the highlighted connections and click **Bridge connections**.
4. Right-click the connection that is providing internet.
5. Click **Properties**.
6. Click the **Sharing** tab.
7. Select **Allow other network users to connect through this computer's internet connection.**
8. On the **Home networking connection** menu, select the bridged connection you just made if the option appears at all. If there is only one option for the connection, the drop-down will not display.
9. Click **OK**.
10. Reconnect and reboot the device(s).

**Figure 11** Identifying the DHCP Server

```
Ethernet adapter Ethernet 2:  
Connection-specific DNS Suffix . :  
Description . . . . . : Remote NDIS Compatible Device  
Physical Address . . . . . : 56-00-14-F8-1A-EB  
DHCP Enabled. . . . . : Yes  
Autoconfiguration Enabled . . . . . : Yes  
Link-local IPv6 Address . . . . . : fe80::e20e:c047:5143:1b5%9(PREFERRED)  
IPv4 Address. . . . . : 172.16.111.241(PREFERRED)  
Subnet Mask . . . . . : 255.255.0.0  
Lease Obtained. . . . . : Tuesday, May 23, 2023 5:07:05 PM  
Lease Expires . . . . . : Friday, June 2, 2023 5:07:05 PM  
Default Gateway . . . . . : 172.16.1.1  
DHCP Server . . . . . : 172.16.92.50  
DHCPv6 IAID . . . . . : 630091326  
DHCPv6 Client DUID. . . . . : 00-01-00-01-2B-EA-E3-78-B0-0C-D1-40-02-4E  
DNS Servers . . . . . : fec0:0:0:ffff::1%1  
fec0:0:0:ffff::2%1  
fec0:0:0:ffff::3%1  
NetBIOS over Tcpip. . . . . : Enabled
```

To test that a device has access to the internet, SSH into it and run **ping google.com**. If the connection to the server is successful, the device can connect to a licensing server over the internet.

# Connectivity Guidelines

Connectivity options are configurable in Device Settings. To access Device Settings, select a device on the View Devices tab and click Manage. On the Device Settings tab, click Communication to configure connectivity settings.

## Network Communication

Follow the procedures in this section to set a static IP address or change the hostname.

### Setting a Static IP Address



**NOTE:** DHCP is the default mode for IP addressing.

1. Disable the **Enable DHCP** checkbox.
2. Change the network-related settings based on your network configuration. For example:
  - a. Open a command prompt
  - b. Type the command: ipconfig
    - a. All TCP/IP network configuration values display on the host PC
    - c. Identify a valid network interface:
    - d. In Zebra Aurora Focus, enter the following values:
      - a. IP Address: 192.168.4.xxx (where xxx is any value from 1-255)
      - b. Subnet Mask: 255.255.252.0
      - c. Default Gateway: 192.168.4.1
  3. Click **Apply** when complete. The device reboots with the new static IP address.

### Changing the Hostname

To change the hostname on the device:

1. Locate the hostname field.

2. Enter the desired hostname:



**NOTE:** The hostname must be alphanumeric and have a maximum length of 26 characters.

3. Click **Apply** when complete.



**NOTE:** The device, application, and network hardware may need to be power-cycled for the hostname change to occur.



**NOTE:** The new hostname is visible following the device reboot.

## TCP/IP Communication

Configure TCP/IP communication settings to send and accept triggers.

### Setting Up TCP/IP Triggering

To set up TCP/IP triggering, follow the steps to enable TCP/IP output in device settings, configure jobs on the device to accept TCP/IP triggers, and send TCP/IP triggers to the device.

### Enabling TCP/IP Output in Device Settings



**NOTE:** TCP/IP output is disabled by default and must be explicitly enabled in the device's settings.

1. Select the representative communication type tab. For example, Ethernet Port 1
2. Scroll to TCPIP Settings
3. Check the Enable TCP/IP Control checkbox (disabled by default)



**NOTE:** Make note of the **Control Part Number** and **Trigger String** fields. This information is required to send a TCP/IP trigger from external software.

4. Click **Apply** in the TCP/IP settings window. Click **OK** in the following prompt.

### Configuring Jobs to Accept TCP/IP Triggers

1. Create or open a job on the device.
2. Within the job tab, click the Connect chevron and navigate to the **Triggers** tab.
3. Ensure the **Trigger Source** is set to **TCP/IP**.
4. Click **Deploy** when the configuration is complete.


## Setting up RS-232 Hardware

The following accessories are necessary for a serial interface connection.

- Power/GPIO Flying Leads cable


- USB to Serial Adaptor
  - DB9 RS-232 D-SUB Serial Adaptor
1. Connect the following wires from the flying leads cables to the DB9 Serial adaptor.

**Figure 12** Flying Leads to DB9 Serial Adapter Wire Diagram



Pin	Color	Description
1	Yellow	OUT1
2	White/Yellow	TXD
3	Brown	RXD
4	White/Brown	IN1
5	Violet	RTS
6	White/Violet	COMMON_IN
7	Red	DC_IN
8	Black	GND
9	Green	COMMON_OUT
10	Orange	IN0
11	Blue	OUT0
12	Grey	CTS
SHELL	Bare	SHIELD

2. Connect DB9 Serial Adapter (female) to USB-to-Serial adapter (Male).
3. Connect USB-to Serial adapter USB end into host PC.
4. Identify the COM port associated with the USB-to-Serial adaptor.
5. Identify the COM port associated with the USB-to-Serial adaptor using Device Manager on a Windows PC.
  - a) Expand the Ports field and identify the USB-to-Serial adaptor.



## Setting up RS-232 Triggering

Follow the steps in this section to enable RS-232 output in device settings or configure a job on the device to accept serial triggers.

### Enabling RS-232 Output in Device Settings



**NOTE:** TCP/IP output is disabled by default and must be explicitly enabled in the device's settings.

1. Select the respective communication type tab. For example, Ethernet Port 1 or USB.
2. Scroll down to RS-232 settings.
3. Check the **Enable RS-232 Control** checkbox (disabled by default).



**NOTE:** Observe the **Trigger String** and keep this value for reference to send a Serial trigger from external software.

4. Click **Apply** in the RS-232 area and **OK** on the resulting prompt to save the configuration.

### Configuring a Job on the Device to Accept Serial Triggers


1. Create or open a job on the device using Zebra Aurora Focus.
2. On the Job tab, click the **Capture** chevron and navigate to the **Triggers** tab to set the **Trigger Source** to **Serial**.
3. Complete the job configuration and click **Deploy** to send the job to the device.

Confirm that the device is able to accept Serial (RS-232) triggers.


### Sending a Serial Trigger to the Device

1. Open a Serial client terminal software such as PuTTY.
2. Establish a connection to the device by clicking **Serial** tab.
3. Enter the **COM port** settings:
  - Name: COM port number as defined in Device Manager.
  - Speed, Baud, and Parity as defined in Device Settings using Zebra Aurora Focus.
  - Stop Bits: 1
  - Handshake/Mode: Off

- Click **Open** to establish a serial connection.




- If a connection is successfully established, observe the **Serial Port COM opened** message.



- Type the **Trigger String** as defined in **Settings** in Zebra Aurora Focus and click **Enter**.

7. Enter **TRIGGER** as the default **Trigger String** and click **Send** to send a trigger using serial.



## RS-232 Results



**NOTE:** RS-232 output is disabled by default and must be explicitly enabled in Device Settings.

## Network Settings

**Ethernet Port 1**

Enable DHCP ⚠ Network controls are read-only when DHCP is enabled.

Network	Current Network
IP Address <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/>	IP Address <input type="text"/>
Subnet Mask <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/>	Subnet Mask <input type="text"/>
Default Gateway <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/>	Default Gateway <input type="text"/>

DNS	Current DNS
Preferred DNS Server <input type="text"/>	Preferred DNS Server <input type="text"/>
Alternate DNS Server <input type="text"/>	Alternate DNS Server <input type="text"/>
DNS Domain Name <input type="text"/>	DNS Domain Name <input type="text"/>

General
DHCP Timeout 30 s
Host Name FS4082b1

**APPLY**

1. Select the associated communication type tab.
2. Scroll down to **RS-232 Settings**.
3. Ensure that the **Enable RS-232 Results** checkbox is checked



**NOTE:** Record the **Speed, Data Bits, Parity, Stop Bits** you may need these settings later to listen for RS-232/Serial results from external software.

### RS-232 Settings

**Control**

Enable RS-232 Control

Control Terminator: CR+LF

Trigger String:

**APPLY**

4. Click **Apply** within the **RS-232 Settings** area

RS-232 Settings

Control

Enable RS-232 Control 

Control Terminator: CR+LF

Trigger String: TRIGGER

Results

Enable RS-232 Results

Speed (Baud Rate): 9600

Data Bits:  7  8

Parity: None


Stop Bits:  1  2

APPLY

## Listening to RS-232 Output Events

1. Open an RS-232 client terminal software such as PuTTy.
2. Establish a connection to the device by clicking **Session**.
3. Set **Serial Line** to the COM Port Number.
4. Set **Speed** to the Serial speed defined in Aurora Focus.


5. Click **Open** to open a serial connection in terminal.



6. If the connection is successful, observe the terminal window with a green cursor.



7. Trigger the job and observe the results in the terminal window to confirm that the device is configured as expected.



## Listening for USB-CDC Output Events

To set USB CDC-Serial Results as job output, enable USB CDC-Serial Output in **Device Settings** using Aurora Focus.


### Setting Up CDC-Serial Output in Device Settings

1. Select the associated communication type tab.
2. Scroll to **USB Settings**.
3. Ensure that the **Enable USB CDC-Serial Results** checkbox is enabled.
4. Click **Apply** within the USB Settings.
5. Click **OK**.

### Listening Over USB CDC-Serial Connection

The process of listening over USB CDC-Serial connections is similar to the RS-232 setup outlined in the previous section.

1. After enabling USB CDC-Serial Results, navigate to Device Manager to identify the COM port associated with your USB connection.
2. Follow the instructions outlined in the RS-232 sections using the COM port in Device Manager.



## USB Settings

Configure USB settings such as enabling a HID Keyboard or adding a Keystring Delay.

### Enabling HID Keyboard

Checking this setting will enable USB-HID output. Job result/output will be streamed over a USB connection to the host PC as if the device was a keyboard. The output streams into any field with focus, such as notepad, excel, or other host-based apps.



**NOTE:** When this setting is applied, the device will automatically reboot. If USB is your sole way of communicating with the device (as opposed to via ethernet cable) and you have a job that automatically starts on startup, it may be difficult to communicate with the device if the job is running and sending output over the USB simultaneously. Ensure that you have de-selected the other options before enabling HID.

### Adding a Keystring Delay

Sometimes data is sent over USB faster than the receiving application receives them. This is commonly seen with some remote applications where latency is a factor. Compensate for this by adding a keystroke delay, where a certain pause (typically in ms) is inserted between each character so no characters (data) are missed.

## PLC Protocol

For specific details on Industrial Ethernet, EtherNet/IP, PROFINET Interface, and Modbus TCP, refer to the FS/VS Industrial Ethernet User Guide.

# Troubleshooting

This section describes potential issues that may occur while using the application and solutions that could correct the problem, such as rebooting the device and reconnecting the USB cable.

**Table 74** Troubleshooting


Problem	Solution
<b>Installation</b>	
Run as Administrator	If you receive an error when attempting to install Aurora Focus, try again by right-clicking the Aurora Focus icon on your PC, and selecting Run as Administrator.
Backward Compatibility	Aurora Focus does not connect to a device with older firmware. This may cause a break in functionality if the device is not updated.
<b>Software</b>	
The device becomes idle while configuring an inspection task.	Perform a factory reset. This can resolve issues that may occur after updating the firmware version.
<b>Device</b>	
External illumination does not turn on when running a job created with a previous firmware version.	Enable external illumination.
External illumination does not turn off when in NPN mode.	Switch back to PNP mode before powering off the device.
On FS10 devices, specific hubs cause USB interfaces (RNDIS and HID) to break upon HID keyboard re-enumeration.	Disconnect and reconnect the USB cable.
Firmware updates fail if the memory consumption on the device is currently high.	Reboot the device and upgrade.
Uninstalling the InstallShield does not always remove all of the registry entries.	Type <code>regedit</code> to access the Registry Editor on your PC, and manually delete the Zebra Aurora Focus folder under Computer \HKEY_LOCAL_MACHINE\SOFTWARE\Zebra\

## Firmware Troubleshooting

**Table 75** Firmware Troubleshooting

Problem	Solution
The firmware update procedure fails.	If the device status is set to Managed, close the device and retry.

**Figure 13** Managed Device Update Firmware Error



## License Troubleshooting

**Table 76** License Troubleshooting


Problem	Solution
Offline licenses are not recognized correctly.	<ol style="list-style-type: none"> <li>1. Deactivate the offline licenses on both devices in the Web HMI.</li> <li>2. Perform a date and time sync. Confirm that the date, timezone, and time are accurate within a minute of the current local time.</li> <li>3. Perform a factory reset on License Storage.</li> <li>4. After the device reboots, reconfirm the time information is accurate.</li> <li>5. Regenerate new offline licenses and apply them to the devices.</li> </ol>
Error x700000024 displays when attempting to apply an online or offline license.	Perform a License Storage reset on the device and try again after rebooting.

## FTP Troubleshooting

If the FTP server is not saving images correctly, it could be a result of an issue with the firewall, folder access or invalid permissions.


### Firewall Settings

If the FTP server is not receiving messages, as in the image below, review the firewall settings.



#### Invalid Folder Attributes


In cases where the FTP server application cannot write on the destination folder. Select the folder and use the **ALT+ENTER** command to open the properties window and verify that the **Read-only** checkbox is not enabled.



### Invalid Permissions

The FTP server configuration prevents certain operations. If the log of the FTP server application shows a critical file transfer error.

To create a directory and upload a file, activate all options as shown in the following figure:




## Testing the FTP Connection

Before using the smart camera, test the FTP connection using an FTP client.

This may also trigger the Windows Defender Firewall for the FTP server application. This operation can be done automatically.

Enable the FTP server for all networks.




## Configuring the Firewall

If there is no communication between the smart camera and the FTP Server application, add the FTP server application to the Windows Firewall Rules using the following procedure.


1. Open Windows Defender Firewall.

## Troubleshooting


### 2. Click Allow an app or feature ....



### 3. Click Allow another app....




4. Select the executable of the FTP server.



## Troubleshooting

5. Select all networks.



6. Click **OK** to apply the settings.

# RegEx Overview

RegEx is used to filter code to identify specific objects. This section provides details on what to look for in your code to confirm that RegEx is functioning properly, what data is constant, and what data can change. If you intend to change the data, you must provide the data type or reduce the data to a specific number of characters when possible.

For a full list of filtering commands to identify various data types, characters, and fixed positions or serial use of specific data, refer to [rexegg.com/regex-quickstart.html](http://rexegg.com/regex-quickstart.html)

## RegEx Examples

RegEx refers to a regular expression sequence of characters that specifies a pattern for the application to identify in the image. This section provides examples of common RegEx use cases and outlines the procedure to utilize them in Zebra Aurora Focus.

All five codes were read without a filter:

## RegEx Overview

The screenshot shows a software interface for barcode reading. On the left, there are several configuration options:

- Barcode String Match: A toggle switch.
- No Read String: An input field.
- Enable Barcode Quality Metrics: A checked checkbox.
- Exhaustive 2D Attempt: An unchecked checkbox.

On the right, a barcode label is displayed with the following text and barcode representations:

- (1P)P/N: CBL-USB03000-USC00
- (D)MFD: 01DEC20
- (2P)REV:
- (Q)QUANTITY: 1
- MADE IN CHINA

Below the label, a status bar shows coordinates X: 282 Y: 1193, R:109 G:109 B:109, Zoom: 81.83%, and -% Size Available. At the bottom, there is a thumbnail labeled "Filmstrip" showing a preview of the barcode label.

**View Results**

Status	Codec	Result	PPM
Good Read	CODE39	D01DEC20	1.9
Good Read	CODE39	ON	2.9
Good Read	CODE39	1PCBL-USB03000-USC00	1.2
Good Read	CODE39	Q1	2.9
Good Read	CODE39	2P	2.9

Filter (\w) for all strings that include matches any word character (equivalent to [a-zA-Z0-9\_]):

## RegEx Overview

Minimum Coverage Percentage

Barcode String Match

Select Last Decode    Regex

No Read String

Enable Barcode Quality Metrics

Exhaustive 2D Attempt

The interface shows a barcode label with the following data:

- (1P)P/N: CBL-USB03000-USC00
- (D)MFD: 01DEC20
- (2P)REV:
- (Q)QUANTITY: 1
- MADE IN CHINA

Below the label, there is a filmstrip view of the original image.

**View Results**

Status	Codec	Result	PPM
—	CODE39	0010EC20	1.9
—	CODE39	ON	2.9
—	CODE39	1PCBL-USB03000-USC00	1.2
—	CODE39	Q1	2.9
—	CODE39	2P	2.9

Filter (\d) for all images with at least one number:

## RegEx Overview

The screenshot shows a barcode reading application interface. On the left, there are configuration options: "Barcode String Match" with a toggle switch, "Select Last Decode" dropdown set to "Id", a search bar, and a checked "Regex" checkbox. Below these are "No Read String" and "Read Barcode" buttons. There are also checkboxes for "Enable Barcode Quality Metrics" and "Exhaustive 2D Attempt".

The main area displays a barcode image with several lines of text and barcodes. The text includes "(1P)P/N: CBL-USB03000-USC00", "(D)MFD: 01DEC20", "(2P)REV:", "(Q)QUANTITY: 1", and "MADE IN CHINA". A green rectangular box highlights the text area.

At the bottom, there is a "View Results" table:

Status	Codec	Result	PPM
Good Read	CODE39	001DEC20	1.9
	CODE39	(1P)P/N: CBL-USB03000-USC00	1.2
	CODE39	(Q)QUANTITY: 1	2.9
	CODE39	(2P)REV:	2.9

A "Filmstrip" section at the bottom right shows a thumbnail of the barcode image.

Filter (\d0) to all numbers that are followed by zero:

## RegEx Overview

The screenshot shows a software interface for barcode reading. On the left, there's a configuration panel with sections for "Barcode String Match" (checkboxes for "Select Last Decode" and "Regex", with "Regex" checked), "No Read String" (an empty input field), "Enable Barcode Quality Metrics" (checkbox), and "Exhaustive 2D Attempt" (checkbox). Below this is a "View Results" section with a table:

Status	Codec	Result	PPM
Good Read	CODE39	D01DEC20	1.9
Good Read	CODE39	(1P)P/N: CBL-USB03000-USC00	1.2

On the right, a large image of a barcode label is displayed. The label contains the following text and barcode representations:

- (1P)P/N: CBL-USB03000-USC00 (blue box)
- (D)MFD: 01DEC20 (blue box)
- (2P)REV: (orange box)
- (Q)QUANTITY: 1 (orange box)
- MADE IN CHINA (black text)

A green rectangular selection box highlights the entire label area. At the bottom of the interface, there are buttons for "X - Y -", "R - G - B -", "Zoom: 81.83%", and "% Size Available".

Filter (\d1) to all numbers followed by the number one:

## RegEx Overview

The screenshot shows a barcode reading application interface. On the left, there are configuration options: "Barcode String Match" (checkbox), "Select Last Decode" dropdown (set to "1st"), "Regex" checkbox (checked), "No Read String" input field, "Enable Barcode Quality Metrics" checkbox, and "Exhaustive 2D Attempt" checkbox. Below these is a "View Results" table:

Status	Codec	Result	PPM
Good Read	CODE39	D01DEC20	19

On the right, a "Read Barcode" window displays a barcode label with the following text and barcodes:

- (1P)P/N: CBL-USB03000-USC00
- (D)MFD: 01DEC20
- (2P)REV:
- (Q)QUANTITY: 1
- MADE IN CHINA

The entire "Read Barcode" window is highlighted with a green border. A vertical green line on the right edge of the window is labeled "DE Loc - 31". At the bottom of the application, there is a "Filmstrip" section showing a thumbnail of the scanned document.

Filter (\d\$) to every code with a number as its last digit:

## RegEx Overview

The screenshot shows a barcode reading application interface. On the left, there are several configuration options:

- Minimum Coverage Percentage
- Barcode String Match
- Select Last Decode    Regex
- No Read String
- Enable Barcode Quality Metrics
- Exhaustive 2D Attempt

On the right, the main area displays a barcode image with a green bounding box around it. Inside the box, the following information is shown:

- (1P)P/N: CBL-USB03000-USC00
- (D)MFD: 01DEC20
- (2P)REV:
- (Q)QUANTITY: 1
- MADE IN CHINA

Below the main display, there is a "View Results" table:

Status	Codec	Result	PPM
Good Read	CODE39	001DEC20	1.9
	CODE39	1PCBL-USB03000-USC00	1.2
	CODE39	Q1	2.9

At the bottom, there is a "Filmstrip" section showing a thumbnail of the scanned document.

Filter (^d) to get any code with a number at the beginning:

## RegEx Overview

The screenshot shows a software interface for barcode reading and analysis. On the left, there are several configuration options:

- Minimum Coverage Percentage
- Barcode String Match (with dropdown "1d" and checked "Regex")
- No Read String:
- Enable Barcode Quality Metrics
- Exhaustive 2D Attempt

On the right, the main area displays a "Read Barcode" window over a background image of a barcode label. The label contains the following text and barcodes:

- (1P)P/N: CBL-USB03000-USC00
- (D)MFD: 01DEC20
- (2P)REV:
- (Q)QUANTITY: 1
- MADE IN CHINA

A green rectangular box highlights the entire label area. Below the main window, there is a "View Results" section and a "Filmstrip" section.

**View Results**

Status	Codec	Result	PPM
Good Read	CODE39	1PCBL-USB03000-USC00	1.2
Good Read	CODE39	2P	2.9

X: 828 Y: 187 R: 181 G: 181 B: 181 Zoom: 81.82% -% Size Available

**Filmstrip**

Filter (\C) for a string that has the letter C:

## RegEx Overview

The screenshot shows a barcode reading application interface. On the left, there are configuration options including "Barcode String Match" (checkbox), "Select Last Decode" dropdown, "IC" input field, "Regex" checkbox, "No Read String" input field, "Enable Barcode Quality Metrics" checkbox, and "Exhaustive 2D Attempt" checkbox. Below these are sections for "View Results" and "Filmstrip".

**View Results:**

Status	Codec	Result	PPM
Good Read	CODE39	D01DEC20	1.9
Good Read	CODE39	CN	2.9
Good Read	CODE39	(1P)P/N: CBL-USB03000-USC00	1.2

**Filmstrip:** A preview of the scanned document showing the barcode label.

**Barcode Label Content:**

- (1P)P/N: CBL-USB03000-USC00
- (D)MFD: 01DEC20
- (2P)REV:
- (Q)QUANTITY: 1
- MADE IN CHINA

A green rectangular box highlights the entire barcode label area.

Filter [DU] by a list. This example is the letter D or U:

## RegEx Overview

The screenshot shows a barcode reading application interface. On the left, there are several configuration options: "Select Last Decode" dropdown, "Read String" input field containing "(DU)", a "RegEx" checkbox checked, "No Read String" input field, "Enable Barcode Quality Metrics" checkbox, and "Exhaustive 2D Attempt" checkbox. Below these is a "View Results" table with columns: Status, Codec, Result, PPM, and a toolbar icon. The table has two entries: one for a "CODE39" codec with result "D01DEC20" and PPM 1.9, and another for a "CODE39" codec with result "(1P)P/N: CBL-USB03000-USC00" and PPM 1.2. To the right of the table is a camera view showing a barcode sticker on a wooden surface. A green rectangular box highlights the area where the barcode is being decoded. The decoded data is displayed in a "Read Barcode" box: "(1P)P/N: CBL-USB03000-USC00", a barcode, "(D)MFD: 01DEC20", a barcode, "(2P)REV:", a barcode, "(Q)QUANTITY: 1", a barcode, and "MADE IN CHINA", a barcode. At the bottom right of the main window, there is a "Filmstrip" section showing a thumbnail of the barcode image.

Look for a specific string in the code (USB):

## RegEx Overview

The screenshot shows a barcode reading application interface. On the left, there are configuration options: "Barcode String Match" with a dropdown set to "1058" and a "Regex" checkbox checked; "No Read String" with an empty input field; "Enable Barcode Quality Metrics" with a checkbox checked; and "Exhaustive 2D Attempt" with an unchecked checkbox. Below these is a "View Results" section with a table:

Status	Codec	Result	PPM
Good Read	CODE39	1P CBL-USB03000-USC00	1.2

On the right, a grayscale image of a barcode label is displayed. A green rectangular box highlights the area where the barcode and text are read. The read data is shown in a "Read Barcode" window:

- (1P)P/N: CBL-USB03000-USC00
- (D)MFD: 01DEC20
- (2P)REV:
- (Q)QUANTITY: 1
- MADE IN CHINA

Below the main interface, there is a "Filmstrip" section showing a thumbnail of the scanned document.

Look for any data filter (\*):

## RegEx Overview

Barcode String Match

Select Last Decode  /   Regex

No Read String

Enable Barcode Quality Metrics

Exhaustive 2D Attempt

**View Results**

Status	Codec	Result	PPM
Good Read	CODE39	001DEC20	1.9
	CODE39	CN	2.9
	CODE39	(1P)P/N: CBL-USB03000-USC00	1.2
	CODE39	Q1	2.9
	CODE39	2P	2.9

**Read Barcode**

(1P)P/N: CBL-USB03000-USC00

(D)MFD: 01DEC20


(2P)REV:

(Q)QUANTITY: 1

MADE IN CHINA

X: 663 Y: 290 R: 172 G: 172 B: 172 Zoom: 81.83% -% Size Available

Filmstrip 



Look for two specific prefix data filters (^78|<sup>S2</sup>):

- ^ sets the anchor to the first char or string in the code
- | is the logical OR


## RegEx Overview



Look for a minimum code length (.{11}):

- . allows any sign
- {11} is the number of signs needed for the result to be true. All orange codes are shorter than 11 signs.

## RegEx Overview



Look for a code length range (`^{3,12}$`):


- “`^`” anchor at the start of the code
- “`$`” anchor at the end of the code

Specify the desired output by providing the information inside the brackets:

- `.` allows any sign.
- `{3,12}` the first number is the minimum number of signs needed to be true, and the second number represents the maximum

All codes with two or fewer signs are ignored, such as the TW on top of the PDF417 code. Codes with a length of 13 or more signs are also ignored.

## RegEx Overview



Look for a code length range and an identifier (^78.[3,12]\$):


- ^ anchor at the start of the code.
- \$ anchor at the end of the code.

Specify the desired output by providing the information inside the brackets:

- . allows any sign.
- **\$78** is the identifier needs to be at the beginning of the string.
- **{3,12}** the first number is the minimum number of signs needed to be true, and the second number represents the maximum.

All codes with two or fewer signs are ignored, such as the TW on top of the PDF417 code. Codes with a length of 13 or more signs are ignored as well.

# RegEx Overview



Look for anything else, then look for a code length range and an identifier (^(?![78.{3,12}\$).) with inverse logic:


- `^` allows any sign.
  - `$` is the identifier needs to be at the beginning of the string.

Specify the desired output by providing the information inside the brackets.

- . allows any sign.
  - **78** is the identifier needs to be at the beginning of the string.
  - {3,12} the first number is the minimum number of signs needed to be true, and the second number represents the maximum

Use the syntax `^(?![pattern])`, where the pattern is the pattern for negative pattern matching:


## RegEx Overview



Look for a numeric code with a length of 13 and starts with a four or a numeric code with a length of 20 that starts with a 0 ( $^4\d{12}|^0\d{19}$ ):

- ^ anchor at the start of code ^4 means the specific number 4 needs to be the first number in the code.
- \d allows numbers only (0-9).
- {12} number of signs needed to be true, and the second number represents the maximum. It's one less than the code length because the full string consists of the fixed first number + 12 numbers.
- | is the logical OR


## RegEx Overview



Find the serial number field of the FIS/MV Zebra Boxes (^S\d{13}):

- ^
- \d allows numbers only (0-9).
- {13}

## RegEx Overview



# Using Zebra Easy Text Interface

Zebra Easy Text Interface (ZETI) is a set of commands used to retrieve information from the device over telnet Port 23 by default.


## Enabling Telnet Connections

Use a Telnet connection with a PC-based terminal over ZETI with a device.

1. Press Win + R to open Run.
2. Search for the Control Panel and click **OK**
3. Search for the Control Panel and click **Programs and Features**
4. Using the left panel, click **Turn Windows Features On or Off**
5. Enable telnet client Windows features dialog.
6. In the Windows Features dialog, scroll down and select **Telnet Client**.

You can also use a terminal client such as Teraterm or Putty. The following image displays the procedure using Putty.

## Using Zebra Easy Text Interface



After opening the session, type the command name and press **Enter**.

```
ASCII Connected
help
*****
Supported Commands
*****
trigger
getimage
getquantity
getcodes
getdecodes
internalight
gain
focus
exposure
autoexposure
autofocus
aimer
getimagersettings
```

## ZETI Commands

Use ZETI commands to make changes on the device and retrieve result data.

## autotune

Use the autotune command to adjust the focus settings of the device based on the specified parameter.

**Table 77** autotune

Command	Short	Parameter	Data	Range	Example
autotune	at	.brightness .focus .method	true/false true/false barcode/ dpm	-	autotune .brightness true .focus true .method barcode command: autotune,ok
autotune	at	.brightness .focus .method	true/false true/false barcode/ dpm	-	autotune .brightness false .focus true .method barcode command: autotune,ok
autotune	at	.brightness .focus .method	true/false true/false barcode/ dpm	-	autotune .brightness true .focus false .method barcode command: autotune,ok
autotune	at	.brightness .focus .method	true/false true/false barcode/ dpm	-	autotune .brightness false .focus false .method barcode command: autotune,ok
autotune	at	.brightness .focus .method	true/false true/false barcode/ dpm	-	autotune .brightness true .focus true .method dpm command: autotune,ok
autotune	at	.brightness .focus .method	true/false true/false barcode/ dpm	-	autotune .brightness true .focus false .method dpm command: autotune,ok
autotune	at	.brightness .focus .method	true/false true/false barcode/ dpm	-	autotune .brightness false .focus true .method dpm command: autotune,ok
autotune	at	.brightness .focus .method	true/false true/false barcode/ dpm	-	autotune .brightness false .focus false .method dpm command: autotune,ok

## backuprestore

backup

Use the backuprestore command to backup a file by passing a backup parameter as CONFIG and the action as 1.

**Table 78** backup

Command	Short	Parameter	Data	Range	Example
backuprestore	br	backup	CONFIG, JOB_DATA, ALL	-	br .backup CONFIG .action 1 command:br,ok
backuprestore	br	action	1		br .backup CONFIG .action 1 command:br,ok

restore

Use the backuprestore command to restore a file to the device.

**Table 79** restore

Command	Short	Parameter	Data	Range	Example
backuprestore	br	action. path	0 base64_data	-	br .action 0 .path base64_data command:br,ok



**NOTE:** Use a Python script to restore the file to the device.

## deletejob

Use the deletejob command to delete a job on the device. Provide the job number as an argument

**Table 80** deletejob

Command	Short	Parameter	Data	Range	Example
deletejob	dj	-	Number	-	deletejob 1 command:deletejob,ok

## dwload

Use the dwload command to upload the dwx configuration file to the host.



**NOTE:** Use a python script to transfer the .dwx file to the device.

**Table 81** dwload

Command	Short	Parameter	Range	Example
dwload	dwload	-	-	dwsideload base64_data command: dwsideload,ok

## dwsideload

Use the dwsideload command to upload the dwx configuration file to the device.



**NOTE:** Use a python script to transfer the .dwx file to the device.

**Table 82** dwsideload

Command	Short	Parameter	Range	Example
dwsideload	dws	file.dwx (base64 format)	-	python dwsideload file.dwx <CR><LF> command: dwsideload,ok

## exposure

Use the exposure command to set the exposure value by passing an argument.

**Table 83** exposure

Command	Short	Parameter	Range	Example
exposure	ex	-	0.05 to 14	exposure 1 command: exposure,ok

## factoryreset

Use the factoryreset command to return the device to its default state.

**Table 84** factoryreset

Command	Short	Parameter	Data	Range	Example
factoryreset	fr	device_settings	-	-	factoryreset device_settings command: factoryreset,ok

## firmwareupdate

Use the firmwareupdate command to update the device firmware.



**NOTE:** The firmwareupdate command is not supported on FS10 devices.

**Table 85** firmwareupdate

Command	Short	Parameter	Data	Range	Example
firmwareupdate	fwu	-	ftp server username ftp server password ftp server url firmware name (scnplg2) force update keepfile	-	fwu user pass 172.16.35.58 abc.scnplg2 1 command:fwu,ok

## focus

Use the `focus` command to set the focus value by passing an argument.

**Table 86** focus

Command	Short	Parameter	Range	Example
focus	fo	-	-6 to 8	focus 7 command: focus,ok

## gain

Use the `gain` command to set the gain value by passing an argument.

**Table 87** gain

Command	Short	Parameter	Range	Example
gain	ga	-	0 to 100	gain 2 command: gain,ok

## getcodes

Use the `getcodes` command to retrieve the code and value of the last operation.

**Table 88** getcodes

Command	Short	Parameter	Data	Range	Example
getcodes	gc	-	-	-	getcodes command: getcodes,ok

## getdecodes

Use the `getdecodes` command to retrieve the decoded value of the last operation.

**Table 89** getdecodes

Command	Short	Parameter	Data	Range	Example
getdecodes	gd	-	-	-	getdecodes command: getdecodes,ok

## getimage

Use the `getimage` command to capture a new image that is not counted as a trigger and download the image as a base64 buffer. The buffer contains a BMP file.

**Table 90** getimage

Command	Short	Parameter	Range	Example
getimage	gi	Base64	-	getimage command: getimage,ok 3073440 /9j/4AAQSkZJRgABAQAAAQABAAAD

## getimagersettings

Use the `getimagersettings` command to retrieve the value of all the parameters mentioned in the following table.

**Table 91** getimagersettings

Command	Short	Parameter	Range	Example
getimagersettings	gis	aimer	-	getimagersettings aimer command: getimagersettings,ok
getimagersettings	gis	external_light	-	getimagersettings external_light command: getimagersettings,ok
getimagersettings	gis	imager	-	getimagersettings imager command: getimagersettings,ok
getimagersettings	gis	internal_light	-	getimagersettings Internal_light command: getimagersettings,ok
getimagersettings	gis	gain	-	getimagersettings gain command: getimagersettings,ok
getimagersettings	gis	focus	-	getimagersettings focus command: getimagersettings,ok

**Table 91** getimageresettings (Continued)

Command	Short	Parameter	Range	Example
getimageresettings	gis	exposure	-	getimageresettings exposure command: getimageresettings,ok
getimageresettings	gis	autoexposure	-	getimageresettings autoexposure command: getimageresettings,ok
getimageresettings	gis	autofocus	-	getimageresettings autofocus command: getimageresettings,ok

## getgpiostatus

Use the `getgpiostatus` command to get the value of the requested pin by passing a pin number as the argument.

**Table 92** getgpiostatus

Command	Short	Parameter	Data	Range	Example
getgpiostatus	gst	Number	Pin number	-	getgpiostatus 1 command: getgpiostatus,ok {response}

## getgpiosetting

Use the `getgpiosetting` command to update the device firmware.

**Table 93** getgpiosetting

Command	Short	Parameter	Range	Example
getgpiosetting	ggs	Pin number, mode	-	ggs .pin 1.mode command: ggs,ok {response}
getgpiosetting	ggs	Pin number, strobe	-	ggs .pin 1.strobe command: ggs,ok {response}
getgpiosetting	ggs	Pin number, reset	-	ggs .pin 1.reset command: ggs,ok {response}
getgpiosetting	ggs	Pin number, edge	-	ggs .pin 1.edge command: ggs,ok {response}

**Table 93** getgpiosetting (Continued)

Command	Short	Parameter	Range	Example
getgpiosetting	ggs	Pin number, debounce	-	ggs .pin 1.debounce command:ggs,ok {response}
getgpiosetting	ggs	Pin number, delay	-	ggs .pin 1.delay command:ggs,ok {response}
getgpiosetting	ggs	Pin number, pulselength	-	ggs .pin 1.pulselength command:ggs,ok {response}

## getjoblist

Use the `getjoblist` command to retrieve the list of all jobs loaded on the device.

**Table 94** getjoblist

Command	Short	Parameter	Data	Range	Example
getjoblist	gjl	-	-	-	getjoblist command: getjoblist,ok

## getlogfiles

Use the `getlogfiles` command to retrieve device or perfetto logs.

### Device Logs

Generate a `log.tar` and retrieve the tar file.

**Table 95** Device Logs

Command	Short	Parameter	Range	Example
getlogfiles	glf	devicelogs	-	getlogfiles devicelogs command: getlogfiles,ok

### Perfetto Logs

Use a python script to retrieve the latest Perfetto logs.

**Table 96** Perfetto Logs

Command	Short	Parameter	Range	Example
getlogfiles	glf	Number	1-10	getlogfiles 10 command:getlogfiles,ok

## getquantity

Use the `getquantity` command to retrieve the number of codes of the last operation.

**Table 97** getquantity

Command	Short	Parameter	Data	Range	Example
getquantity	gq	-	-	-	getquantity command: getquantity,ok

## getresultimage

Use the `getresultimage` command to download the last inspected image as a base64 buffer. The resulting image is a JPG file.

**Table 98** getresultimage

Command	Short	Parameter	Data	Range	Example
getresultimage	gri	-	Base64	-	getresultimage command: getresultimage,ok 90326 /9j/4AAQSkZJRgABAQAAAQABAAAD

## help

Use the `help` command to return all supported ZETI commands.

**Table 99** help

Command	Short	Parameter	Data	Range	Example
help	he	None	-	-	help Supported Commands trigger getimage getquantity ... list of all supported commands

## internallight

Use the `internallight` command to enable or disable the internal light feature by passing On or Off as an argument.

**Table 100** internallight

Command	Short	Parameter	Data	Range	Example
internallight	il	-	on/off	-	internallight on command: internallight,ok

## loadjob

Use the `loadjob` command to load the job passing slot number as an argument to ensure that the required job is loaded

**Table 101** loadjob

Command	Short	Parameter	Data	Range	Example
loadjob	lj	-	Number	-	loadjob command:loadjob,ok

## protocolconfig

Use the `protocolconfig` command to set global parameters.



**NOTE:** Logs are not recorded on Telnet if `.echo` is off while using `protocolconfig`.

**Table 102** protocolconfig

Command	Short	Parameter	Data	Range	Example
protocolconfig	pc	<code>.echo</code>	on/off	-	protocolconfig <code>.echo</code> off command:protocolconfig,ok

## reboot

Use the `reboot` command to reboot the device.

**Table 103** reboot

Command	Short	Parameter	Data	Range	Example
reboot	re	None	-	-	reboot command:reboot,ok

## setgpiosetting

Use the `setgpiosetting` command to retrieve the attribute values of a pin.

**Table 104** setgpiosetting

Command	Short	Parameter	Range	Example
setgpiosetting	sgs	Pin number, mode, Number	-	sgs .pin 1.mode 0 command:sgs,ok
setgpiosetting	sgs	Pin number, reset, Number	-	sgs .pin 1.reset 0 command:sgs,ok
setgpiosetting	sgs	Pin number, strobe, Number	-	sgs .pin 1.strobe 0 command:sgs,ok
setgpiosetting	sgs	Pin number, edge, Number	-	sgs .pin 1.edge 0 command:sgs,ok
setgpiosetting	sgs	Pin number, debounce, Number	-	sgs .pin 1.debounce 0 command:sgs,ok
setgpiosetting	sgs	Pin number, delay, Number	-	sgs .pin 1.delay 0 command:sgs,ok
setgpiosetting	sgs	Pin number, pulselwidth, Number	-	sgs .pin 1.mode pulselwidth 0 command:sgs,ok

## setgpiostatus

Use the `setgpiostatus` command to set the value for the required pin by passing a pin number as the first argument and the value as the second argument.

**Table 105** setgpiostatus

Command	Short	Parameter	Data	Range	Example
setgpiostatus	sst	Number, Number	Pin number, value	-	setgpiostatus 1 0 command:setgpiostatus,ok

## trigger

Use the trigger command to trigger a job on a specified slot by passing the required job number as an argument. The withresult parameter gives the resulting JSON of the last result as a response after the trigger.

**Table 106** trigger

Command	Short	Parameter	Data	Range	Example
trigger	tr	withresult	Number	-	trigger command: trigger,ok trigger withresult command: trigger,ok

- getjobdata(gjd) – Get the data from specified job.
- setjobdata(sjd) – Set the data from specified job.

getjobdata .jobData.trigger.mode .slot 3

Settings related to jobData.trigger are configured using get/setjobdata with the sub parameters displayed in the following table:

**Table 107** trigger

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. trigger .jt	mode	NONE SINGLE_SHOT LEVEL BURST PERIODIC_SINGLE_SHOT CONTINUOUS PRESENTATION	gjd .jt.mode .slot 3 command: gjd,ok {response} sjd .jt.mode CONTINUOUS .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger .jt	start_criteria	GPIO DEVICE SERIAL PLC TCP_IP AUTO TEST_TRIGGER	gjd .jt.start_criteria .slot 3 command: gjd,ok {response} sjd .jt.start_criteria AUTO .slot 3 command: sjd,ok

**Table 107** trigger (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. trigger .jt	end_criteria	GPIO DEVICE SERIAL PLC TCP_IP AUTO TEST_TRIGGER	gjd.jt.end_criteria.slot 3 command: gjd,ok {response} sjd.jt.end_criteria AUTO .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger .jt	show_image	true/false	gjd.jt.show_image.slot 3 command: gjd,ok {response} sjd.jt.show_image true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger .jt	no_read _same_ barcode	Int	gjd.jt.no_read_same_barcode.slot 3 command: gjd,ok {response} sjd.jt.no_read_same_barcode 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger .jt	reset_dnr _on_trigger	true/false	gjd.jt.reset_dnr_on_trigger.slot 3 command: gjd,ok {response} sjd.jt.reset_dnr_on_trigger true .slot 3 command: sjd,ok

getjobdata.jobData.trigger.trigger\_settings.same\_barcode\_timeout.slot 3

Settings related to jobData.trigger.trigger\_settings are configured using get/setjobdata with the sub-parameters displayed in the following table

**Table 108** trigger\_settings

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	same_barcode _timeout	Number (0-500 ms)	gjd.jts.same_barcode_timeout .slot 3 command: gjd,ok {response} sjd.jts.same_barcode_timeout 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	job_interval	Number (0-60000 ms)	gjd.jts.job_interval .slot 3 command: gjd,ok {response} sjd.jts.job_interval 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	burst_count	Number (1-100)	gjd.jts.burst_mode .slot 3 command: gjd,ok {response} sjd.jts.burst_count 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	presentation_ sensitivity	Number	gjd.jts.presentation_sensitivity .slot 3 command: gjd,ok {response} sjd.jts.presentation_sensitivity 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	decode_ failure_timeout	Number (0-60000 ms)	gjd.jts.decode_failure_timeout .slot 3 command: gjd,ok {response} sjd.jts.decode_failure_timeout 1 .slot 3 command: sjd,ok

**Table 108** trigger\_settings (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	active_level .	LOW HIGH	gjd.jts.active_level .slot 3 command: gjd,ok {response} sjd.jts.active_level 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	fast_hw _trigger_ enabled	true/false	gjd.jts.fast_hw_trigger_enabled .slot 3 command: gjd,ok {response} sjd.jts.fast_hw_trigger_enabled true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	read_multiple _barcode	true/false	gjd.jts.read_multiple_barcodes .slot 3 command: gjd,ok {response} sjd.jts.read_multiple_barcodes true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	send _aggregate _level_assert_ data	true/false	gjd.jts.send_aggregate_level_assert_data .slot 3 command: gjd,ok {response} sjd.jtssend_aggregate_level_assert_data true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	disable_active _job_timeout	true/false	gjd.jts.disable_active_job_timeout .slot 3 command: gjd,ok {response} sjd.jts.disable_active_job_timeout true .slot 3 command: sjd,ok

**Table 108** trigger\_settings (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. trigger trigger_settings .jts	same_data _timeout _must_leave _fov	true/false	gjd.jts. same_data_timeout_must_leave_fov .slot 3 command: gjd,ok {response} sjd.jts. same_data_timeout_must_leave_fov true .slot 3 command: sjd,ok

**meta**

```
getjobdata .jobData.meta.description .slot 3
```

Settings related to jobData.meta are configured using the get/setjobdata with sub parameters displayed in this table:

**Table 109** meta

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. meta .jm	description	String	gjd.jm.description .slot 3 command: gjd,ok {response} sjd.jm.description String .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. meta .jm	device	String	gjd.jm.device .slot 3 command: gjd,ok {response} sjd.jm.device String .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. meta .jm	filePath	NullString	gjd.jm.filePath .slot 3 command: gjd,ok {response} sjd.jm.filePath String .slot 3 command: sjd,ok

**Table 109** meta (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. meta .jm	title	String	gjd.jm.title.slot 3 command: gjd,ok {response} sjd.jm.title String .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. meta .jm	zoom_level	Number	gjd.jm.zoom_level.slot 3 command: gjd,ok {response} sjd.jm.zoom_level String .slot 3 command: sjd,ok

### imager setups

getjobdata .jobData.imager\_setups.aimer

Settings related to jobData.image\_setups are configured using the getjobdata/setjobdata with the sub-parameters displayed in the following table:

**Table 110** imager\_setups

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. imager_setups .ji	aimer	true/false	gjd.ji.0.aimer.slot 3 command: gjd,ok {response} sjd.ji.0.aimer.true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	imager .auto_exposure	true/false	gjd.ji.0.imager.auto_exposure.slot 3 command: gjd,ok {response} sjd.ji.0.imager.auto_exposure .slot 3 command: sjd,ok

**Table 110** imager\_setups (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	.jobData. imager_setups .ji	bank	Number	gjd.ji.0.bank.slot 3 command: gjd,ok {response} sjd.ji.0.bank true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	external_light .enabled	true/false	gjd.ji.0.external_light.enabled.slot 3 command: gjd,ok {response} sjd.ji.0.external_light.enabled true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	external_light .intensity	Number	gjd.ji.0.external_light.intensity.slot 3 command: gjd,ok {response} sjd.ji.0.external_light.intensity 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	internal_light .color	WHITE BLUE RED INFRARED GREEN YELLOW DPM	gjd.ji.0.internal_light.color.slot 3 command: gjd,ok {response} sjd.ji.0.internal_light.color true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	imager auto_focus	true/false	gjd.ji.0.imager.auto_focus.slot 3 command: gjd,ok {response} sjd.ji.0.imager.auto_focus true .slot 3 command: sjd,ok

**Table 110** imager\_setups (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	.jobData. imager_setups .ji	imager.exposure	Number (0.5 to 14)	gjd.ji.0.imager.exposure.slot 3 command: gjd,ok {response} sjd.ji.0.imager.exposure 0.6 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	imager .gain	Number (0 to 100)	gjd.ji.0.imager.gain.slot 3 command: gjd,ok {response} sjd.ji.0.imager.gain 2 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	imager .focus	Number (-7 to +7)	gjd.ji.0.imager.focus.slot 3 command: gjd,ok {response} sjd.ji.0.imager.focus 3 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	imager .long_exposure	Number (1 to 10)	gjd.ji.0.imager.long_exposure.slot 3 command: gjd,ok {response} sjd.ji.0.imager.long_exposure 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	internal_light .enabled	true/false	gjd.ji.0.internal_light.enabled.slot 3 command: gjd,ok {response} sjd.ji.0.internal_light.enabled true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	internal_light .intensity	Number	gjd.ji.0.internal_light.intensity.slot 3 command: gjd,ok {response} sjd.ji.0.internal_light.intensity 1 .slot 3 command: sjd,ok

**Table 110** imager\_setups (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	.jobData. imager_setups .ji	internal_light .max_duration	Number	gjd.ji.0.internal_light.max_duration.slot 3 command: gjd,ok {response} sjd.ji.0.internal_light.max_duration 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	internal_light .regions.bottom	true/false	gjd.ji.0.internal_light.regions.bottom.slot 3 command: gjd,ok {response} sjd.ji.0.internal_light.regions.bottom true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	internal_light .regions.top	true/false	gjd.ji.0.internal_light.regions.top.slot 3 command: gjd,ok {response} sjd.ji.0.internal_light.regions.top true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	internal_light .regions.right	true/false	gjd.ji.0.internal_light.regions.right.slot 3 command: gjd,ok {response} sjd.ji.0.internal_light.regions.right true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	internal_light .regions.left	true/false	gjd.ji.0.internal_light.regions.left.slot 3 command: gjd,ok {response} sjd.ji.0.internal_light.regions.left true .slot 3 command: sjd,ok

**Table 110** imager\_setups (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	.jobData. imager_setups .ji	internal_light .torch_mode	true/false	gjd.ji.0.internal_light.torch_mode.slot 3 command: gjd,ok {response} sjd.ji.0.internal_light.torch_mode true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	name	String	gjd.ji.0.name.slot 3 command: gjd,ok {response} sjd.ji.0.name STRING .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	auto_tune .brightness	true/false	gjd.ji.0.auto_tune.brightness.slot 3 command: gjd,ok {response} sjd.ji.0.auto_tune.brightness true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	auto_tune .max_exposure	Number	gjd.ji.0.auto_tune.max_exposure.slot 3 command: gjd,ok {response} sjd.ji.0.auto_tune.max_exposure 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	auto_tune .tune_focus	true/false	gjd.ji.0.auto_tune.tune_focus.slot 3 command: gjd,ok {response} sjd.ji.0.auto_tune.tune_focus true .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. imager_setups .ji	auto_tune .method	String	gjd.ji.0.auto_tune.method.slot 3 command: gjd,ok {response} sjd.ji.0.auto_tune.method STRING .slot 3 command: sjd,ok

## industrial ethernet

getjobdata .jobData.industrial\_ethernet.input.mode .slot 3

Settings related to jobData.industrial\_ethernet are configured using the getjobdata/setjobdata with the sub-parameters in the following table:

**Table 111** industrial\_ethernet

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	input .mode	ENTRY RAW	gjd.jie.input.mode .slot 3 command: gjd,ok {response} sjd.jt.input.mode RAW . slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	input .switch_bits	true/false	gjd.jie.input.switch_bits .slot command: gjd,ok {response} sjd.jie.input.switch_bits true . slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	input.config .data_type	String	gjd.jie.input.config.0.data_type .slot 3 command: gjd,ok {response} sjd.jie.input.config.0.data_type STRING .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	input.config .field	String	gjd.jie.input.config.0.field .slot 3 command: gjd,ok {response} sjd.jie.input.config.0.field STRING .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	input.config .field_size	Number	gjd.jie.input.config.0.field_size .slot 3 command: gjd,ok {response} sjd.jie.input.config.0.field_size 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	input.config .isBase64	true/false	gjd.jie.input.config.0..isBase64 .slot 3 command: gjd,ok {response} sjd.jie.input.config.0.isBase64 true .slot 3 command: sjd,ok

**Table 111** industrial\_ethernet (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	input.config .order	Number	gjd.jie.input.config.0.order.slot 3 command: gjd,ok {response} sjd.jie.input.config.0.order 1.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	input.config .type	String	gjd.jie.input.config.0.type.slot 3 command: gjd,ok {response} sjd.jie.input.config.0.type String.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	input.config .type_id	String	gjd.jie.input.config.0.type_id.slot 3 command: gjd,ok {response} sjd.jie.input.config.0.type_id String.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output .mode	ENTRY RAW	gjd.jie.output.mode.slot 3 command: gjd,ok {response} sjd.jie.output.mode RAW.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output .switch_bits	true/false	gjd.jie.output.switch_bits.slot 3 command: gjd,ok {response} sjd.jie.output.switch_bits true.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output.config .data_type	String	gjd.jie.output.config.0.data_type.slot 3 command: gjd,ok {response} sjd.jie.output.config.0.data_type String.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output.config .field	String	gjd.jie.output.config.0.field.slot 3 command: gjd,ok {response} sjd.jie.output.config.0.field String.slot 3 command: sjd,ok

**Table 111** industrial\_ethernet (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output.config .field_size	Number	gjd.jie.output.config.0.field_size.slot 3 command: gjd,ok {response} sjd.jie.output.config..0.field_size 1.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output.config .isBase64	true/false	gjd.jie.output.config.0.isBase64.slot 3 command: gjd,ok {response} sjd.jie.output.config.0.isBase64 true.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output.config .order	Number	gjd.jie.output.config.0.order.slot 3 command: gjd,ok {response} sjd.jie.output.config.0.order 1.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output.config .type	String	gjd.jie.output.config.0.type.slot 3 command: gjd,ok {response} sjd.jie.output.config.0.type String.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output.config .type_id	String	gjd.jie.output.config.0.type_id.slot 3 command: gjd,ok {response} sjd.jie.output.config.0.type_id String.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output.config .default.codec		gjd.jie.output.config.0.default.codec.slot 3 command: gjd,ok {response} sjd.jie.output.config.0.default.codec 1.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output.config .default.ppm		gjd.jie.output.config.0.default.ppm.slot 3 command: gjd,ok {response} sjd.jie.output.0.config.default.ppm 1.slot 3 command: sjd,ok

**Table 111** industrial\_ethernet (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. industrial_ ethernet .jie	output.config .default.quality_ score		gjd.jie.output.config.0.default.quality_score .slot 3 command: gjd,ok {response} sjd.jie.output.config.0.default.quality_score 1 .slot 3 command: sjd,ok

**save options**

```
getjobdata.jobData.save_options.conditions.slot 3
```

Settings related to jobData.save\_options are configured using getjobdata/setjobdata with the sub parameters displayed in the following table:

**Table 112** save options

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.jobData. save_options .jt	conditions	NO_READ GOOD_READ	gjd.js.0.conditions.slot 3 command: gjd,ok {response} sjd.js.0.conditions NO_READ.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. save_options .jt	destination	ON_DEVICE FTP SFTP	gjd.js.0.destination.slot 3 command: gjd,ok {response} sjd.js.0.destination ON_DEVICE.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. save_options .jt	enabled	true/false	gjd.js.0.enabled.slot 3 command: gjd,ok {response} sjd.js.0.enabled true.slot 3 command: sjd,ok

**Table 112** save options (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	.jobData. save_options .jt	file_prefix	String	gjd.js.0.file_prefix.slot 3 command: gjd,ok {response} sjd.js.0.file_prefix ZEB.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. save_options .jt	file_suffix	DATETIME INDEX	gjd.js.0.file_suffix.slot 3 command: gjd,ok {response} sjd.js.0.file_suffix INDEX.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. save_options .jt	format	BMP JPG	gjd.js.0.format.slot 3 command: gjd,ok {response} sjd.js.0.format JPG.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. save_options .jt	id	Number	gjd.js.0.id.slot 3 command: gjd,ok {response} sjd.js.0.id 2.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. save_options .jt	remote_settings	ftp/sftp server settings	gjd.js.0.remote_settings.slot 3 command: gjd,ok {response} sjd.js.0.remote_settings {ftp server settings}.slot 3 command: sjd,ok
getjobdata setjobdata	.jobData. save_options .jt	size	FULL QUARTER ONE_SIXTEENTH ONE_SIXTY_FOURTH	gjd.js.0.size.slot 3 command: gjd,ok {response} sjd.js.0.size FULL.slot 3 command: sjd,ok

**Table 112** save options (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata	.jobData.	trigger	String	gjd.js.0.trigger .slot 3
setjobdata	save_options .jt			command: gjd,ok {response} sjd.js.0.trigger IMAGES_PER_RESULT .slot 3 command: sjd,ok

### barcode configuration

getjobdata.job\_run\_data.graph.nodes.BARCODE.configuration.type .slot 2

Settings related to job\_run\_data.graph.nodes.BARCODE.configuration are configured using getjobdata/setjobdata with the sub-parameters in the following table:

**Table 113** BARCODE.configuration

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	roi.data .height	Number	gjd.jrc.roi.data.height .slot 3 command: gjd,ok {response} sjd.jrc.roi.data.height 3 .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	roi.data .rotation	Number	gjd.jrc.roi.data.rotation .slot 3 command: gjd,ok {response} sjd.jrc.roi.data.rotation 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	roi.data .width	Number	gjd.jrc.roi.data.width .slot 3 command: gjd,ok {response} sjd.jrc.roi.data.width 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	roi.data.x	Number	gjd.jrc.roi.data.x .slot 3 command: gjd,ok {response} sjd.jrc.roi.data.x 1 .slot 3 command: sjd,ok

**Table 113** BARCODE.configuration (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	roi.data.y	Number	gjd.jrc.roi.data.y.slot 3 command: gjd,ok {response} sjd.jrc.roi.data.y 1.slot 3 command: sjd,ok

**Table 113** BARCODE.configuration (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrd	match_string .all (update all similiar tools in a job) .base64 (when base64 encoded string to be given) .friendly_name (update string should be within single quotes based on friendly name of a tool)	-	<p>string should be within single quotes sjd.jrd.match_string 'string to be matched'</p> <p>To update all match strings of ocr tools in a job sjd.jrd.match_string 'string to be matched' .all</p> <p><b>To update all match strings of ocr tools in a job of a given slot number</b> sjd.jrd.match_string 'string to be matched' .all .slot 19</p> <p><b>To update match string ( base64 encoded) to a tool , it should not be within any quotes</b> sjd.jrd.match_string aGVsbG8gdBiYXNlNg .base64</p> <p><b>To update match string (base64 encoded) to all tools</b> sjd.jrd.match_string aGVsbG8gdBiYXNlNg .base64 .all</p> <p><b>To update match string (base64 encoded) to all tools with a given slot number</b> sjd.jrd.match_string aGVsbG8gdBiYXNlNg .base64 .all .slot 19</p> <p><b>To update match string to a particular tool based on friendly name</b> sjd.jrd.match_string 'this is to change only ocr2' .friendly_name 'ocr2'</p> <p><b>To update match string to a particular tool based on friendly name to a particular job of given slot number</b> sjd.jrd.match_string 'this is to change only ocr2' .friendly_name 'ocr2'.slot 19</p> <p><b>To update base64 encoded match string</b> sjd.jrd.match_string aGVsbG8gdBiYXcdefergtrrytthtyjNUTyvvylNg .base64 .friendly_name 'ocr1'</p> <p><b>To update base64 encoded match string slot based</b> sjd.jrd.match_string aGVsbG8gdBiYXcdefergtrrytthtyjNUTyvvylNg .base64 .friendly_name 'ocr2' .slot 19</p> <p>command: sjd,ok</p>

**Table 113** BARCODE.configuration (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	roi.type	RECTANGLE POLYGON CIRCLE ANNULUS	gjd.jrc.roi.type.slot 3 command: gjd,ok {response} sjd.jrc.roi.type ANNULUS.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	source _images .type	ACQUISITION TOOL	gjd.jrc.source_images.type.slot 3 command: gjd,ok {response} sjd.jrc.source_images.type TOOL.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	source _images .value	String	gjd.jrc.source_images.value.slot 3 command: gjd,ok {response} sjd.jrc.source_images.value TOOL.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	Enabled	true/false	gjd.jrc.enabled.slot 3 command: gjd,ok {response} sjd.jrc.enabled true.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	Invert	true/false	gjd.jrc.invert.slot 3 command: gjd,ok {response} sjd.jrc.invert true.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	data _formatting	COMPLEX	gjd.jrc.data_formatting.slot 3 command: gjd,ok {response} sjd.jrc.data_formatting COMPLEX.slot 3 command: sjd,ok

**Table 113** BARCODE.configuration (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	localData .friendly _name	String	gjd.jrc.localData.friendly_name.slot 3 command: gjd,ok {response} sjd.jrc.localData.friendly_name 'Reads'.slot 3 command: sjd,ok 'Reads'
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration .jrc	localData .barcode _data_ formatting _mode	STANDARD TRAILING_TAB ADVANCED TRAILING_LINE _BREAK	gjd.jrc.localData. barcode_data_formatting_mode.slot 3 command: gjd,ok {response} sjd.jrc.localData. barcode_data_formatting_mode STANDARD.slot 3 command: sjd,ok

## data formatting

```
getjobdata.job_run_data.graph.nodes.BARCODE.configuration.barcode_data_formatting  
.all_symbologies.data_types.encoding.slot 2
```

Settings related to  
job\_run\_data.graph.nodes.BARCODE.configuration.barcode\_data\_formatting.all\_symbologies are  
configured using the getjobdata/setjobdata with the sub parameters displayed in the following table:

**Table 114** barcode\_data\_formatting.all\_symbologies

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .all_symbologies .jra	data_type _delimiter	NONE SPACE COMMA TAB LINEBREAK	gjd.jra.data_type_delimiter.slot 3 command: gjd,ok {response} sjd.jra.data_type_delimiter TAB ZEB . slot 3 command: sjd,ok

**Table 114** barcode\_data\_formatting .all\_symbologies (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .all_symbologies .jra	data_types. encoding	TEXT BASE64	gjd.jra.data_types.encoding.slot 3 command: gjd,ok {response} sjd.jra.data_types.encoding TEXT . slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .all_symbologies .jra	data_types .type	DECODED_STRING PPM SUBDECODED _STRING ANGLE SYMOLOGY CENTER_X CENTER_Y	gjd.jra.data_types_type.slot 3 command: gjd,ok {response} sjd.jra.data_types_type ANGLE.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .all_symbologies .jra	end_delimiter	NONE SPACE COMMA TAB LINEBREAK	gjd.jra.end_delmiter.slot 3 command: gjd,ok {response} sjd.jra.end_delimiter TAB.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .all_symbologies .jra	Prefix	String	gjd.jra.prefix.slot 3 command: gjd,ok {response} sjd.jra.prefix STRING.slot 3 command: sjd,ok

**Table 114** barcode\_data\_formatting .all\_symbologies (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .all_symbologies .jra	Suffix	String	gjd.jra.suffix.slot 3 command: gjd,ok {response} sjd.jra.suffix STRING . slot 3 command: sjd,ok

**manycode**

```
getjobdata .
job_run_data.graph.nodes.BARCODE.configuration.barcode_data_formatting.many_code.prefix.slot 2
gjd.jrm.prefix.slot 2

Settings related to
job_run_data.graph.nodes.BARCODE.configuration.barcode_data_formatting.many_code are configured
using the getjobdata /setjobdata with the sub parameters in the following table:
```

**Table 115** many\_code

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .many_code .jrm	data_type_ delimiter	NONE SPACE COMMA TAB LINEBREAK	gjd.jrm.data_type_delimiter.slot 3 command: gjd,ok {response} sjd.jrm.data_type_delimiter TAB.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .many_code .jrm	data_types. encoding	TEXT BASE64	gjd.jrm.data_types.encoding.slot 3 command: gjd,ok {response} sjd.jrm.data_types.encoding.TEXT.slot 3 command: sjd,ok

**Table 115** many\_code (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .many_code .jrm	data_types .type	DECODED_STRING PPM SUBDECODED _STRING ANGLE SYMBOLIC CENTER_X CENTER_Y	gjd.jrm.data_types.type.slot 3 command: gjd,ok {response} sjd.jrm.data_types.type ANGLE.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .many_code .jrm	end_delimiter	NONE SPACE COMMA TAB LINEBREAK	gjd.jrm.end_delimiter.slot 3 command: gjd,ok {response} sjd.jrm.end_delimiter TAB.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .many_code .jrm	Prefix	String	gjd.jrm.prefix.slot 3 command: gjd,ok {response} sjd.jrm.prefix STRING.slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. barcode_data_ formatting .many_code .jrm	Suffix	String	gjd.jrm.suffix.slot 3 command: gjd,ok {response} sjd.jrm.suffix STRING.slot 3 command: sjd,ok

**decode**

```
getjobdata.job_run_data.graph.nodes.BARCODE.configuration.decode.Inverse1D.slot 2
```

## Using Zebra Easy Text Interface

The settings related to job\_run\_data.graph.nodes.BARCODE.configuration.decode can be configured using the getjobdata/setjobdata along with the sub parameter as shown in the below table

**Table 116** BARCODE.configuration.decode

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	adaptive_roi_ scale_factor	SMALL MEDIUM LARGE	gjd.jrd.adaptive_roi_scale_factor .slot 3 command: gjd,ok {response} sjd.jrd.adaptive_roi_scale_factor SMALL .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	Inverse1D	Number	gjd.jrd.Inverse1D.slot 3 command: gjd,ok {response} sjd.jrd.Inverse1D 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	advanced_decode_ settings. allow_rectangular _codes	true/false	gjd.jrd.advanced_decode_settings. allow_rectangular_codes.slot 3 command: gjd,ok {response} sjd.jrd.advanced_decode_settings. allow_rectangular_codes true .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	advanced_decode_ settings. contrast_threshold	Number	gjd.jrd.advanced_decode_settings. contrast_threshold.slot 3 command: gjd,ok {response} sjd.jrd.advanced_decode_settings. contrast_threshold 1 .slot 3 command: sjd,ok

**Table 116** BARCODE.configuration.decode (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	advanced_decode_ settings. decode_strategy	FAST MODERATE EXHAUSTIVE	gjd.jrd.advanced_decode_settings. decode_strategy.slot 3 command: gjd,ok {response} sjd.jrd.advanced_decode_settings. decode_strategy FAST .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	advanced_decode_ settings. detection_method	UNIFORM FINDER_PATTERN QUIET_ZONE	gjd.jrd.advanced_decode_settings. detection_method.slot 3 command: gjd,ok {response} sjd.jrd.advanced_decode_settings. detection_method UNIFORM .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	advanced_decode_ settings. max_module_size	Number	gjd.jrd.advanced_decode_settings. max_module_size.slot 3 command: gjd,ok {response} sjd.jrd.advanced_decode_settings. max_module_size 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	advanced_decode_ settings. min_module_size	Number	gjd.jrd.advanced_decode_settings. min_module_size.slot 3 command: gjd,ok {response} sjd.jrd.advanced_decode_settings. min_module_size 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	advanced_decode_ settings. min_row_count	Number	gjd.jrd.mode.slot 3 command: gjd,ok {response} sjd.jrd.mode CONTINUOUS .slot 3 command: sjd,ok

**Table 116** BARCODE.configuration.decode (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	advanced_decode_ settings. max_row_count	Number	gjd.jrd.advanced_decode_settings. max_row_count.slot 3 command: gjd,ok {response} sjd.jrd.advanced_decode_settings. max_row_count 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	advanced_decode_ settings. min_column_count	Number	gjd.jrd.advanced_decode_settings. min_column_count.slot 3 command: gjd,ok {response} sjd.jrd.advanced_decode_settings. min_column_count 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. .job_run_data. graph.nodes. BARCODE. configuration. decode .jrd BARCODE. configuration. decode .jrd	advanced_decode_ settings. max_column_count	Number	gjd.jrd.advanced_decode_settings. max_column_count.slot 3 command: gjd,ok {response} sjd.jrd.advanced_decode_settings. max_column_count 1 .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	Priority	NONE 1D 2D	gjd.jrd.priority.slot 3 command: gjd,ok {response} sjd.jrd.priority NONE .slot 3 command: sjd,ok

**Table 116** BARCODE.configuration.decode (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	barcode_dpm	true/false	gjd .jrd.barcode_dpm .slot 3 command: gjd,ok {response} sjd .jrd.barcode_dpm true .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	decode_all_ barcodes	true/false	gjd .jrd.decode_all_barcodes .slot 3 command: gjd,ok {response} sjd .jrd.decode_all_barcodes true .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	dpm	true/false	gjd .jrd.dpm .slot 3 command: gjd,ok {response} sjd .jrd.dpm true .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	enable_adaptive_ roi_search	true/false	gjd .jrd.enable_adaptive_roi_search .slot 3 command: gjd,ok {response} sjd .jrd.enable_adaptive_roi_search true .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	enable_bqm	true/false	gjd .jrd.enable_bqm .slot 3 command: gjd,ok {response} sjd .jrd.enable_bqm true .slot 3 command: sjd,ok

**Table 116** BARCODE.configuration.decode (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	enable_identical_ decode_symbols	true/false	gjd.jrd.enable_identical_decode_ symbols.slot 3 command: gjd,ok {response} sjd.jrd.enable_identical_decode_ symbols true .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	enable_partial_ results	true/false	gjd.jrd.enable_partial_results.slot 3 command: gjd,ok {response} sjd.jrd.enable_partial_results true .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	enable_string_ match_on_ entire_payload	true/false	gjd.jrd.enable_string_match_on_ entire_payload.slot 3 command: gjd,ok {response} sjd.jrd.enable_string_match_on_ entire_payload true .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	exhaustive_ manycode	true/false	gjd.jrd.exhaustive_manycode.slot 3 command: gjd,ok {response} sjd.jrd.mode exhaustive_manycode true .slot 3 command: sjd,ok
getjobdata setjobdata	.job_run_data. graph.nodes. BARCODE. configuration. decode .jrd	match_mode	DISABLED STRING_EXACT STRING_CONTAINS REGEX	gjd.jrd.match_mode.slot 3 command: gjd,ok {response} sjd.jrd.match_mode DISABLED .slot 3 command: sjd,ok

**Table 116** BARCODE.configuration.decode (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	match_string .all (update all similar tools in a job) .base64 (when base64 encoded string is to be provided) .friendly_name (update based on the friendly name of a tool)	String	<p>string should be within single quotes sjd .jrd.match_string 'string to be matched'</p> <p><b>To update all match strings of barcode tools in a job:</b> sjd .jrd.match_string 'string to be matched' .all</p> <p><b>To update all match strings of barcode tools in a job of a given slot number:</b> sjd .jrd.match_string 'string to be matched' .all .slot 19</p> <p><b>To update match string (base64 encoded) to a tool, it should not be within any quotes:</b> sjd .jrd.match_string aGVsbGBiYXNING .base64</p> <p><b>To update match string (base64 encoded) for all tools:</b> sjd .jrd.match_string aGVsbGBiYXNING .base64 .all</p> <p><b>To update match string (base64 encoded) to all tools with a given slot number:</b> sjd .jrd.match_string aGVsbGBiYXNING .base64 .all .slot 19</p> <p><b>To update the match string to a specific tool based on a friendly name:</b> sjd .jrd.match_string 'this is to change only barcode1' .friendly_name 'barcode1'</p> <p><b>To update the match string to a specific tool based on a friendly name to a specific job of a given slot number:</b> sjd .jrd.match_string 'this is to change only barcode1' .friendly_name 'bar2' .slot 19</p> <p><b>To update base64 encoded match string:</b> sjd .jrd.match_string aGVsbGBiYXNING .base64 .friendly_name 'barcode1'</p> <p><b>To update base64 encoded match string slot base:</b></p>

**Table 116** BARCODE.configuration.decode (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	multicode	true/false	gjd .jrd.multicode .slot 3 command: gjd,ok {response} sjd .jrd.multicode true .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	no_read_string	String	gjd .jrd.no_read_string .slot 3 command: gjd,ok {response} sjd .jrd.no_read_string STRING .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	ocr	true/false	gjd .jrd.ocr .slot 3 command: gjd,ok {response} sjd .jrd.ocr true .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	number_barcodes _to_decode	Number	gjd .jrd. number_barcodes_to_decode .slot 3 command: gjd,ok {response} sjd .jrd. number_barcodes_to_decode 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	percentSymbolInRoi	Number	gjd .jrd.percentSymbolInRoi .slot 3 command: gjd,ok {response} sjd .jrd.percentSymbolInRoi 1 .slot 3 command: sjd,ok

**Table 116** BARCODE.configuration.decode (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. decode . jrd	sorting_type	ALPHABETICAL FIRST_DECODED HORIZONTAL VERTICAL SYMOLOGY	gjd .jrd.sorting_type .slot 3 command: gjd,ok {response} sjd .jrd.sorting_type VERTICAL .slot 3 command: sjd,ok

### symbology settings

```
getjobdata .job_run_data.graph.nodes.BARCODE.configuration.symbology_settings.  
CODE128.Code128Length1 .slot 2
```

```
gjd .jrm.prefix .slot 2
```

The settings related to job\_run\_data.graph.nodes.BARCODE.configuration.barcode\_data\_formatting.symbology\_settings are configured using getjobdata/setjobdata with the sub parameters displayed in the following table:

**Table 117** BARCODE.configuration.symbology\_settings

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings . jrs	CODE128 .Code128Length1	Number	gjd .jrs.CODE128.Code128Length1 .slot 3 command: gjd,ok {response} sjd .jrs.CODE128.Code128Length1 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings . jrs	CODE128 .Code128Length2	Number	gjd .jrs.CODE128.Code128Length2 .slot 3 command: gjd,ok {response} sjd .jrs.CODE128.Code128Length2 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE128 .GS1_128	Number	gjd .jrs.CODE128.GS1_128 .slot 3 command: gjd,ok {response} sjd .jrs.CODE128.GS1_128 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE128 .ISBT_ Concatenation	Number	gjd .jrs.CODE128.ISBT_Concatenation .slot 3 command: gjd,ok {response} sjd .jrs.CODE128.ISBT_Concatenation 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE128 . ISBT_ Concatenation_ Redundancy	Number	gjd .jrs.CODE128. ISBT_Concatenation_Redundancy .slot 3 command: gjd,ok {response} sjd .jrs.CODE128. ISBT_Concatenation_Redundancy 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE128 .ISBT128	Number	gjd .jrs.CODE128.ISBT128 .slot 3 command: gjd,ok {response} sjd .jrs.CODE128.ISBT128 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE128 .IgnoreCode 128FNC4	Number	gjd .jrs.CODE128.IgnoreCode128FNC4 .slot 3 command: gjd,ok {response} sjd .jrs.CODE128.IgnoreCode128FNC4 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE39 .Code39 CheckDigit Verification	Number	gjd .jrs.CODE39. Code39CheckDigitVerification .slot 3 command: gjd,ok {response} sjd .jrs.CODE39. Code39CheckDigitVerification 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE39 .Code39 FullASCII Conversion	Number	gjd .jrs.CODE39. Code39FullASCIIConversion .slot 3 command: gjd,ok {response} sjd .jt.CODE39. Code39FullASCIIConversion 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE39 .ConvertCode39 toCode32	Number	gjd .jrs.CODE39. ConvertCode39toCode32 .slot 3 command: gjd,ok {response} sjd .jrs.CODE39. ConvertCode39toCode32 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE39 .LengthforCode39 Length1	Number	gjd.jrs.CODE39. LengthforCode39Length1 .slot 3 command: gjd,ok {response} sjd.jrs.CODE39. LengthforCode39Length1 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE39 .LengthforCode39 Length2	Number	gjd.jrs.mode .slot 3 command: gjd,ok {response} sjd.jrs.mode CONTINUOUS .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE39 .TransmitCode39 CheckDigit	Number	gjd.jrs.CODE39. TransmitCode39CheckDigit .slot 3 command: gjd,ok {response} sjd.jrs.CODE39. TransmitCode39CheckDigit 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE39 .TriopticCode39	Number	gjd.jrs.CODE39. TriopticCode39 .slot 3 command: gjd,ok {response} sjd.jrs.CODE39. TriopticCode39 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE93 .LengthforCode93 Length1	Number	gjd.jrs.CODE93. LengthforCode93Length1 .slot 3 command: gjd,ok {response} sjd.jrs.CODE93. LengthforCode93Length1 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	CODE93 .LengthforCode93 Length2	Number	gjd.jrs.CODE93. LengthforCode93Length2 .slot 3 command: gjd,ok {response} sjd.jrs.CODE93. LengthforCode93Length2 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	DATAMATRIX .DPM_Mode	Number	gjd.jrs. DATAMATRIX.DPM_Mode .slot 3 command: gjd,ok {response} sjd.jrs. DATAMATRIX.DPM_Mode 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	DATAMATRIX .Decode_Data_ Matrix_Mirror_ Images	Number	gjd.jrs.DATAMATRIX. Decode_Data_Matrix_Mirror_Images .slot 3 command: gjd,ok {response} sjd.jrs.DATAMATRIX. Decode_Data_Matrix_Mirror_Images 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	DATAMATRIX .InverseDataMatrix	Number	gjd.jrs. DATAMATRIX.InverseDataMatrix .slot 3 command: gjd,ok {response} sjd. DATAMATRIX.InverseDataMatrix 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	DATAMATRIX .GS1_Datamatrix	Number	gjd.jrs. DATAMATRIX.GS1_Datamatrix .slot 3 command: gjd,ok {response} sjd.jrs. DATAMATRIX.GS1_Datamatrix 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	DOTCODE .ECCErasure DotCode	Number	gjd.jrs. DOTCODE.ECCErasureDotCode .slot 3 command: gjd,ok {response} sjd.jrs. DOTCODE.ECCErasureDotCode 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	DOTCODE .InverseDotCode	Number	gjd.jrs. DOTCODE.InverseDotCode .slot 3 command: gjd,ok {response} sjd.jrs. DOTCODE.InverseDotCode 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	DOTCODE .MirrorDotCode	Number	gjd.jrs. DOTCODE.MirrorDotCode .slot 3 command: gjd,ok {response} sjd.jrs. DOTCODE.MirrorDotCode 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	DOTCODE .PrioritizeDotCode	Number	gjd.jrs. DOTCODE.PrioritizeDotCode .slot 3 command: gjd,ok {response} sjd.jrs. DOTCODE.PrioritizeDotCode 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	I25 .ConvertI2of5to EAN13	Number	gjd.jrs. I25.ConvertI2of5toEAN13 .slot 3 command: gjd,ok {response} sjd.jrs. I25.ConvertI2of5toEAN13 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	I25 .Febraban (I2of5)	Number	gjd.jrs. I25.Febraban(I2of5) .slot 3 command: gjd,ok {response} sjd.jrs.I25.Febraban(I2of5) 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	I25 .LengthforI2of5 Length1	Number	gjd.jrs. I25.LengthforI2of5Length1.slot 3 command: gjd,ok {response} sjd.jrs. I25.LengthforI2of5Length11.slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	I25 .LengthforI2of5 Length2	Number	gjd.jrs. I25.LengthforI2of5Length2 .slot 3 command: gjd,ok {response} sjd.jrs. I25.LengthforI2of5Length21 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	I25 .TransmitI2of5 CheckDigit	Number	gjd.jrs. I25.TransmitI2of5CheckDigit .slot 3 command: gjd,ok {response} sjd.jrs. I25.TransmitI2of5CheckDigit1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	MAXICODE	Number	gjd.jrs.MAXICODE .slot 3 command: gjd,ok {response} sjd.jrs.MAXICODE1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	PDF-417 .MicroPDF	Number	gjd.jrs.PDF-417.MicroPDF .slot 3  command: gjd,ok {response} sjd.jrs.PDF-417.MicroPDF 1 .slot 3  command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	QRCODE .GS1_QR	Number	gjd.jrs.QRCODE.GS1_QR .slot 3  command: gjd,ok {response} sjd.jrs.QRCODE.GS1_QR .slot 3  command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	QRCODE .Linked_QR_Mode	Number	gjd.jrs.QRCODE.GS1_QR .slot 3  command: gjd,ok {response} sjd.jrs.QRCODE.GS1_QR 1 .slot 3  command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	QRCODE .MicroQREnable	Number	gjd.jrs.QRCODE.MicroQREnable .slot 3  command: gjd,ok {response} sjd.jrs.QRCODE.MicroQREnable 1 .slot 3  command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .Bookland_Format	Number	gjd.jrs.UPCEAN.Bookland_Format .slot 3  command: gjd,ok {response} sjd.jrs.UPCEAN.Bookland_Format 1 .slot 3  command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .BooklandEAN	Number	gjd.jrs. UPCEAN.BooklandEAN .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.BooklandEAN 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .Convert_UPC_ E_to_A	Number	gjd.jrs. UPCEAN.Convert_UPC_E_to_A .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.Convert_UPC_E_to_A 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .Convert_UPC_ E1_to_A	Number	gjd.jrs. UPCEAN.Convert_UPC_E1_to_A .slot 3 command: gjd,ok {response} sjd.jrs.mode UPCEAN.Convert_UPC_E1_to_1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .EAN_13_JAN13	Number	gjd.jrs. UPCEAN.EAN_13_JAN13 .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.EAN_13_JAN13 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .EAN_8_JAN8	Number	gjd.jrs. UPCEAN.EAN_8_JAN8 .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.EAN_8_JAN8 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .EAN_8_JAN_8_ Extend	Number	gjd.jrs. UPCEAN.EAN_8_JAN_8_Extend .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.EAN_8_JAN_8_Extend 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .ISSN_EAN	Number	gjd.jrs. UPCEAN.ISSN_EAN .slot 3 command: gjd,ok {response} sjd.jrs. .UPCEAN.ISSN_EAN 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .Transmit_UPC_E1_ Check_Digit	Number	gjd.jrs. UPCEAN. Transmit_UPC_E1_Check_Digit .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN. Transmit_UPC_E1_Check_Digit 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .TransmitUPC_A CheckDigit	Number	gjd.jrs. UPCEAN.TransmitUPC_ACheckDigit .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.TransmitUPC_ACheckDigit 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN . UCC_Coupon_ Extended_Code	Number	gjd.jrs. UPCEAN. UCC_Coupon_Extended_Code .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN. UCC_Coupon_Extended_Code 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN . UPC_EAN_JAN Supplements	Number	gjd.jrs. UPCEAN.UPC_EAN_JANSupplements .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN. UPC_EAN_JANSupplements 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .UPC/EAN /JAN _Supplemental _Redundancy	Number	gjd.jrs. UPCEAN.UPC/EAN / JAN_Supplemental_Redundancy .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.UPC/EAN / JAN_Supplemental_Redundancy 1.slot 3 
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .UPC_A	Number	gjd.jrs. UPCEAN.UPC_A .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.UPC_A 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .UPC_A_ Preamble	Number	gjd.jrs. UPCEAN.UPC_A_Preamble .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.UPC_A_Preamble 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .UPC_E	Number	gjd.jrs. UPCEAN.UPC_E .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.UPC_E 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

<b>Command</b>	<b>Parameter</b>	<b>Sub Parameter</b>	<b>Range</b>	<b>Example</b>
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .UPC_E_ Preamble	Number	gjd.jrs. UPCEAN.UPC_E_Preamble .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.UPC_E_Preamble 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .UPC_E1	Number	gjd.jrs. UPCEAN.UPC_E1 .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.UPC_E1 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .UPC_E1_ Preamble	Number	gjd.jrs. UPCEAN.UPC_E1_Preamble .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.UPC_E1_Preamble 1 .slot 3 command: sjd,ok
getjobdata setjobdata	. job_run_data. graph.nodes. BARCODE. configuration. symbology_settings .jrs	UPCEAN .UserDefined Suppl	Number	gjd.jrs.UPCEAN.UserDefinedSupp1 .slot 3 command: gjd,ok {response} sjd.jrs.UPCEAN.UserDefinedSupp1 1 .slot 3 command: sjd,ok

**Table 117** BARCODE.configuration.symbology\_settings (Continued)

Command	Parameter	Sub Parameter	Range	Example
getjobdata	. job_run_data.	UPCEAN	Number	gjd.jrs.
setjobdata	graph.nodes. BARCODE. configuration. symbology_settings .jrs	.UserDefined Supp2		UPCEAN.UserDefinedSupp2 .slot 3 command: gjd,ok {response} sjd.jrs. UPCEAN.UserDefinedSupp2 1 .slot 3 command: sjd,ok

## uploadjob

Use the `uploadjob` command to upload the job to the device.



**NOTE:** This command requires the zjob in base64 format as an argument.

**Table 118** uploadjob

Command	short	Parameter	Data	Range	Example
uploadjob	uj	-	zjob (base64 format)	-	Uploadjob base64_data command:uploadjob,ok



**NOTE:** Use a python script to transfer large base64 files.

