

SEE MORE. DO MORE.

DISMANTLING AND TREATMENT INFORMATION

WhereCall Product

Conforms to Waste electrical and electronic equipment (WEEE) 2002/96/EC Category 3 product according Annex IA

Date: 10 October 2011

Zebra Technologies 2940 North 1st Street San Jose, CA 95134 <u>www.zebra.com</u>


Reuse and treatment information

Material	Weight [g]	Weight [%]	Important Information
Waste Disposal (WD)			
Ceramic	0	0	
Subtotal	0	0	
Recovery Operations (RO)			
Leather	0	0	
Rubber / elastomere	0	0	
Sealant compound	0	0	
Wood	0	0	
Subtotal	0	0	
Aluminium alloy cast	0	0	
Aluminium alloy wrought	0	0	
Battery	39.7	23.4	Remove battery
Cable	0	0	
Cable with plug	0	0	
Carton	0	0	
Copper	0	0	
Copper Alloy	0	0	
Gas	0	0	
Glass Optical	0	0	
Iron	0	0	
Liquid Crystal Displays	0	0	<100 cm ²
Magnesium alloy	0	0	
Magnetic material	0	0	
Metal nonferrous	0	0	
Paper	0	0	
Plastic	73.6	43.3	
Plug	0	0	
Printed circuit board	56.7	33.3	Remove Printed Circuit Board
Sintered material	0	0	
Steel	0	0	
Steel stainless	0	0	
Textile material	0	0	
Subtotal	170	100	
Re-Use (RU)			
Subtotal	0	0	
Total weight	170g	100%	

Product identification and selective treatment information



78 mm x 125 mm x 36 mm



Product Description:

The WhereCall is a palm-sized device in a yellow and gray colored case. A green colored actuator button is in the center of the device. A liquid crystal display (LCD) screen is located above the button. WhereCalls are powered by AA-size Lithium-Thionyl Chloride battery cells.

Dismantling Instructions

- A) Open case by removing two screws on front and four on back.B) Remove printed circuit board from case.
- C) Remove two batteries from battery holder.

